

Leica TPS1200+/ TS30/TM30 Applications Field Manual



Version 7.1
English

- when it has to be **right**

Leica
Geosystems

Introduction

Purchase

Congratulations on the purchase of a TPS1200+/TS30/TM30 series instrument.



To use the product in a permitted manner, please refer to the detailed safety directions in the User Manual.

Product identification


The type and the serial number of your product are indicated on the type plate. Enter the type and serial number in your manual and always refer to this information when you need to contact your agency or Leica Geosystems authorized service workshop.

Type: _____

Serial No.: _____

Symbols

The symbols used in this manual have the following meanings:

Type	Description
	Important paragraphs which must be adhered to in practice as they enable the product to be used in a technically correct and efficient manner.

Trademarks

- CompactFlash and CF are trademarks of SanDisk Corporation
 - Bluetooth is a registered trademark of Bluetooth SIG, Inc
- All other trademarks are the property of their respective owners.

Validity of this instrument

This manual applies to TPS1200+ and TS30/TM30 instruments. Due to the different instruments and equipment, some parts of the manual may not be valid. Where there are differences between the instruments they are clearly described.

Available documentation

Refer to the following resources for all TPS1200+/TS30/TM30 documentation and software

- the Leica SmartWorx DVD
- <http://www.leica-geosystems.com/downloads>

Table of Contents

In this manual	Chapter	Page
	1 Application Programs - Getting Started	7
	1.1 Starting an Application Program	7
	1.2 Configuration of a Logfile	10
	2 COGO	11
	2.1 Overview	11
	2.2 Accessing COGO	12
	2.3 Configuring COGO	13
	2.4 COGO Calculation - Inverse Method	16
	2.4.1 Overview	16
	2.4.2 Inverse Between Two Known Points	18
	2.4.3 Inverse Between a Known Point and a Line	19
	2.4.4 Inverse Between a Known Point and an Arc	20
	2.5 COGO Calculation - Traverse Method	22
	2.6 COGO Calculation - Intersections Method	26
	2.7 COGO Calculation - Line/Arc Calculations Method	30
	2.8 COGO Calculation - Shift, Rotate & Scale (Manual) Method	36
	2.9 COGO Calculation - Shift, Rotate & Scale (Match Pts) Method	41
	2.10 COGO Calculation - Area Division	43
	3 Determine Coordinate System - General	49
	3.1 Overview	49
	3.2 Configuring Det Coord System	51
	3.2.1 Configuring Det Coord System - Normal	51
	3.2.2 Configuring Det Coord System - One Point Localisation	53
	4 Determine Coordinate System - Normal	55
	4.1 Determining a New/Updating a Coordinate System	55
	4.2 Selecting/Editing a New Pair of Matching Points	60
	4.3 Transformation Results	61
	5 Determine Coordinate System - One Point Localisation	63
	5.1 Accessing Det Coord System - One Point Localisation	63
	5.2 Det Coord System - Onestep/Twostep Transformation	64
	5.2.1 Determining a New/Coordinate System	64
	5.2.2 Computing the Grid Scale Factor for Twostep Transformation	70
	5.2.3 Computing the Height Scale Factor for Twostep Transformation	71
	5.3 Det Coord System - Classic 3D Transformation	72
	5.4 Computing Required Azimuth	73
	6 GPS Survey	75
	6.1 Overview	75
	6.2 Management of Antennas	79
	6.2.1 Overview	79
	6.2.2 Creating a New Antenna/Editing an Antenna	80

7	Hidden Point	83
7.1	Overview	83
7.2	Configuring Hidden Point	85
7.3	Measuring Hidden Points	87
8	Reference Line	91
8.1	Overview	91
8.2	Configuring Reference Line	92
8.3	Starting Reference Line	97
8.3.1	Manually Entering a Reference Line/Arc	97
8.3.2	Selecting an Existing Reference Line/Arc	100
8.3.3	Defining the Offsets related to a Reference Line/Arc	104
8.3.4	Defining the Slope related to a Reference Line/Arc	106
8.4	Measuring to a Reference Line/Arc	110
8.5	Staking to a Reference Line/Arc	113
8.6	Gridstaking to a Reference Line/Arc	117
8.7	Staking to a Polyline	119
8.7.1	Overview	119
8.7.2	Accessing Staking to Polylines & Choosing a Polyline	120
8.7.3	Stake Parameters	121
8.7.4	Staking Operation	123
8.7.5	Results of Stakeout	126
9	Reference Plane & Face Scan	129
9.1	Overview	129
9.2	Configuring Reference Plane	132
9.3	Managing Reference Planes	134
9.4	Measuring Points to a Reference Plane	139
9.5	Scanning a Plane	140
10	Sets of Angles	143
10.1	Overview	143
10.2	Sets of Angles	144
10.2.1	Accessing Sets of Angles	144
10.2.2	Configuring Sets of Angles	145
10.2.3	Managing the Points List	148
10.2.4	Measuring the New Points	150
10.2.5	Measuring the Sets	151
10.2.6	Calculating Angles and Distances in Two Faces	152
10.2.7	Viewing Angle and Distance Results in Two Faces	153
10.2.8	Viewing Angle and Distance Results in One Face	155
10.3	Monitoring	156



11 Setup	159
11.1 Overview	159
11.2 Configuring Setup	162
11.3 Setup with SmartStation	165
11.4 Setup with SmartPole	168
11.5 Setup Reminder	171
11.6 Setup Method - Set Azimuth	172
11.7 Setup Method - Known Backsight Point	175
11.8 Setup Method - Orientation & Height Transfer	177
11.9 Setup Method - Resection/Resection Helmert	180
11.10 Setup Method - Local Resection	181
11.11 Setup Results - Least Square and Robust Calculation	182
11.12 Setup Results - Local Resection	185
12 Stakeout	187
12.1 Overview	187
12.2 Configuring Stakeout	188
12.3 Staking Out	193
12.4 Stakeout Difference Limit Exceeded	196
13 Survey - General	197
14 Survey - Auto Points	201
14.1 Overview	201
14.2 Configuring Auto Points	202
14.3 Auto Points	206
14.4 Offset Points of Auto Points	209
14.4.1 Overview	209
14.4.2 Configuring Offset Points	210
15 Survey - Remote Point	213
15.1 Overview	213
15.2 Configuring Remote Point	214
15.3 Remote Point	215
16 Survey Cross Section	217
16.1 Overview	217
16.2 Configuring Survey Cross Section	218
16.3 Surveying Cross Sections	220
16.4 Cross Section Templates	222
16.4.1 Accessing Cross Section Template Management	222
16.4.2 Creating/Editing a Cross Section Template	223

17 Traverse	227
17.1 Overview	227
17.2 Configuring Traverse	228
17.3 Traverse Information and Traverse Management	230
17.4 Traverse Data	232
17.5 Traverse Point Results	233
17.6 Traverse Results	235
17.7 Traverse Methods	237
17.7.1 Starting Traverse	237
17.7.2 Continuing an Existing Traverse	238
17.7.3 Closing Traverse	240
17.8 Traverse Adjustment	242
17.8.1 Accessing Traverse Adjustment	242
17.8.2 Adjustment Results	243
18 Volume Calculations	245
18.1 The Volume Calculations Menu	245
18.2 Step 1) Surveying the Points	246
18.3 Step 2) Triangulating the Surface	248
18.4 Step 3) Computing the Volume	251
Index	253

1 Application Programs - Getting Started


1.1 Starting an Application Program

Access an application program step-by-step

Step	Description
1.	PROG. The PROG key opens the TPS1200+ Programs menu.
2.	Select an application program from the menu.
3.	Press CONT (F1) to access a Begin screen.
	Some application programs are protected. They are activated through a specific licence key. This can either be typed in Main Menu: Tools...Licence Keys or the first time the application program is started.
	Four application programs can be open at one time. XX Begin is shown for the application program opened first, but not for the following application programs.

XX Begin

SURVEY Survey Begin is shown as an example. Additional fields are available for particular application programs.



11:40
SURVEY

Survey Begin

Job : active job

Coord System : <None>

Codelist : <None>

Config Set : survey

Reflector : Leica Circ Prism

Add. Constant: 0.0

Q2 a

CONT CONF SETUP CSYS

CONT (F1)

To accept changes and access the subsequent screen.

CONF (F2)

To configure the application program.

SETUP (F3)

To set up the station.

CSYS (F6)


To select a different coordinate system. Not available for **<Use Auto CrdSys: Yes>** configured in **CONG-FIGURE Additional Rover Settings**.

Description of fields

Field	Option	Description
<Stakeout Job:>	Choicelist	<ul style="list-style-type: none"> Available for Stakeout. The job containing the points to be staked.
<Fixpoint Job:>	Choicelist	<ul style="list-style-type: none"> Available for Traverse. The job containing points for the control points, to begin, to check and to end the traverse.

Field	Option	Description
<Job:>	Choicelist	<ul style="list-style-type: none"> The active job. For Stakeout and Reference Line: points which are occupied after staking out are stored in this job.
<Coord System:>	Output	<ul style="list-style-type: none"> The coordinate system currently attached to the selected <Job:>.
<Codelist:>	Choicelist	<ul style="list-style-type: none"> No codes are stored in the selected <Job:>. All codelists from Main Menu: Manage... \Codelists can be selected.
	Output	<ul style="list-style-type: none"> Codes have already been stored in the selected <Job:>.
<DTM Job:>	Choicelist	<ul style="list-style-type: none"> Available for Stakeout if <Use DTM: DTM only> and <Use DTM: DTM & Stake Job> in STAKEOUT Configuration, Heights page. Available for Reference Line if <Heights: Use DTM Model> in REFLINE Configuration, Heights page. To select a DTM to be staked and to select the active DTM layer to be used. Heights are then staked out relative to the selected DTM.
<Config Set:>	Choicelist	<ul style="list-style-type: none"> The active configuration set.
<Reflector:>	Choicelist	<ul style="list-style-type: none"> The active reflector.
<Add. Constant:>	Output	<ul style="list-style-type: none"> The additive constant stored with the chosen reflector.

Description of fields for Determine Coordinate System

Field	Option	Description
<Name:>	User input	<p>A unique name for the coordinate system. The name may be up to 16 characters in length and may include spaces. Input is mandatory.</p> <p> Entering the name of an existing coordinate system will allow that system to be updated.</p>
<WGS84Pts Job:>	Choicelist	The job from which the points with WGS84 coordinates will be taken.
<Local Pts Job:>	Choicelist	The job from which the points with local coordinates will be taken.

Field	Option	Description
<Method:>	Choicelist	Method used to determine the coordinate system.

Next step

IF the application program	THEN
is to be accessed	CONT (F1) accepts the changes and starts the application program. Refer to the relevant chapters.
is to be configured	CONF (F2) . Refer to the relevant chapters.

1.2 Configuration of a Logfile

Description

A logfile is a summary of the calculations done while using an application program. The logfile is written to the \DATA directory of the CompactFlash card or internal memory if fitted. The creation of a logfile can be activated while configuring an application program.

Access step-by-step

Step	Description
1.	PROG . The PROG key opens the TPS1200+ Programs menu.
2.	Select an application program from the menu.
3.	Press CONT (F1) to access a Begin screen.
4.	Press CONF (F2) to access XX Configuration .
5.	Press PAGE (F6) until the Logfile page is active.

XX Configuration, Logfile page

Description of fields

Field	Option	Description
<Write Logfile:>	Yes or No	To generate a logfile when the application program is exited.
<File Name:>	Choicelist	Available for <Write Logfile: Yes>. The name of the file to which the data should be written.
<Format File:>	Choicelist	Available for <Write Logfile: Yes>. A format file defines which and how data is written to a logfile. Format files are created using LGO.

Next step

PAGE (F6) changes to the first page on this screen.

2.1 Overview

Description

- COGO is an application program for **coordinate geometry** calculations such as:
 - coordinates of points.
 - distances between points.
 - bearings between points.
- The calculations can be made from:
 - existing point data in the job, known distances or known azimuths.
 - measured points.
 - entered coordinates.



- Changing coordinates of a point which has been previously used in COGO does not result in the point being recomputed.

COGO calculation methods


- The COGO calculation methods are:
 - Inverse.
 - Traverse.
 - Intersections.
 - Line calculations.
 - Arc calculations.
 - Shift, Rotate & Scale (Manual)
 - Shift, Rotate & Scale (Match Pts)
 - Area Division

Distances and azimuths

- Type of distances: The choices are: Ground, Grid, Ellipsoidal.
- Type of azimuths: The azimuths are grid azimuths relative to the local grid.

2.2 Accessing COGO

Access step-by-step

Step	Description
1.	PROG. The PROG key opens the TPS1200+/TS30/TM30 Programs menu.
2.	Select COGO and press CONT (F1) .
3.	Press CONT (F1) to access COGO COGO Menu All COGO calculation methods and the option to end COGO are listed. Select the COGO calculation method to be started.
4.	Press CONT (F1) to access the screen for the COGO calculation method.
	The screens for each COGO calculation method can be accessed directly by pressing a configured hot key or USER . The currently active configuration set and job are used.


2.3 Configuring COGO

Access step-by-step

Step	Description
1.	PROG. The PROG key opens the TPS1200+/TS30/TM30 Programs menu.
2.	Select COGO and press CONT (F1) .
3.	Press CONF (F2) to access COGO Configuration .

COGO Configuration, Parameters page

The explanations for the softkeys given below are valid for all pages.



CONT (F1)

To accept changes and return to the screen from where this screen was accessed.

Description of fields

Field	Option	Description
<Distance Type:>	Grid, Ground or Ellipsoid	The type of distances and offsets to be accepted as input, shown as output and used in the calculation.
		<p>a Ellipsoid Known P1 First known point P2 Second known point Unknown d1 Ground distance d2 Ellipsoid distance d3 Grid distance</p>
<Two Faces:>	Yes or No	Defines if the instrument measures the second face automatically after storing the first or not.
<Use Offsets:>	Yes or No	Activates the use of offsets in the COGO calculations. Input fields for the offsets are available in COGO XX .
<Store Pts As:>	MEAS or CTRL	To store the cogo point with point class MEAS or with point class CTRL.

Field	Option	Description
		Points stored with point class MEAS can be stored with the same point ID. The averaging functionality (configured under job management) can then be used to calculate an average for these points. Points stored with point class CTRL can only be stored with a unique point ID. A message is always displayed when a point is about to be stored with an already existing point ID. The user can then decide to either keep the existing point or overwrite the existing point.
<Est Pos Qlty:>	User input	The estimated value for the position quality assigned to all calculated COGO points which is used for the averaging calculation.
<Est Ht Qlty:>	User input	The estimated value for the height quality assigned to all calculated heights which is used for the averaging calculation.
When the Intersections method=TPS Obs-TPS Obs, the following fields apply:		
<Compute Ht:>	Using Average, Use Upper Height or Use Lower Height	Defines the height being used.

Next step

PAGE (F6) changes to the **Residuals** page.

COGO Configuration, Residuals page

This page applies to COGO Shift, Rotate & Scale (Match Pts).

Description of fields

Field	Option	Description
<Easting:>, <Northing:> or <Height:>	User input	The limit above which Easting/Northing/Height residuals will be flagged as possible outliers.
<Residual Distbtn:>	None 1/Distance^{XX} Multiquadratic	The method by which the residuals of the control points will be distributed throughout the transformation area. No distribution is made. Residuals remain with their associated points. Distributes the residuals according to the distance between each control point and the newly transformed point. Distributes the residuals using a multiquadratic interpolation approach.

Next step

PAGE (F6) changes to the **Logfile** page. Refer to "1.2 Configuration of a Logfile".




<Azimuth:> is used throughout this chapter. This should always be considered to also mean **<Bearing:>**.

2.4 COGO Calculation - Inverse Method

2.4.1 Overview

Description

It is possible to compute an inverse result between point, line and arc elements:



Option 1: inverse between point - point

To compute an inverse between two known points.

Known elements:

P1 First known point (From)

P2 Second known point (To)


Unknown elements:

α Direction from P1 to P2

d1 Slope distance between P1 and P2

d2 Horizontal distance between P1 and P2

d3 Height difference between P1 and P2



Option 2: inverse between point - line

To compute an inverse between a known point and a given line (the inverse is computed as the perpendicular between the known point and the given line).

Known elements:

P0 Instrument station

P1 Starting point

P2 End point or the direction from P1 to P2


P3 Offset point

Unknown elements:

P4 Base point

d1 The perpendicular offset to the base point

d2 The distance along the line



Option 3: inverse between point - arc

To compute an inverse between a known point and a given arc (the inverse is computed as the perpendicular between the known point and the given arc).

Known elements:

P0 Instrument station

P1 Starting point

P2 End point

P3 Offset point

P4 Second point or arc radius or arc/chord length

Unknown elements:

P4 Base point

d1 The perpendicular offset to the base point

d2 The distance along the arc

The coordinates of the points must be known. The points:

- may be taken from the active job.
 - may be measured during the COGO calculation.
 - may be entered manually.
-

2.4.2 Inverse Between Two Known Points

Access

Refer to "2.2 Accessing COGO" to access **COGO Inverse**.

Calculating

The screenshot shows the 'Inverse Input' screen with the following data:

From	:	201	↓
To	:	200	↓
Azimuth	:	150.0000	g
HDist-Grid	:	141.424	m
Δ Height	:	0.000	m
Slope Dist	:	141.424	m
Grade	:	1:0	hv

At the bottom, there is a menu with three options: **STORE**, **SURVY**, and **PAGE**.

STORE (F1)

To store the result.

SURVY (F5)

To measure a known point for the calculation.

SHIFT CONF (F2)

To configure the program.

PAGE (F6)

To change to another page on the screen.

Description of fields

Field	Option	Description
<From:> or <To:>	Choicelist	The point ID of the two known points. To type in coordinates for a known point open the choicelist. Press NEW (F2) to create a new point.
<Azimuth:>	Output	The direction from the first point to the second point.
<HDist-XX:>	Output	The horizontal distance between the two points.
<ΔHeight:>	Output	The height difference between the two points.
<Slope Dist:>	Output	The slope distance between the two points.
<Grade:>	Output	The grade between the two points.
<ΔEasting:>	Output	The difference in Easting between the two points.
<ΔNorthing:>	Output	The difference in Northing between the two points.

Storing the results step-by-step

Step	Description
1.	Press STORE (F1) to store the inverse result to the active job. There are no points stored to the database, only the inverse result.
2.	Inverse results can be exported from the job using a format file. The format file is created with Format Manager in LEICA Geo Office.

2.4.3 Inverse Between a Known Point and a Line

Access

Refer to "2.2 Accessing COGO" to access **COGO Inverse**.

Calculating

22:37
COGO
Inverse Pt - Line Input
Input Map
Method : 2 Points
Start Point : 200
End Point : 201
Offset Point : 101
CALC INV LAST SURVY PAGE

CALC (F1)

To calculate the result.

INV (F2)

To calculate the inverse between two points.

LAST (F4)

To select the values for distance and offset from previous COGO inverse calculations.

SURVY (F5)

To measure a known point for the calculation.

SHIFT CONF (F2)

To configure the program

SHIFT MODIF (F4)

To modify the original azimuth, distance or offset value.

PAGE (F6)

To change to another page on the screen.

Description of fields

Field	Option	Description
<Method:>		2 Points or Pt/Brg/Dist . The method for calculating the inverse result.
<Start Point:>	Choicelist	The point ID defining the start of the line.
<End Point:>	Choicelist	The point ID defining the end of the line.
<Azimuth:>	Output	The direction from the first point to the second point.
<HDist-XX:>	Output	The horizontal distance between the two points.
<Offset Point:>	Choicelist	The point ID defining an offset to the line.

Storing the results step-by-step

Step	Description
1.	Press CALC (F1) to calculate the inverse result.
2.	Press STORE (F1) to store the inverse result to the active job. There are no points stored to the database, only the inverse result.
3.	Inverse results can be exported from the job using a format file. The format file is created with Format Manager in LEICA Geo Office.

2.4.4 Inverse Between a Known Point and an Arc

Access

Refer to "2.2 Accessing COGO" to access **COGO Inverse**.

Calculating

23:06
COGO

IR STD

Inverse Pt - Arc Input

Input Map

Method : 3 Points

Start Point : 200

Second Point : 201

End Point : 202

Offset Point : 101

CALC INV LAST SURVY PAGE

CALC (F1)

To calculate the result.

INV (F2)

To calculate the inverse between two points.

LAST (F4)

To select the values for distance and offset from previous COGO Inverse calculations.

SURVY (F5)

To measure a known point for the calculation.

SHIFT CONF (F2)

To configure the program.

SHIFT MODIF (F4)

To modify the original azimuth, distance or offset value.

PAGE (F6)

To change to another page on the screen.

Description of fields

Field	Option	Description
<Method:>		3 Points or 2 Points/Radius or 2 Tgnts/Radius or 2 Tgnts/Arc Lngt or 2 Tgnts/Chrd Lngt . The method for calculating the inverse result.
<Start Point:>	Choicelist	The point ID defining the start of the arc.
<Second Point:>	Choicelist	The point ID defining a second point on the arc.
<End Point:>	Choicelist	The point ID defining the end of the arc.
<Arc Length:>	User Input	The arc length.
<Azimuth:>	Output	The direction from the first point to the second point.
<Chord length:>	User Input	The chord length of the arc.
<HDist-XX:>	Output	The horizontal distance between the two points.
<Offset Point:>	Choicelist	The point ID defining an offset to the arc.
<PI Point:>	Choicelist	The point ID defining the intersection of the tangents.

Field	Option	Description
<Point 1:>	Choicelist	The point ID (with PI Point) defining the 1st tangent.
<Point 2:>	Choicelist	The point ID (with PI Point) defining the 2nd tangent.
<Radius:>	User Input	The radius of the arc.


**Storing the results
step-by-step**

Step	Description
1.	Press CALC (F1) to calculate the inverse result.
2.	Press STORE (F1) to store the inverse result to the active job. There are no points stored to the database, only the inverse result.
3.	Inverse results can be exported from the job using a format file. The format file is created with Format Manager in LEICA Geo Office.

2.5 COGO Calculation - Traverse Method

Diagram

COGO traverse calculation with offset for a single point




Known

- P1 Known point
- α Direction from P1 to P2
- d1 Distance between P1 and P2
- d2 Positive offset to the right
- d3 Negative offset to the left

Unknown

- P2 COGO point without offset
- P3 COGO point with positive offset
- P4 COGO point with negative offset

COGO traverse calculation without offset for multiple points



Known

- P1 Known point
- $\alpha1$ Direction from P1 to P2
- $\alpha2$ Direction from P2 to P3
- $\alpha3$ Direction from P3 to P4
- $\alpha4$ Direction from P3 to P5
- d1 Distance between P1 and P2
- d2 Distance between P2 and P3
- d3 Distance between P3 and P4
- d4 Distance between P3 and P5

Unknown

- P2 First COGO point
- P3 Second COGO point
- P4 Third COGO point - sideshot
- P5 Fourth COGO point

Access

Refer to "2.2 Accessing COGO" to access **COGO Traverse Input**.

COGO Traverse Input, Input page

13:04	IR	STD			
COGO					
Traverse Input					
Input	Map				
Method	:	Angle Right			
From	:	0002	↓		
Backsight	:	0001	↓		
Angle Right	:	230.8432	g		
Azimuth	:	282.4382	y		
HDist-Grid	:	95.769	m		
Offset	:	0.000	m		
Q2 a ↑					
CALC	INV	SSHOT	LAST	SURVY	PAGE

CALC (F1)

To calculate the COGO point.

INV (F2)

To calculate the values for the azimuth, distance and the offset from two existing points. Available if **<Azimuth:>**, **<HDist-XX:>** or **<Offset:>** is highlighted.

SSHOT (F3)

To calculate the point as a sideshot.

LAST (F4)

To select the values for the distance and the offset from previous COGO inverse calculations. Available if **<Azimuth:>**, **<HDist-XX:>** or **<Offset:>** is highlighted.

SURVY (F5)

To measure a point for the COGO calculation. Available if **<From:>** or **<Backsight:>** is highlighted.


SHIFT CONF (F2)

To configure the COGO application program.

SHIFT MODIF (F4)

To type in numbers for the multiplication, division, addition and subtraction with the original azimuth, distance or offset value. The standard rules of mathematical operations apply. Available if **<Azimuth:>**, **<Angle Right:>**, **<HDist-XX:>** or **<Offset:>** is highlighted.

Description of fields


Field	Option	Description
<Method:>	Azimuth or Angle Right	The direction from the known point to the COGO point.
<From:>	Choicelist	The point ID of the known point.  To type in coordinates for a known point open the choicelist when <From:> is highlighted. Press NEW (F2) to create a new point.
<Backsight:>	Choicelist	The point ID of a point used as backsight. Available for <Method: Angle Right> .
<Angle Right:>	User input	The angle between <Backsight:> and the new COGO point to be calculated from the point selected as <From:> . A positive value is for clockwise angles. A negative value is for counter clockwise angles. Available for <Method: Angle Right> .
<Azimuth:>	Output	The direction from the known point to the COGO point. For <Method: Angle Right> this is calculated from <Angle Right:> .

Field	Option	Description
<HDist-XX:>	User input	The horizontal distance between the known point and the COGO point.
<Offset:>	User input	The offset of the COGO point from the line of direction. A positive offset is to the right, a negative offset is to the left.

Next step

CALC (F1) calculates the result and accesses **COGO Traverse Results**.

The calculated coordinates are displayed.



STORE (F1)

To store the result and return to **COGO Traverse Input, Input** page.

COORD (F2)

To view other coordinate types unless **<Coord System: None>**.

STAKE (F5)

To access the Stakeout application program and stake out the calculated COGO point.

SHIFT INDIV (F5) or SHIFT RUN (F5)

To change between entering an individual point ID different to the defined ID template and the running point ID according to the ID template.

SHIFT QUIT (F6)

Does not store the COGO point and exits COGO calculation.



Description of fields

Field	Option	Description
<Point ID:>	User input	The identifier for the COGO point depending on the point ID template configured. The point ID can be changed. <ul style="list-style-type: none"> To start a new sequence of point ID's overtype the point ID. SHIFT INDIV (F5) for an individual point ID independent of the ID template. SHIFT RUN (F5) changes back to the next ID from the configured ID template.

Next step

PAGE (F6) changes to the **Code** page.

COGO
Traverse Results
Code page

The settings for <Thematc Codes:> in **CONFIGURE Coding & Linework** determines the availability of the fields and softkeys. They are identical to those of thematic coding with/without codelist. Refer to "TPS1200+ System Field Manual" for information on coding.


Next step

PAGE (F6) changes to the **Plot** page.

2.6 COGO Calculation - Intersections Method

Diagram

Bearing - Bearing



TPS12_148


Known

- P1 First known point
- P2 Second known point
- α_1 Direction from P1 to P3
- α_2 Direction from P2 to P3

Unknown

- P3 COGO point

Bearing - Distance



TPS12_149


Known

- P1 First known point
- P2 Second known point
- α Direction from P1 to P3 and P4
- r Radius, as defined by the distance from P2 to P4 and P3

Unknown

- P3 First COGO point
- P4 Second COGO point

Distance - Distance



TPS12_150


Known

- P1 First known point
- P2 Second known point
- r_1 Radius, as defined by the distance from P1 to P3 or P4
- r_2 Radius, as defined by the distance from P2 to P3 or P4

Unknown

- P3 First COGO point
- P4 Second COGO point

By Points



TPS12_151


Known

- P1 First known point
- P2 Second known point
- P3 Third known point
- P4 Fourth known point
- a Line from P1 to P2
- b Line from P3 to P4

Unknown

- P5 COGO point

TPS Observation - TPS Observation



GPS12_170

Known

- P0 First known point (TPS Stn)
- P1 Second known point (TPS Stn)
- α_1 Direction from P0 to P2
- α_2 Direction from P1 to P2

Unknown

- P2 COGO point


Access

Refer to "2.2 Accessing COGO" to access **COGO Intersection Input**.

COGO Intersection Input, Input page

The setting for **<Method:>** in this screen determines the availability of the subsequent fields and softkeys. The softkeys are identical to those available for traverse COGO calculations. Refer to "2.5 COGO Calculation - Traverse Method" for information on the softkeys.

Description of fields

Field	Option	Description
<Method:>	Choicelist	The type of intersection COGO calculation.
<1st Point:> , <2nd Point:> , <3rd Point:> or <4th Point:>	Choicelist	The point ID of the known point. For <Method: By Points> , these are the start and end points of the lines.  To type in coordinates for a known point open the choicelist when this field is highlighted. Press NEW (F2) to create a new point.
<1st TPS Stn:> or <2nd TPS Stn:>	Choicelist	Only for <Method: TPS Obs- TPS Obs> . The point ID of the known point.
<TPS Measmnt:>	Choicelist	Only for <Method: TPS Obs- TPS Obs> . The point ID of the TPS measurement made from the selected station for <1st TPS Stn:> or <2nd TPS Stn:> .
<Azimuth:>	User input	The direction from the first known point to the COGO point. For <Method: Brng & Brng> and <Method: Brng & Dist> . For <Method: TPS Obs- TPS Obs> the option is an output field.

Field	Option	Description
<Offset:>	User input User input	Input optional. <ul style="list-style-type: none"> For <Method: Brng & Brng> and <Method: Brng & Dist>. The offset of the COGO point from the line of direction. A positive offset is to the right, a negative offset is to the left. For <Method: By Points>: The offset of the line in the direction start point to end point. A positive offset is to the right, a negative offset is to the left.
<HDist-XX:>	User input	The horizontal distance between the two known points. Available for <Method: Brng & Dist> and <Method: Dist & Dist>.

Next step


CALC (F1) calculates the result and accesses **COGO XX Results**.

For <Method: Brng - Dist>, two results are calculated. They are displayed on the **Result1** page and the **Result2** page. For simplicity, the title **Result** is used in the following.

COGO XX Results, Result page

The calculated coordinates are displayed.

The majority of softkeys is identical to those available for traverse COGO calculations. Refer to "2.5 COGO Calculation - Traverse Method" for information on the identical softkeys.



STORE (F1)

To store the result and return to **COGO Intersection Input, Input** page. For <Method: Brng - Dist>, each result must be stored individually on the relevant page.

RSLT1 (F3) or RSLT2 (F3)

To view the first and second result. Available for <Method: Brng - Dist>.

STAKE (F5)

To access the Stakeout application program and stake out the calculated COGO point.



Description of fields

Field	Option	Description
<Point ID:>	User input	The identifier for the COGO point depending on the point ID template configured. The point ID can be changed. <ul style="list-style-type: none">To start a new sequence of point ID's overwrite the point ID.SHIFT INDIV (F5) for an individual point ID independent of the ID template. SHIFT RUN (F5) changes back to the next ID from the configured ID template.
<Ortho Ht:> or <Local Ell Ht:>	User input	The height of the first point used in the COGO calculation is suggested. A height value to be stored with the calculated point can be typed in. For <Method: TPS Obs- TPS Obs > the option is an output field.
<Ht Computed:>	Output	The height modulus being used in the COGO calculation.

Next step

PAGE (F6) changes to the **Code** page.

COGO XX Results, Code page

The settings for <Thematc Codes:> in **CONFIGURE Coding & Linework** determines the availability of the fields and softkeys. They are identical to those of thematic coding with/without codelist. Refer to TPS1200+ Technical Reference Manual for information on coding.

Next step

PAGE (F6) changes to the **Plot** page.


2.7 COGO Calculation - Line/Arc Calculations Method



The functionality of all screens and fields are similar for both the COGO line and COGO arc calculations. For simplicity, both COGO calculation methods are explained in this chapter. The screen names, field names and explanations for lines are used. If required, additional information is given for COGO arc calculations.

Diagrams Line Calculation

Base Point



Known

P0 Instrument station

P1 <Start Point:>

P2 <End Point:>

P3 <Offset Point:>


Unknown

P4 Base point

d1 <Offset-XX:>

d2 <ΔLine-XX:>

Offset Point



Known

P0 Instrument station

P1 <Start Point:>

P2 <End Point:>

d1 <Offset-XX:>


d2 <ΔLine-XX:>

Unknown

P3 <Offset Point:>

P4 Base point

Segmentation




Line divided by

<Method: No. of Segments>

P0 <Start Point:>

P1 <End Point:>

d Equally spaced segments result from dividing a line by a certain number of points.



Line divided by

<Method: Segment Length>

P0 <Start Point:>


P1 <End Point:>

d1 <Seg Length:>

d2 Remaining segment

Diagrams
Arc Calculation

Arc Center



TPS12_217


Known

- P0 Instrument station
- P1 <Start Point:>
- P2 <End Point:>

Unknown

- P3 Arc center
- d1 <Arc Radius:>
- d2 <Arc Length:>

Base Point



TPS12_186


Known

- P0 Instrument station
- P1 <Start Point:>
- P2 <End Point:>
- P3 <Offset Point:>

Unknown

- P4 Base point
- d1 <ΔOffset-XX:>
- d2 <ΔArcDist-XX:>

Offset Point



TPS12_186

Known

- P0 Instrument station
- P1 <Start Point:>
- P2 <End Point:>
- d1 <ΔOffset-XX:>
- d2 <ΔArcDist-XX:>

Unknown

- P3 <Offset Point:>
- P4 Base point

Access

Refer to "2.2 Accessing COGO" to access **COGO Line Calculations Input**.

COGO
Line Calculations
Input,
Input page

- The setting for <Task:> and <Method:> in this screen determines the availability of the subsequent fields.
- The softkeys are identical to those available for traverse COGO calculations. Refer to "2.5 COGO Calculation - Traverse Method" for information on the softkeys.

Description of fields

Field	Option	Description
<Task:>	Choicelist	The type of line/arc COGO calculation.
<Method:>		The method by which the line will be defined.

Field	Option	Description
	3 Points	Uses three known points to define the arc.
	2 Points/Radius	Defines the arc using two known points and a radius of the arc.
	2 Tgnts/Radius	Defines the arc using two tangents and a radius of the arc.
	2 Tgnts/Arc Lngt	Defines the arc using two tangents and the length of the arc.
	2 Tgnts/Chrd Lngt	Defines the arc using two tangents and the chord of the arc.
<Start Point:>	Choicelist	The start point of the line.
<Second Point:>	Choicelist	The second point of the arc.
<End Point:>	Choicelist	The end point of the line. Available for <Method: 2 Points>.
<Point 1:>	Choicelist	A point on the first tangent. Available for <Method: 2 Tgnts/Radius>, <Method: 2 Tgnts/Arc Lngt> and <Method: 2 Tgnts/Chrd Lngt>.
<PI Point:>	Choicelist	The point of intersection of the two tangents. Available for <Method: 2 Tgnts/Radius>, <Method: 2 Tgnts/Arc Lngt> and <Method: 2 Tgnts/Chrd Lngt>.
<Point 2:>	Choicelist	A point on the second tangent. Available for <Method: 2 Tgnts/Radius>, <Method: 2 Tgnts/Arc Lngt> and <Method: 2 Tgnts/Chrd Lngt>.
<Azimuth:>	User input	The azimuth of the line. Available for <Method: Pt/Brg/Dist>.
<HDist-XX:>	User input	The horizontal distance from the start point to the end point of the line. Available for <Method: Pt/Brg/Dist>.
<Radius:>	User input	The radius of the arc. Available for <Method: 2 Points/Radius>.
<Arc Length:>	User input	The length of the arc. Available for <Method: 2 Tgnts/Arc Lngt>.
<Chord Length:>	User input	The length of the chord. Available for <Method: 2 Tgnts/Chrd Lngt>.
<Offset Point:>	Choicelist	The offset point. Available for <Task: Calc Base Point>.
<ΔLine-XX:>	User input	Horizontal distance from start point to base point. Available for <Task: Calc Offset Point>.

Field	Option	Description
<ΔArcDist-XX:>	User input	Horizontal distance along the arc from start point to base point. Available for <Task: Calc Offset Point>.
<Offset-XX:>	User input	Offset from base point to offset point. Positive to the right and negative to the left of the line. Available for <Task: Calc Offset Point>.
<ΔOffset-XX:>	User input	Offset from base point to offset point. Positive to the right and negative to the left of the arc. Available for <Task: Calc Offset Point>.

Next step

IF	THEN
<Task: Calc Arc Center>, <Task: Calc Base Point> or <Task: Calc Offset Point>	CALC (F1) calculates the result. Refer to paragraph "COGO XX Results, Result page".
<Task: Segmentation>	CALC (F1) accesses COGO Define Segmentation . Refer to paragraph "COGO Define Segmentation".

COGO XX Results, Result page

- The calculated coordinates are displayed.
- The softkeys are identical to those available for traverse COGO calculations. Refer to "2.5 COGO Calculation - Traverse Method" for information on the softkeys.

Description of fields

Field	Option	Description
<Point ID:>	User input	The identifier for the COGO point. The configured point ID template is used. The ID can be changed: <ul style="list-style-type: none"> • To start a new sequence of point ID's overtype the point ID. • For an individual point ID independent of the ID template SHIFT INDIV (F5). SHIFT RUN (F5) changes back to the next free ID from the configured ID template.
<Ortho Ht:> or <Local Ell Ht:>	User input	---- is displayed when entering the Result page. A height value to be stored with the calculated point can be typed in.
<Offset Point:>	Output	Point ID of offset point. Available for <Task: Calc Base Point>.

Field	Option	Description
<ΔLine-XX:>	Output	Horizontal distance from start point to base point. Available for <Task: Calc Base Point>.
<ΔArcDist-XX:>	Output	Horizontal distance along the arc from start point to base point. Available for <Task: Calc Base Point>.
<ΔOffset-XX:>	Output	Offset from base point to offset point. Positive to the right and negative to the left of the line. Available for <Task: Calc Base Point>.
<Line Length:>	Output	Length of line from start point to end point. Available for <Task: Calc Offset Point>.
<Line Brng:>	Output	Bearing of line from start point to end point. Available for <Task: Calc Offset Point>.
<Arc Radius:>	Output	Computed radius of arc. Available for <Task: Calc Arc Center> and <Task: Calc Offset Point>.
<Arc Length:>	Output	Computed length of arc. Available for <Task: Calc Arc Center> and <Task: Calc Offset Point>.
<Offs Pt Brng:>	Output	Bearing of offset point from base point to offset point. Available for <Task: Calc Offset Point>.

Next step

PAGE (F6) changes to the **Code** page.

**COGO
XX Results,
Code page**

The setting for <Thematc Codes:> in **CONFIGURE Coding & Linework** determines the availability of the fields and softkeys. They are identical to those of thematic coding with/without codelist. Refer to the TPS1200+ Technical Reference Manual for information on coding.

Next step

PAGE (F6) changes to the **Plot** page.

**COGO
Define
Segmentation**

Description of fields

Field	Option	Description
<Method:>	Delta Angle	How the line is to be divided. Refer to paragraph "Diagrams Line Calculation". To divide the arc by an angular value.
<Line Length:>	Output	Calculated line length between the selected <Start Point:> and <End Point:>.

Field	Option	Description
<Arc Length:>	Output	Computed length of arc.
<No. of Segs:>	User input or output	The number of segments for the line.
<Seg Length:>	User input or output	The calculated length of each segment or the required segment length.
<Last Seg Lgth:>	Output	Available for <Method: Segment Length>. The length of the remaining segment.
<Delta Angle:>	User input	The angular value by which new points will be defined on the arc.
<Start PtID:>	User input	The point ID to be assigned to the first new point on the line.
<PtID Inc:>	User input	<Start PtID:> is incremented numerically for the second, third, etc. point on the line.

Next step

CALC (F1) to access **COGO Segmentation Results**.

**COGO
Segmentation
Results**

The coordinates of the new points are calculated. The heights are computed along the line assuming a linear slope between <Start Point:> and <End Point:>.

Field	Option	Description
<Number of Segments:>	Output	Describes the number of resulting segments for the line including the remaining segment, if it applies.
<Last Segment Lgth:>	Output	Available for <Method: Segment Length>. The length of the remaining segment.

Next step




PAGE (F6) changes to the **Plot** page.

2.8 COGO Calculation - Shift, Rotate & Scale (Manual) Method

Description

The COGO calculation shift, rotate & scale (manual) applies shifts and/or rotation and/or scale to one or several known points. The values for shifts and/or rotation and/or scale are typed in manually.

Diagrams




Access

Refer to "2.2 Accessing COGO" to access **COGO Shift, Rotate & Scale**.

**COGO
Shift, Rotate &
Scale,
Points page**

Listed are points which have been selected for shifting, rotating and/or scaling.



CALC (F1)

To perform the shift, rotation and scale calculation and to continue with the subsequent screen. Calculated COGO points are not yet stored.

ADD (F2)

To add several points from the active job to the list. Selected sort and filter settings apply.

ADD 1 (F3)

To add one point from the active job to the list. Selected sort and filter settings apply.

REMOV (F4)

To remove the highlighted point from the list. The point itself is not deleted.

MORE (F5)

To display information about the codes if stored with any point, the time and the date of when the point was stored and the 3D coordinate quality and the class.

SHIFT REM A (F4)

To remove all points from the list. The points itself are not deleted.

SHIFT RANGE (F5)

To define a range of points from the active job to be added to the list.

Next step

PAGE (F1) accesses **COGO Shift, Rotate & Scale, Shift** page.

**COGO
Shift, Rotate &
Scale,
Shift page**

- The setting for **<Method:>** in this screen determines the availability of the subsequent fields.
- The softkeys are identical to those available for traverse COGO calculations. Refer to "2.5 COGO Calculation - Traverse Method" for information on the softkeys.

Description of fields

Field	Option	Description
<Method:>	Choicelist	The method by which the shift in Δ Easting, Δ Northing and Δ Height will be determined.
<From:>	Choicelist	Available for <Method: Use 2 Points> . The point ID of the first known point for calculating the shift.

Field	Option	Description
<To:>	Choicelist	Available for <Method: Use 2 Points>. The point ID of the second known point for calculating the shift.
<Azimuth:>	User input	Available for <Method: Enter Bng,Dst,Ht>. The azimuth defines the direction of the shift.
<HDist-XX:>	User input	Available for <Method: Enter Bng,Dst,Ht>. The amount of shift from the original point to the calculated COGO points.
<Δ Easting:>	User input or output	The amount of shift in East direction.
<Δ Northing:>	User input or output	The amount of shift in North direction.
<Δ Height:>	User input or output	The amount of shift in height.

Next step

PAGE (F6) accesses **COGO Shift, Rotate & Scale, Rotate** page.

COGO Shift, Rotate & Scale, Rotate page

- The softkeys are identical to those available for traverse COGO calculations.
- Refer to "2.5 COGO Calculation - Traverse Method" for information on the softkeys.

Description of fields

Field	Option	Description
<Method:>	Choicelist	The method by which the rotation angle will be determined.
<Rotation Pt:>	Choicelist	The point around which all points will be rotated.
<Existing Az:>	User input	Available for <Method: Computed>. A known direction before rotating.
<New Azimuth:>	User input	Available for <Method: Computed>. A known direction after rotating.
<Rotation:>	User input or output	The amount by which the points will be rotated.

Next step

PAGE (F6) accesses **COGO Shift, Rotate & Scale, Scale** page.

COGO
Shift, Rotate &
Scale,
Scale page

The softkeys are identical to those available for traverse COGO calculations.
Refer to "2.5 COGO Calculation - Traverse Method" for information on the softkeys.

Description of fields

Field	Option	Description
<Method:>	Choicelist	The method by which the scale factor will be determined.
<Existing Dist:>	User input	Available for <Method: Computed>. A known distance before scaling. This value is used for calculating the scale factor.
<New Dist:>	User input	Available for <Method: Computed>. A known distance after scaling. This value is used for calculating the scale factor.
<Scale:>	User input or output	The scale factor used in the calculation.
<Scale From Pt:>	No Yes	Scaling is performed by multiplying the original coordinates of the points by <Scale:>. <Scale:> is applied to the coordinate difference of all points relative to <Rotation Pt:> selected on the Rotation page. The coordinates of <Rotation Pt:> will not change.

Next step

CALC (F1) performs the shift, rotation and scale calculation and accesses **COGO Shift, Rotate & Scale Store**.

COGO
Shift, Rotate &
Scale Store,
General page

Description of fields

Field	Option	Description
<Pts Selected:>	Output	The number of selected points having been shifted, rotated and/or scaled.
<Store Job:>	Choicelist	The calculated COGO points will be stored in this job. The original points are not copied to this job.
<Add Identifier:>	Yes or No	Activates the use of additional identifiers for the point ID's of the calculated COGO points.
<Identifier:>	User input	The identifier with up to four characters is added in front of or at the end of the ID of the calculated COGO points.
<Prefix/Suffix:>	Prefix	Adds the setting for <Identifier:> in front of the original point ID's.

Field	Option	Description
	Suffix	Adds the setting for <Identifier:> at the end of the original point ID's.

Next step

STORE (F1) accesses **COGO Shift, Rotate & Scale Results, Result** page.

Description of fields

Field	Option	Description
<No. of New Pts:>	Output	Number of new points created.
<No. of Skipped Pts>	Output	Number of points which were skipped either due to not being able to convert coordinates or points with identical point ID's already existed in <Store Job:> .

Next step

CONT (F1) returns to **COGO Shift, Rotate & Scale**.

**COGO
Shift, Rotate &
Scale Results
Result page**

2.9 COGO Calculation - Shift, Rotate & Scale (Match Pts) Method

Description

The COGO calculation shift, rotate & scale (match pts) applies shifts and/or rotation and/or scale to one or several known points. The shifts and/or rotation and/or scale are calculated from selected points using a 2D Helmert transformation.

The number of pairs of points matched determines whether the shift, rotation and scale values are computed.

Access

Refer to "2.2 Accessing COGO" to access **COGO Match Common Points (n)**.

COGO Match Common Points (n)

This screen provides a list of points chosen from the active job. The points are used for the determination of the 2D Helmert transformation. Unless there is no pair of matching points in the list all softkeys are available.

Source Pt	Target Pt	Match
0001	100	P & H
0002	200	P & H

Q2 a

CALC NEW EDIT DEL MATCH RESID

CALC (F1)

To confirm the selections, compute the transformation and continue with the subsequent screen.

NEW (F2)

To match a new pair of points. This pair is added to the list. A new point can be manually occupied. Refer to paragraph "Match points step-by-step".

EDIT (F3)

To edit the highlighted pair of matched points.

DEL (F4)

To delete the highlighted pair of matched points from the list.

MATCH (F5)

To change the type of match for a highlighted pair of matched points.

RESID (F6)

To display a list of the matched points used in the transformation calculation and their associated residuals.

SHIFT PARAM (F5)

To define the parameters to be used in the 2D transformation. Refer to paragraph "Fix parameters".

Description of columns

Column	Description
Source Pt	The point ID of the points of origin for the calculation of the shifts and/or rotation and/or scale.
Target Pt	The point ID of the target points for the calculation of the shifts and/or rotation and/or scale.


Column	Description
Match	The type of match to be made between the points. This information is used in the transformation calculation. Position & Height, Position only, Height only or None . None removes matched common points from the transformation calculation but does not delete them from the list. This can be used to help improve residuals.

Next step

CALC (F1). The calculated shift, rotation and scale values are displayed in **COGO Shift, Rotate & Scale**. They cannot be edited. The remaining functionality of the calculation is very similar to COGO calculation shift, rotate & scale (manual). Refer to "2.8 COGO Calculation - Shift, Rotate & Scale (Manual) Method".

Match points step-by-step

Matching new points and editing matched points is very similar.

Step	Description
1.	Refer to "2.2 Accessing COGO" to access COGO Match Common Points .
2.	NEW (F2) or EDIT (F3)
3.	COGO Choose Matching Points or COGO Edit Matching Points <Source Pt:> A point of origin for the calculation of the shifts and/or rotation and/or scale. <Target Pt:> A target point for the calculation of the shifts and/or rotation and/or scale. <Match Type:> The type of match to be made between the points selected in <Source Pt:> and <Target Pt:> . Position & Height, Position Only, Height Only or None . Select the points to be matched.
	SURVY (F5) . To manually occupy a point and store it in the active job.
4.	CONT (F1) returns to COGO Match Common Points (n) and adds a new pair of matched points to the matched points list.

Fix parameters

The values for fixing the shifts, the rotation and the scale are displayed.


Next step

IF	AND	THEN
a field displays ----	the parameter needs to be fixed to a value	highlight the field. Enter the value of the parameter. FIX (F4) .
a field displays a value	the parameter needs to be calculated	highlight the field. ADJUST (F4) .
all parameters are configured	-	CONT (F1) to return to COGO Match Common Points (n) .

2.10 COGO Calculation - Area Division


Diagrams

Area division method	<Divide:>	<Using:>	<Shift:>
1.	By Defined Line	Parallel Line	By Distance
2.	By Percentage	Parallel Line	-
3.	By Area	Parallel Line	-




- P0 <Point A:> of defined line
- P1 <Point B:> of defined line
- P2 First new COGO point
- P3 Second new COGO point
- d <HDist-XX:>

Area division method	<Divide:>	<Using:>	<Shift:>
1.	By Defined Line	Perpendic Line	By Distance
2.	By Percentage	Perpendic Line	-
3.	By Area	Perpendic Line	-




- P0 <Point A:> of defined line
- P1 <Point B:> of defined line
- P2 First new COGO point
- P3 Second new COGO point
- d <HDist-XX:>

Area division method	<Divide:>	<Using:>	<Shift:>
1.	By Defined Line	Parallel Line	Through Point




- P0 <Point A:> of defined line
- P1 <Point B:> of defined line
- P2 <Through Point:>; in this case it is a known point of the existing border
- P3 New COGO point
- d <HDist-XX:>

Area division method	<Divide:>	<Using:>	<Shift:>
1.	By Defined Line	Perpetic Line	Through Point



- P0 <Point A:> of defined line
- P1 <Point B:> of defined line
- P2 <Through Point:>; in this case it is a known point of the existing border
- P3 New COGO point
- d <HDist-XX:>

Area division method	<Divide:>	<Using:>	<Shift:>
1.	By Percentage	Swing Line	-
2.	By Area	Swing Line	-



- P0 First new COGO point
- P1 Second new COGO point
- P2 <Rotation Pnt:>
- α <Azimuth:>

Access

Refer to "2.2 Accessing COGO" to access **COGO Choose Area to be Divided**.

COGO
Choose Area to be Divided


Description of fields

Field	Option	Description
<Area to Use:>	Select Existing	To use an area from the <Job:> selected in COGO COGO Begin . The area can be edited and a new area can be created from points existing in the <Job:>.
	Survey New Area	To survey points that do not exist in the job yet. The points will be added to a new area.
<Area ID:>	Choicelist or user input	To select the area to be divided or to enter a name for the new area.
<No. of Points:>	Output	Number of points forming the area.
<Area:>	Output	The size of the selected area.
<Perimeter:>	Output	The perimeter of the area.

Next step

IF	THEN
<Area to Use: Select Existing>	CONT (F1) accesses COGO Define How to Divide Area . Refer to paragraph "COGO Define How to Divide Area, Input page".
<Area to Use: Survey New Area>	CONT (F1) accesses COGO Survey: Job Name . Points to be added to the new area can be surveyed. COGO Survey: Job Name <ul style="list-style-type: none"> To stop surveying the area and to store the area: DONE (F4) and then STORE (F1). To return to COGO Choose Area to be Divided: ESC.

COGO
Define How to Divide Area, Input page



CALC (F1)

To perform the area division and to continue with the subsequent screen. Calculated COGO points are not yet stored.

INV (F2)

To calculate the value for the distance from two existing points. Available if <HDist-XX:> is highlighted.

SIZE (F3) and PERC (F3)

To display the size and the percentage of the sub-area.

LAST (F4)

To select the value for the distance from previous COGO inverse calculations. Available if **<HDist-XX:>** is highlighted.

SURVY (F5)

To manually occupy a point for the COGO calculation. Available if **<Point A:>**, **<Point B:>**, **<Rotation Pnt:>** or **<Through Point:>** is highlighted.

SHIFT CONF (F2)

To configure the COGO application program.

Description of fields

Field	Option	Description
<Divide By:>	Choicelist	This field defines how the size of the sub area is defined.
<Using:>	Parallel Line	The border will be parallel to a line defined by <Point A:> and <Point B:> .
	Perpendic Line	The border will be perpendicular to a line defined by <Point A:> and <Point B:> .
	Swing Line	The border will be a line rotated around <Rotation Pnt:> by <Azimuth:> .
<Sub-Area-XX:>	User input	For <Divide By: Percentage> and <Divide By: Area> . The size of the sub area must be typed either in % or in m ² . When dividing the area using a parallel or perpendicular line, a reference line is defined by <Point A:> and <Point B:> . The direction of the new dividing line is always the same as the direction of the reference line. The sub area is always to the left of the new dividing line. When dividing an area using a swing line, the direction of the new dividing line is defined by the <Rotation Pnt:> and the <Azimuth:> . The sub area is always to the left of the new dividing line.
	Output	For <Divide By: Defined Line> . The size of the sub area is calculated and displayed.
<Point A:>	Choicelist	The first point of the line which is used as the reference for a new parallel or perpendicular border.

Field	Option	Description
<Point B:>	Choicelist	The second point of the line which is used as the reference for a new parallel or perpendicular border.
<Shift:>	By Distance Through Point	Available for <Divide By: Defined Line>. The new border will run in a certain distance from the line defined by <Point A:> and <Point B:>. The new border will run through a point defined in <Through Point:>.
<Through Point:>	Choicelist	Available for <Shift: Through Point>. The point through which the new border will run.
<Rotation Pnt:>	Choicelist	Available for <Using: Swing Line>. The point around which the new border will rotate by <Azimuth:>.
<Azimuth:>	Output	Available for <Using: Swing Line>. The angle of the new border from <Rotation Pnt:> to the new COGO point.
<HDist-XX:>	User input or output	The distance from the line defined by <Point A:> and <Point B:> to the new border.

Next step

CALC (F1) performs the area division and accesses **COGO Results of Area Division**.

**COGO
Results of Area
Division,
Result page**

Description of fields



Field	Option	Description
<Area Ratio:>	Output	The ratio of the size of the two sub areas in percent.
<Area 1-XX:>	Output	The size of the first sub area in m ² .
<Area 2-XX:>	Output	The size of the second sub area in m ² .

Next step

CONT (F1) accesses **COGO Area Division Results**.

**COGO
Area Division
Results,
ResultX page**

The coordinates of the intersection points of the new border with the original area are displayed.



STORE (F1)

To store the two results and to return to **COGO Choose Area to be Divided** once both points are stored.

COORD (F2)

To view other coordinate types.

RSLT1 (F3) or RSLT2 (F3)

To view the first and second result.

STAKE (F5)

To access the Stakeout application program and stake out the calculated COGO point.

SHIFT INDIV (F5) and SHIFT RUN (F5)

To change between entering an individual point ID different to the defined ID template and the running point ID according to the ID template.

Next step

STORE (F1) stores the results and accesses **COGO Choose Area to be Divided**. For **<Write Logfile: Yes>** in **COGO Configuration, Logfile** page the result is written to the logfile.

3 Determine Coordinate System - General

3.1 Overview

Description

- GPS measured points are always stored based on the global geocentric datum known as WGS 1984. Using GPS measured points with the TPS1200+ requires coordinates in a local grid system, for example, based on a country's official mapping datum or an arbitrary grid system used in a particular area such as a construction site. To convert the WGS 1984 coordinates into local coordinates a coordinate system needs to be created. Part of the coordinate system is the transformation used to convert coordinates from the WGS 1984 datum to the local datum.
- The Determine Coordinate System application program allows:
 - the parameters of a new transformation to be determined.
 - the parameters of an existing transformation to be recomputed.

Requirements to determine a transformation

- To determine a transformation it is necessary to have common control points whose positions are known in both WGS 1984 coordinates and local coordinates. The more points that are common between datums the more accurately the transformation parameters can be calculated. Depending on the type of transformation used, details about the map projection, the local ellipsoid and a local geoidal model program may also be needed.

Requirements for control points

- The control points used for the transformation should surround the area for which the transformation is to be applied. It is not good practice to survey or convert coordinates outside of the area covered by the control points as extrapolation errors may be introduced.
- When a geoid field file and/or a CSCS field file is used in the determination of a coordinate system, the control points for the calculation must fall within the areas of the field files.



- With one common control point, it is still possible to calculate a Classic 3D transformation, as long as the rotations and the scale parameter are fixed. Such a transformation fits perfectly in the vicinity of the common control point, but is degraded by the distance from that point, because neither the orientation of the local reference frame nor any scale factor within the local datum can be taken into account.

Coordinate system determination methods

Two different methods for determining a coordinate system are available:

Coordinate system determination method	Characteristic	Description
Normal	Number of control points needed	One or more control points for both the WGS 1984 and the local datum.

Coordinate system determination method	Characteristic	Description
	Transformation to use	Onestep, Twostep or Classic 3D, depending on number of control points and available information.
One point localisation	Number of control points needed Transformation to use	One control point for both the WGS 1984 and the local datum. <ul style="list-style-type: none"> • Onestep or Twostep when information about the necessary rotations and scale factor is known. • Classic 3D when the rotations are to be set to zero and the scale factor to one.

3.2 Configuring Det Coord System

3.2.1 Configuring Det Coord System - Normal

Description


The configuration of **DET C SYS**, normal method, allows options to be set which are used as the default options within the Determine Coordinate System application program when using the normal method. These settings are stored within the active configuration set.

Access step-by-step

Step	Description
1.	PROG . The PROG key opens the TPS1200+/TS30/TM30 Programs menu.
2.	Select Determine Coordinate System and press CONT (F1) .
3.	Press CONF (F2) to access DET C SYS Configuration . Select <Default Method: Normal> .

DET C SYS Configuration, Method page

The explanations for the softkeys given below are valid for all pages, unless otherwise stated.



CONT (F1)

To accept changes and return to the screen from where this screen was accessed.

FIX (F4) or ADJUST (F4)

Available for **Classic 3D** page unless **<Transf Model:>** is highlighted. To define which parameters are computed or fixed in the Classic 3D transformation.

Description of fields

Field	Option	Description
<Default Method:>	Normal or One Pt Localistn	Method used to determine the coordinate system.
<Default Transformation:>	Onestep , Twostep or Classic 3D	The default transformation to be used when determining the coordinate system.
<Default Height Mode:>	Orthometric or Ellipsoidal	The default height type to be used when determining the coordinate system.
<Default Match:>	Pos & Height , Pos Only , Height Only or <None>	Options available depend on the choice made for <Default Transformation:> . Point parameters to be matched between points in both datums.

Next step

PAGE (F6) changes to the **Residuals** page.

DET C SYS
Configuration,
Residuals page

Description of fields

Field	Option	Description
<Easting:>	User input	The limit above which Easting residuals will be flagged as possible outliers.
<Northing:>	User input	The limit above which Northing residuals will be flagged as possible outliers.
<Height:>	User input	The limit above which Height residuals will be flagged as possible outliers.
<Default Residual Distbtn:>	None, 1/Distance ^{XX} or Multiquadratic	The method by which the residuals of the control points will be distributed throughout the transformation area.

Next step

PAGE (F6) changes to the **Classic 3D** page.

DET C SYS
Configuration,
Classic 3D page

The settings on this page define the parameters to be used in a Classic 3D transformation.

IF the value for a field is	THEN the value for this parameter will be
-----	calculated.
any number	fixed to that value.

Next step

CONT (F1) returns to **DET C SYS Determine Coord System Begin**.

3.2.2 Configuring Det Coord System - One Point Localisation

Access
step-by-step

Step	Description
1.	PROG. The PROG key opens the TPS1200+/TS30/TM30 Programs menu.
2.	Select Determine Coordinate System and press CONT (F1) .
3.	Press CONF (F2) to access DET C SYS Configuration . Select <Default Method: One Pt Localistn> .

**DET C SYS
Configuration,
Method page**

The softkeys are identical to those available for **<Default Method: Normal>**. Refer to "3.2.1 Configuring Det Coord System - Normal" for information on softkeys.

Description of fields

Field	Option	Description
<Default Method:>	Normal or One Pt Localistn	Method used to determine the coordinate system.
<Default Transformation:>	Onestep, Twostep or Classic 3D	The default transformation to be used when determining the coordinate system.
<Default Height Mode:>	Orthometric or Ellipsoidal	The default height mode to be used when determining the coordinate system.

Next step

PAGE (F6) changes to the **Onestep** page.

**DET C SYS
Configuration,
Onestep page**

Description of fields

Field	Option	Description
<Default Rotation:>	Use WGS84 North	Rotate to North as defined by WGS 1984.
	User Entered	Rotation can be manually typed in.
	Convergence Angle	Angle between grid North and geodetic North at a certain point.
	Two WGS84 Points	Rotation defined by two points on the WGS 1984 datum.
<Default Height SF:>	User Entered	Height scale factor can be manually typed in.
	Known WGS84 Pt	Height scale factor defined by a known point on the WGS 1984 datum.
	Known WGS84 Ht	Height scale factor defined by the known height of a point on the WGS 1984 datum.

Next step

PAGE (F6) changes to the **Twostep** page.

**DET C SYS
Configuration,
Twostep page**

Some fields are identical to those on the **Onestep** page. Additional fields are explained here.

Description of fields

Field	Option	Description
<Default Scale:>	User Entered	Scale factor can be manually typed in
	Compute CSF	Compute the combined grid and height scale factor.
<Deflt Grid SF:>	User Entered or Known Local Pt	Available for <Default Scale: Compute CFS >. Default method for computing the grid scale factor of the known point.

Next step

PAGE (F6) changes to the **Classic 3D** page.

**DET C SYS
Configuration,
Classic 3D page**

Description of fields

Field	Option	Description
<Default Local Height:>	Use WGS84 Pt Ht or Use Local Pt Ht	Source of height information to use.

Next step

CONT (F1) returns to **DET C SYS Determine Coord System Begin**.

4 Determine Coordinate System - Normal

4.1 Determining a New/Updating a Coordinate System

Access
step-by-step

Step	Description
1.	PROG. The PROG key opens the TPS1200+/TS30/TM30 Programs menu.
2.	Select Determine Coordinate System and press CONT (F1) .
3.	Press CONF (F2) to access DET C SYS Configuration . Select <Default Method: Normal> .



If a coordinate system was chosen to be edited in **DET C SYS Determine Coord System Begin**, pressing **CONT (F1)** accesses **DET C SYS Step 3: Match Points (n)**.

DET C SYS
Step 1: Choose
Transform Type

Description of fields

Field	Option	Description
<Transfrm Name:>	User input	A unique name for the transformation. If a coordinate system is being updated then its name is displayed.
<Transfrm Type:>	Onestep, Twostep or Classic 3D Output	Available when determining a new coordinate system. Available when updating a coordinate system. The transformation type shown is the same as the transformation used in the existing system.
<Height Mode:>	Orthometric or Ellipsoidal Output	Available when determining a new coordinate system. Available when updating a coordinate system. The height mode shown is the same as the mode used in the existing system.

Next step

CONT (F1) continues to **DET C SYS Step 2: Choose Parameters**.

DET C SYS
Step 2: Choose
Parameters

This screen contains different fields, depending on what transformation type was chosen in **DET C SYS Step 1: Choose Transform Type**.

Description of fields

Field	Option	Description
<Geoid Model:>	Choicelist	The geoid model to be used in the transformation. Geoid models from MANAGE Geoid Models can be selected.
<Pre Transform:>	Choicelist	The pre-transformation to use for the preliminary 3D transformation.
<Ellipsoid:>	Choicelist Output	The ellipsoid to use in the transformation. The ellipsoid being used by a hard wired projection when selected in <Projection:>.
<Projection:>	Choicelist	The projection to use in the transformation.
<CSCS Model:>	Choicelist	The CSCS model to use in the transformation. All CSCS models from MANAGE CSCS Models can be selected.

Next step

CONT (F1) continues to **DET C SYS Step 3: Match Points (n)**.

DET C SYS
Step 3: Match
Points (n)

This screen provides a list of points chosen from <WGS84 Pts Job:> and <Local Pts Job:>. The number of control points matched between both jobs is indicated in the title, for example **DET C SYS Step 3: Match Points (4)**. Unless there is no pair of matching points in the list all softkeys are available.

The screenshot shows a handheld device screen with the following content:

- Top status bar: 08:10, DET C SYS, and various system icons.
- Title bar: Step 3: Match Points (4)
- Main table:

WGS84 Pts	Local Pts	Match
101	101	P & H
200	200	P & H
300	300	P & H
400	400	P & H
- Bottom softkey bar: CALC, NEW, EDIT, DEL, MATCH, Q2 a ↑, AUTO.

CALC (F1)

To confirm the selections, compute the transformation and continue with the subsequent screen.

NEW (F2)

To match a new pair of points. This pair is added to the list. A new point can be measured.

EDIT (F3)

To edit the highlighted pair of matched points.

DEL (F4)

To delete the highlighted pair of matched points from the list.

MATCH (F5)

To change the type of match for a highlighted pair of matched points.

AUTO (F6)

To scan both jobs for points that have the same point ID. Points with matching point ID's are added to the list.

SHIFT PARAM (F5)

To configure Classic 3D transformation parameters for <Transform Type: Classic 3D> or 2D & Height transformation parameters for <Transform Type: Onestep> and <Transform Type: Twostep> in **DET C SYS Step 1: Choose Transform Type**.

Description of columns

Column	Description
WGS84 Pts	The point ID of the points chosen from <WGS84 Pts Job:>.
Local Pts	The point ID of the points chosen from <Local Pts Job:>.
Match	<p>The type of match to be made between the points. This information is used in the transformation calculation. Position & Height, Position only, Height only or None.</p> <ul style="list-style-type: none">For <Transform Type: Onestep> or <Transform Type: Twostep> possible options are P & H, P only, H only or None.For <Transform Type: Classic 3D> possible options are P & H or None. <p>None removes matched common points from the transformation calculation but does not delete them from the list. This can be used to try and improve the residuals that are obtained when calculating the transformation.</p>

Next step

CALC (F1) computes the transformation and continues to **DET C SYS Step 4: Check Residuals**.

DET C SYS Step 4: Check Residuals

Displays a list of the matched points used in the transformation calculation and their associated residuals.

Step 4: Check Residuals		
WGS84 Pts	East [m]	North [m]
101	0.009!	0.004
200	0.000	0.003
300	-0.002	-0.004
400	-0.008	-0.004!

CONT	RESLT	MORE	Q2 a ↑
------	-------	------	--------

CONT (F1)

To accept the residuals and to continue with the subsequent screen.

RESLT (F3)

To view results of the transformation.

MORE (F5)

To display information about height residuals.

Description of columns

Column	Description
WGS84 Pts	The point ID of the points chosen from <WGS84 Pts Job:>.
East, North and Height	The Easting, Northing and Height residuals. If positions or heights were not used in the transformation calculation then ----- will be displayed.
!	Indicates residuals that exceed the residual limit defined in DET C SYS Configuration, Residuals page.
!	Indicates the largest residual in East, North and Height .

Next step

IF the residuals are	THEN
unacceptable	ESC returns to DET C SYS Step 3: Match Points (n) . Matched points can be edited, deleted or temporarily removed from the list and the transformation recalculated.
acceptable	CONT (F1) continues to DET C SYS Step 5: Store Coord System .

DET C SYS Step 5: Store Coord System, Summary page

Description of fields

Field	Option	Description
<Name:>	User input	The name of the coordinate system can be changed.
<Transfrm Type:>	Output	The type of transformation used, as defined in DET C SYS Step 1: Choose Transform Type .
<Matched Pts:>	Output	Number of matched points, as defined in DET C SYS Step 3: Match Points (n) .
<Easting:>, <Northing:> and <Height:>	Output	Largest Easting residual from the transformation calculation.

Next step

PAGE (F6) changes to the **Coord System** page.

DET C SYS
Step 5: Store Coord
System,
Coord System
page

Description of fields common to all transformations

Field	Option	Description
<Residuals:>	None, 1/Distance ^{XX} or Multiquadratic	The method by which the residuals of the control points will be distributed throughout the transformation area.

Refer to paragraph "DET C SYS Step 2: Choose Parameters" for details of all other fields.

Next step

STORE (F1) stores the coordinate system to the DB-X and attaches it to the <WGS84 Pts Job:> selected in **DET C SYS Determine Coord System Begin**, replacing any coordinate system attached to this job. <WGS84 Pts Job:> becomes the active job.

4.2 Selecting/Editing a New Pair of Matching Points

Access
step-by-step

Step	Description
1.	Refer to "4.1 Determining a New/Updating a Coordinate System". Follow the instructions to access DET C SYS Step 3: Match Points (n) .
2.	Press NEW (F2)/EDIT (F3) to access DET C SYS Choose Matching Points/DET C SYS Edit Matching Points .



Editing a pair of matched points is similar to creating a new pair of matching points. For simplicity, the screen is called **DET C SYS XX Matching Points** and differences are clearly outlined.

DET C SYS
XX Matching Points



WGS84 Point : [redacted] w101
Known Point : L101
Match Type : Pos & Height

CONT (F1)

To accept the matching points and to continue with the subsequent screen.

SURVY (F5)

To measure a point and store it in the local job.



Description of fields

Field	Option	Description
<WGS84 Point:>	Choicelist	A WGS 1984 control point. All WGS 1984 stored points from MANAGE Data: Job Name can be selected.
<Known Point:>	Choicelist	A local control point. All local stored points from MANAGE Data: Job Name of any class, except NONE , can be selected.
<Match Type:>	Pos & Height, Position Only, Height Only or None	The type of match to be made between the points selected in <WGS84 Point:> and <Known Point:>. The options available depend on <Transfrm Type:> in DET C SYS Step 1: Choose Transform Type .

Next step

CONT (F1) returns to **DET C SYS Step 3: Match Points (n)** and adds a new line of matched points to the matched points list.

4.3 Transformation Results

Access
step-by-step

Step	Description
1.	Refer to "4.1 Determining a New/Updating a Coordinate System". Follow the instructions to access DET C SYS Step 4: Check Residuals .
2.	Press RESLT (F3) to access DET C SYS Transformation Results .

DET C SYS
Transformation
Results,
Position page;
DET C SYS
Transformation
Results,
Parameters page

Position	Height
Shift dX :	249519.0014 m
Shift dY :	758220.2394 m
Rotation :	-5511.36979 °
Scale :	34.6421 ppm
Rot Orig X :	3.6845 m
Rot Orig Y :	5.8791 m

CONT SCALE RMS PAGE

CONT (F1)

To return to **DET C SYS Step 4: Check Residuals**.

SCALE (F4) or PPM (F4)

Available on the **Position** page. To switch between **<Scale:>** displaying the true scale and displaying the ppm.

RMS (F5) or PARAM (F5)

To switch between the root mean square values of the parameters and the actual parameter values. The name of the screen changes to **DET C SYS Transformation Results rms** when displaying rms values.

Description of fields

Field	Option	Description
<Shift dX:>	Output	Shift in X direction.
<Shift dY:>	Output	Shift in Y direction.
<Rotation:>	Output	Rotation of transformation.
<Rotations X:> , <Rotations Y:> or <Rotation Z:>	Output	Rotation around the X, Y or Z axis.
<Scale:>	Output	Scale factor used in transformation. Either true scale or ppm.
<Rot Orig X:>	Output	Position in the X direction of the origin of rotation.
<Rot Orig Y:>	Output	Position in the Y direction of the origin of rotation.

Next step

IF	THEN
<Transfrm Type: Onestep> or <Transfrm Type: Twostep>	PAGE (F6) changes to the Height page.
<Transfrm Type: Classic 3D>	PAGE (F6) changes to the Rotn Origin page.

**DET C SYS
Transformation
Results,
Height page**

Description of fields

Field	Option	Description
<Slope in X:>	Output	Tilt of the transformation in the X direction.
<Slope in Y:>	Output	Tilt of the transformation in the Y direction.
<Height Shift:>	Output	Shift in height between WGS 1984 datum and local datum.

Next step

CONT (F1) returns to **DET C SYS Step 4: Check Residuals.**

**DET C SYS
Transformation
Results,
Rotn Origin page**

Description of fields

Field	Option	Description
<Transf Model:>	Output	Classic 3D transformation model used for the transformation as defined in DET C SYS Configuration, Classic 3D page.
<Rot Orig X:>, <Rot Orig Y:> and <Rot Orig Z:>	Output	Available for <Transf Model: Molodensky-Bad >. Position in the X, Y and Z direction of the origin of rotation.

Next step

CONT (F1) returns to **DET C SYS Step 4: Check Residuals.**

5 Determine Coordinate System - One Point Localisation

5.1 Accessing Det Coord System - One Point Localisation



<Azimuth:> is used throughout this chapter. This should always be considered to also mean <Bearing:>.

Access
step-by-step

Step	Description
1.	PROG. The PROG key opens the TPS1200+/TS30/TM30 Programs menu.
2.	Select Determine Coordinate System and press CONT (F1) .
3.	Press CONF (F2) to access DET C SYS Configuration . Select <Default Method: One Pt Localistn>.
4.	Press CONT (F1) to access DET C SYS Step 1: Choose Transform Type .

DET C SYS
Step 1: Choose
Transform Type

Description of fields

Field	Option	Description
<Transfrm Name:>	User input	A unique name for the coordinate system. The name may be up to 16 characters in length and may include spaces.
<Transfrm Type:>	Onestep, Twostep or Classic 3D	The type of transformation to be used when determining a coordinate system.
<Height Mode:>	Orthometric or Ellipsoidal	The height mode to be used in the determination of a coordinate system

Next step

IF	THEN
<Transfrm Type: Onestep > or <Transfrm Type: Twostep >	CONT (F1) to access DET C SYS Step 2: Choose Parameters . Refer to "5.2 Det Coord System - Onestep/Twostep Transformation".
<Transfrm Type: Classic 3D >	CONT (F1) to access DET C SYS Step 2: Choose Parameters . Refer to "5.3 Det Coord System - Classic 3D Transformation".

5.2 Det Coord System - Onestep/TwoStep Transformation

5.2.1 Determining a New/Coordinate System

Access

Refer to "5.1 Accessing Det Coord System - One Point Localisation" to access **DET C SYS Step 2: Choose Parameters**.

DET C SYS Step 2: Choose Parameters

Description of fields

Field	Option	Description
<Pre Transform:>	Chocelist	Available for <Transfrm Type: Twostep>. The pretransformation to be used for the preliminary 3D transformation.
<Ellipsoid:>	Chocelist	Available for <Transfrm Type: Twostep>. The ellipsoid to be used in the transformation.
	Output	The ellipsoid being used by a hard wired projection when selected in <Projection:>.
<Projection:>	Chocelist	Available for <Transfrm Type: Twostep>. The projection to be used in the transformation.
<Geoid Model:>	Chocelist	The geoid model to be used in the transformation.

Next step

CONT (F1) continues to **DET C SYS Step 3: Choose Common Point**.

DET C SYS Step 3: Choose Common Point

CONT (F1)

To confirm the selections and to continue with the subsequent screen.

SURVY (F5)

To measure a point and store it in <Local Pts Job:>.

Description of fields

Field	Option	Description
<Match Type:>	Pos & Height	Position and height are taken from the same pair of matching points.
	Pos Only	Position is taken from one pair of matching points. The height can be taken from another pair of matching points.


Field	Option	Description
<WGS84 Point:>	Choicelist	The point ID of the control point chosen from <WGS84 Pts Job:>.
<Known Point:>	Choicelist	The point ID of the control point chosen from <Local Pts Job:>.
<Match Height:>	Yes or No	Available for <Match Type: Pos Only>. Activates the determination of the vertical shift from a separate pair of matching points.

Next step

CONT (F1) continues to **DET C SYS Step 4: Determine Rotation**.

DET C SYS Step 4: Determine Rotation

This screen contains different fields, depending on the <Method:> selected. The explanations for the softkeys given below are valid as indicated.



CONT (F1)

To confirm the selections and to continue with the subsequent screen.

INV (F2)

Available for <Method: Two WGS84 Points> and <Method: User Entered>. To compute an azimuth between two local points.

SURVY (F5)

To manually occupy a point and store it in <WGS84 Pts Job:>. Available when certain fields are highlighted.

Description of common fields

Field	Option	Description
<Method:>	Use WGS84 North, User Entered, Convergence Angle or Two WGS84 Points	Method by which the rotation angle for the transformation is determined.

For <Method: Use WGS84 North>

Description of fields

Field	Option	Description
<Rotation:>	Output	Transformation will be rotated to North as defined by the WGS 1984 datum. North is 0.00000°.

For <Method: User Entered>

Description of fields

Field	Option	Description
<Rotation:>	User input	Allows the orientation of the transformation to be manually typed in or calculated in DET C SYS Compute Required Azimuth .

For <Method: Convergence Angle>

Description of fields

Field	Option	Description
<Coord System:>	Choicelist	Coordinate system to provide the direction of grid North in the area where the control point used for determining the local coordinate system, is located.
<WGS84 Point:>	Choicelist	WGS 1984 point of which the convergence angle will be calculated.
<Rotation:>	Output	The rotation of the transformation calculated as 0.00000° minus the computed convergence angle. The field is updated as <Coord System:> and <WGS84 Point:> are changed.

For <Method: Two WGS84 Points>

Description of fields

Field	Option	Description
<Point 1:>	Choicelist	First point to use for computation of <Azimuth:> .
<Point 2:>	Choicelist	Second point to use for computation of <Azimuth:> .
<Azimuth:>	Output	Computed azimuth between <Point 1:> and <Point 2:> .
<Reqd Azimuth:>	User input	The required grid azimuth, computed between two local points.
<Rotation:>	Output	The rotation of the transformation calculated as <Reqd Azimuth> minus <Azimuth> . The field is updated as <Point 1:> , <Point 2:> and <Reqd Azimuth:> are changed.

Next step

CONT (F1) continues to **DET C SYS Step 5: Determine Scale**.

DET C SYS

Step 5: Determine Scale

This screen contains different fields, depending on the **<Method:>** selected. The explanations for the softkeys given below are valid as indicated. The scale is calculated using the formula $(r + h)/r$ where r is the distance from the centre of the ellipsoid to the WGS 1984 point selected in **DET C SYS Step 3: Choose Common Point** and h is the height of this point above the WGS 1984 ellipsoid for **<Transfrm Type: Onestep>** or the local ellipsoid for **<Transfrm Type: Twostep>**.

09:49
DET C SYS
Step 5: Determine Scale
Method : Known WGS84 Pt
WGS84 Point : 101
Scale : 0.9999257
(Reduced to Ellipsoid)
CONT PPH Q2 a 0

CONT (F1)

To confirm the selections and to continue with the subsequent screen.

GRID (F2)

To compute the grid scale factor. Available for **<Transfrm Type: Twostep>** where **<Method: Compute CSF>**.

HIGHT (F3)

To compute the height scale factor. Available for **<Method: Compute CSF>**.

SCALE (F4) or PPM (F4)

To switch between **<Scale:>** displaying the true scale and displaying the ppm.

SURVY (F5)

To measured a point and store it in **<Local Pts Job:>**.

For <Transfrm Type: Onestep>

Description of common fields

Field	Option	Description
<Method:>	User Entered, Known WGS84 Pt or Known WGS84 Ht	Method of determining the scale factor of the transformation.

For <Transfrm Type: Onestep> and <Method: User Entered>

Description of fields

Field	Option	Description
<Scale:>	User input	Allows the scale factor to be typed in manually.

For <Transfrm Type: Onestep> and <Method: Known WGS84 Pt>

Description of fields

Field	Option	Description
<WGS84 Point:>	Choicelist	WGS 1984 point from which the scale factor will be calculated. The scale factor is calculated using the height of the known WGS 1984 point.
<Scale:>	Output	The calculated scale factor.

For <Transfrm Type: Onestep> and <Method: Known WGS84 Ht>

Description of fields

Field	Option	Description
<Known Height:>	User input	The WGS 1984 height of a point can be typed in. The scale factor is calculated using this height.
<Scale:>	Output	The calculated scale factor.

For <Transfrm Type: Twostep>

Description of fields

Field	Option	Description
<Method:>	User Entered or Compute CSF	The default method for determining the Combined Scale Factor to be used in the transformation process.
<Grid SF:>	Output	Available for <Method: Compute CSF>. The grid scale factor as computed in DET C SYS Compute Grid Scale Factor.
<Height SF:>	Output	Available for <Method: Compute CSF>. The height scale factor as computed in DET C SYS Compute Height Scale Factor.
<Combined SF:>	User input	Available for <Method: User Entered>. The scale factor can be typed in.
	Output	Available for <Method: Compute CSF>. The product of the grid scale factor and the height scale factor.

Next step

CONT (F1) continues to DET C SYS Step 6: Store Coord System.

DET C SYS

Step 6: Store Coord System

The shifts in X and Y direction, the rotation, the scale factor of the transformation and the position of the origin of rotation is displayed.

09:51	+	IR	I	+	+	+	+	+	+
DET C SYS									
Step 6: Store Coord System									
Name	:	dfas							
Shift dX	:	253215.9352	m						
Shift dY	:	764436.0446	m						
Rotation	:	0.00000	"						
Scale	:	-74.3342	ppm						
Rot Orig X	:	0.0000	m						
Rot Orig Y	:	0.0000	m						
Q2 a ↑									
STORE				SCALE					

STORE (F1)

To store the coordinate system to the DB-X, attach the system to **<WGS84 Pts Job:>** that was selected in **DET C SYS Determine Coord System**

Begin and return to

TPS1200+/TS30/TM30 Main Menu.

SCALE (F4) or PPM (F4)

To switch between **<Scale:>** displaying the true scale and displaying the ppm.

Next step

STORE (F1) stores the coordinate system and returns to **TPS1200+/TS30/TM30 Main Menu.**

5.2.2 Computing the Grid Scale Factor for Twostep Transformation

Access step-by-step

Step	Description
1.	Refer to "5.1 Accessing Det Coord System - One Point Localisation" to access DET C SYS Step 1: Choose Transform Type .
2.	Select <Transfrm Type: Twostep> .
3.	Continue to DET C SYS Step 5: Determine Scale .
4.	Select <Method: Compute CSF> .
5.	Press GRID (F2) to access DET C SYS Compute Grid Scale Factor .

DET C SYS Compute Grid Scale Factor

Description of fields

Field	Option	Description
<Method:>	User Entered	Grid scale factor can be manually typed in.
	Known Local Pt	Grid scale factor is computed using the position of a known local point.
<Local Point:>	Choicelist	Available for <Method: Known Local Pt> . The point ID of the point chosen from <Local Pts Job:> from which the grid scale factor is computed using the projection selected in DET C SYS Step 2: Choose Parameters .
<Grid SF:>	User input	Available for <Method: User Entered> . To type in the grid scale factor.
	Output	Available for <Method: Known Local Pt> . The computed grid scale factor.

Next step

CONT (F1) returns to **DET C SYS Step 5: Determine Scale**.

5.2.3 Computing the Height Scale Factor for Twostep Transformation

Access step-by-step

Step	Description
1.	Refer to "5.1 Accessing Det Coord System - One Point Localisation" to access DET C SYS Step 1: Choose Transform Type .
2.	Select <Transform Type: Twostep> .
3.	Continue to DET C SYS Step 5: Determine Scale .
4.	Select <Method: Compute CSF> .
5.	Press HIGHT (F3) to access DET C SYS Compute Height Scale Factor .

DET C SYS Compute Height Scale Factor

Description of fields

Field	Option	Description
<Method:>	User Entered	Height scale factor can be manually typed in.
	Known Local Pt	Height scale factor is computed using the height of a known local point.
	Known Local Ht	Height scale factor is computed using the known height of a local point.
<Known Point:>	Choicelist	Available for <Method: Known Local Pt> . The point ID of the point chosen from <Local Pts Job:> from which the height scale factor is computed.
<Known Height:>	User input	Available for <Method: Known Local Ht> . A known local height.
<Height SF:>	User input	Available for <Method: User Entered> . To type in the height scale factor.
	Output	Available for <Method: Known Local Pt> and <Method: Known Local Ht> . The computed height scale factor.

Next step

CONT (F1) returns to **DET C SYS Step 5: Determine Scale**.

5.3 Det Coord System - Classic 3D Transformation

Access

Refer to "5.1 Accessing Det Coord System - One Point Localisation" to access **DET C SYS Step 1: Choose Transform Type**.

DET C SYS Step 2: Choose Parameters

Description of fields

Refer to "5.2 Det Coord System - Onestep/Twostep Transformation" paragraph "DET C SYS Step 2: Choose Parameters" for information about the fields available.

Next step

CONT (F1) continues to **DET C SYS Step 3: Choose Common Point**.

DET C SYS Step 3: Choose Common Point



WGS84 Point :
 Known Point :

Local Height :

CONT (F1)

To confirm the selections and to continue with the subsequent screen.

SURVY (F5)

To measure a point and store it in **<Local Pts Job:>**.



Description of fields

Field	Option	Description
<WGS84 Point:>	Choicelist	The point ID of the control point chosen from <WGS84 Pts Job:> .
<Known Point:>	Choicelist	The point ID of the control point chosen from <Local Pts Job:> .
<Local Height:>	Use WGS84 Pt Ht or Use Local Pt Ht	The source of the height information to use in the transformation.

Next step

CONT (F1) continues to **DET C SYS Step 4: Store Coord System**.

DET C SYS Step 4: Store Coord System

The shifts in the X, Y and Z directions are displayed.

Next step

STORE (F1) stores the coordinate system and returns to **TPS1200+/TS30/TM30 Main Menu**.

5.4 Computing Required Azimuth



Available for <Method: Two WGS84 Points> and <Method: User Entered> in **DET C SYS Step 4: Determine Rotation**.

Description

Allows two local points to be chosen from <Local Pts Job:> selected in **DET C SYS Determine Coord System Begin** between which the required azimuth will be computed. This azimuth is then used with an azimuth computed between two WGS 1984 points chosen from <WGS84 Pts Job:> selected in **DET C SYS Determine Coord System Begin**, to calculate the rotation of the transformation. The computed required azimuth appears in the <Reqd Azimuth:> field for <Method: Two WGS84 Points> and the <Rotation:> field for <Method: User Entered> in **DET C SYS Step 4: Determine Rotation**.

Access step-by-step

Step	Description
1.	Refer to "5.1 Accessing Det Coord System - One Point Localisation" to access DET C SYS Step 1: Choose Transform Type .
2.	Select <Transform Type: Onestep> or <Transform Type: Twostep>.
3.	Continue to DET C SYS Step 4: Determine Rotation .
4.	Select <Method: Two WGS84 Points> or <Method: User Entered>.
5.	Press INV (F2) to access DET C SYS Compute Required Azimuth .

DET C SYS Compute Required Azimuth

Description of fields

Field	Option	Description
<From:>	Choicelist	The point ID of the first known point for the azimuth calculation.
<To:>	Choicelist	The point ID of the second known point for the azimuth calculation.

Next step

CONT (F1) to calculate the required azimuth and return to **DET C SYS Step 4: Determine Rotation**.

6 GPS Survey

6.1 Overview

Description GPS Survey is an application program which is used with SmartStation. The main purpose of this application program is to enable measurement of points in GPS mode without having to run through the Setup application program.

Access Select **Main Menu: Programs...GPS Survey**.

Point properties The properties of GPS Survey points are:

Type	Property	Property
Class	MEAS	NAV
Sub class	GPS Fixed, GPS Code only	GPS Code only
Source	GPS Survey	GPS Survey
Instrument source	GPS	GPS

GPS SURVEY GPS Survey Begin

12:13
GPS SURVEY
GPS Survey Begin

Job : construction

Coord System : <None>

Codelist : <None>

Config Set : TCRP SmartStn

Antenna : ATX1230 SmartStn

CONT CSYS

CONT (F1)

To accept changes and access the subsequent screen. The chosen settings become active.

CSYS (F6)

To select a different coordinate system.

Description of fields

Field	Option	Description
<Job:>	Choicelist	The active job. All jobs from Main Menu: Manage...Jobs can be selected.
<Coord System:>	Output	The coordinate system currently attached to the selected <Job:>.
<Codelist:>	Choicelist	No codes are stored in the selected <Job:>. All codelists from Main Menu: Manage...Codelists can be selected.

Field	Option	Description
	Output	Codes have already been stored in the selected <Job:>. If codes had been copied from a System RAM codelist, then the name of the codelist is displayed. If codes have not been copied from a System RAM codelist but typed in manually, then the name of the active job is displayed.
<Config Set:>	Choicelist	The active configuration set. All configuration sets from Main Menu: Manage... \Configuration Sets can be selected.
<Antenna:>	Choicelist	Opening the choicelist accesses MANAGE Antennas . The default antenna is SmartAntenna.

Next step

CONT (F1) accepts the changes and accesses **GPS SURVEY GPS Survey**.


**GPS SURVEY
GPS Survey,
Survey page**

Overview

Important features about this screen:

- Upon entering this screen SmartStation switches into GPS mode.
- The display mask for this screen is fixed and is not configurable.
- SmartAntenna is automatically turned on upon entry to the screen.
- Some of the screen icons change from TPS specific to GPS specific.
- The GPS real-time radio link is automatically activated, if configured.
- The occupation/storing behaviour is dependent on the configuration settings.

Diagram



Refer to "Description of softkeys" for details on the softkeys and their functionality.



Description of softkeys

Key	Description
OCCUPY (F1)	To start logging of static observations. The position mode icon changes to the static icon. (F1) changes to STOP .

Key	Description
STOP (F1)	To end logging of static observations when enough data is collected. When <Auto STOP: Yes> in CONFIGURE Point Occupation Settings , logging of static observations ends automatically as defined by the stop criteria. The position mode icon changes to the moving icon. (F1) changes to STORE .
STORE (F1)	To store the measured point. When <Auto STORE: Yes> in CONFIGURE Point Occupation Settings , the measured point is stored automatically. (F1) changes to OCUPY . It may happen that a point with the same point ID exists in the job. If the codes and/or attribute values of the new and the existing point do not match, a screen opens where they can be corrected.
SHIFT AVGE (F2)	To check the residuals for the averaged position. Available for <Averaging Mode: Average> and for more than one measured coordinate triplet recorded for the same point.
SHIFT ABS (F2)	To check the absolute difference between measurements. Available for <Averaging Mode: Absolute Diffs> and for more than one measured coordinate triplet recorded for the same point.
SHIFT CONEC (F3) and SHIFT DISCO (F3)	To dial the number of the reference station configured in the active configuration set and to hang up immediately after the survey is completed. Available for GPS real-time devices of type digital cellular phone or modem. Available for <Auto CONEC: No> in CONFIGURE GSM Connection .
SHIFT INIT (F4)	To select an initialisation method and to force a new initialisation. Available for configuration sets allowing phase fixed solutions.
SHIFT INDIV (F5) and SHIFT RUN (F5)	To change between entering an individual point ID different to the defined ID template and the running point ID according to the ID template.

Description of fields

Field	Option	Description
<Point ID:>	User input	The identifier for manually occupied points. The configured point ID template is used. The ID can be changed: To start a new sequence of point ID's over-type the point ID. For an individual point ID independent of the ID template SHIFT INDIV (F5) . SHIFT RUN (F5) changes back to the next ID from the configured ID template.

Field	Option	Description
<Instrument Ht:>	User input	Current instrument height. SmartAntenna offset is automatically added but not displayed.
<3D CQ:>	Output	The current 3D coordinate quality of the computed position.
<Time at Point:>	Output	The time from when the point is occupied until point occupation is stopped.
<RTK Positions:>	Output	The number of GPS real-time positions recorded over the period of point occupation.

Next step

PAGE (F6) changes to the **Code** page.

GPS SURVEY
GPS Survey,
Code page

The setting for <Thematic Codes:> in **CONFIGURE Coding Settings** determines the availability of the fields and softkeys.

Next step

PAGE (F6) changes to the **Map** page.

GPS SURVEY
GPS Survey,
Map page

The **Map** page provides an interactive display of the data.

Next step

PAGE (F6) changes to the first page on this screen.

6.2 Management of Antennas

6.2.1 Overview

Description

- Leica Geosystems antennas are predefined as default and can be selected from a list.
 - Additional antennas can be defined.
 - Default antennas contain an elevation dependent correction model.
 - New antenna correction models can be set up and transferred to the instrument using LGO.
-

6.2.2 Creating a New Antenna/Editing an Antenna

Access
step-by-step

Step	Description
1.	Refer to "6.1 Overview" to access MANAGE Antennas .
2.	In MANAGE Antennas highlight an antenna. When creating a new antenna, highlight the antenna with offset characteristics similar to those required by the new antenna.
3.	Press NEW (F2)/EDIT (F3) to access MANAGE New Antenna/MANAGE Edit Antenna .



Editing antennas is similar to creating a new antenna. All fields can be edited except those of Leica default antennas. For simplicity, the screens are called **MANAGE XX Antenna**.

**MANAGE
XX Antenna,
General page**

21:02
MANAGE
New Antenna
General | TRS
Name : new antenna
Hz Offset : 0.0000
V Offset : 0.1462
L1 PhOffset : 0.0888
L2 PhOffset : 0.0885
Copy Additional Corrections : Yes
STORE PAGE

STORE (F1)

To store the new antenna and to return to **MANAGE Antennas**.

Description of fields

Field	Option	Description
<Name:>	User input	A unique name for the new antenna.
<Hz Offset:>	User input	Horizontal offset of measurement reference point.
<V Offset:>	User input	Vertical offset of measurement reference point.
<L1 PhOffset:>	User input	Offset of L1 phase centre.
<L2 PhOffset:>	User input	Offset of L2 phase centre.
<Copy Additional Corrections:>	Yes or No	Allows additional corrections to be copied from the antenna which was highlighted when MANAGE New Antenna was accessed.

Next step

PAGE (F6) changes to the **IGS** page.

**MANAGE
New Antenna,
IGS page**

The combination of values typed in on this page provides a unique standardised ID for the antenna being used.

Description of fields

Field	Option	Description
<IGS Name:>	User input	The International GPS Service name of the antenna.
<Serial Number:>	User input	The serial number of the antenna.
<Set Up Number:>	User input	The set up number of the antenna. This identifies the version number of the current calibration.

Next step

STORE (F1) stores the antenna and returns to **MANAGE Antennas**.

7 Hidden Point

7.1 Overview


Description

Hidden points cannot be measured directly by TPS. This is because they are not directly visible.

- A hidden point can be calculated from measurements to prisms mounted on a hidden point rod with a known spacing and a known length of the hidden point rod. The hidden point rod may be held at any angle, as long as it is stationary for all measurements.
- Measurements for the hidden point are calculated as if the hidden point was observed directly. These calculated measurements can also be recorded.
- The hidden point rod can have either two or three reflectors. Refer to "7.2 Configuring Hidden Point" for information on configuring the hidden point rod.
- If three reflectors are used the average will be calculated.

Hidden point rod

The reflectors on the hidden point rod are also called auxiliary points after they have been measured.



TPS12_130

- 1 Reflector 1
- 2 Reflector 2
- 3 Reflector 3
- d1 Rod length
- d2 Distance from reflector 1 to reflector 2
- d3 Distance from reflector 1 to reflector 3

Hidden point tasks

The Hidden Point application program can be used for the following tasks:

- The hidden point program may be used to obtain accurate three dimensional coordinates for a point that is currently blocked from direct measurement by an obstruction between the point and the instrument.
- Determination of flow line locations and elevations in manholes, without measuring from the rim of the manhole to the flow line and estimating corrections for nonverticality of the measuring tape and eccentricity from the measurement on the rim to the horizontal location of the flow line;
- Determination of recesses in building corners for detailed surveys, without estimating right angle offsets, with or without taping of the dimensions;
- Measurements behind overhangs, buttresses and columns for quantity determinations in underground construction or mining, without estimating right angle offsets, with or without taping of the dimensions;
- Measurements of industrial process piping or other equipment in close quarters;
- Detailed architectural surveys for remodeling or cultural preservation or restoration work
- Any place where accurate measurements would require many more instrument setups in order to achieve line of sight from the instrument to the points being measured.




TPS Hidden Point application program does not generate a logfile.

7.2 Configuring Hidden Point

Access
step-by-step

Step	Description
1.	PROG. The PROG key opens the TPS1200+/TS30/TM30 Programs menu.
2.	Select Hidden Point and press CONT (F1) .
3.	Press CONF (F2) to access HIDDEN PT Configuration .

HIDDEN PT
Configuration



CONT (F1)

To accept changes and return to the screen from where this screen was accessed.

DMASK (F3)

To edit the display mask currently being displayed in this field. Accesses **CONFIGURE Define Display Mask n**. Available for **<Display Mask:>** being highlighted.

SHIFT ABOUT (F6)

To display information about the program name, the version number, the date of the version, the copyright and the article number.

Description of fields

Field	Option	Description
<Display Mask:>	Choicelist	The user defined display mask to be shown in HIDDEN PT Measure Reflector n . All display masks of the active configuration set defined in CONFIGURE Display Settings can be selected.
<Meas Tolerance:>	User input	Limit of the difference between input and measured spacing of the reflectors. For three reflectors being used, limit for maximum deviation of the three measurements.
<Delete Aux Points:>	Yes or No	The auxiliary points are deleted when the hidden point is stored. The auxiliary points are reflector 1, reflector 2 and reflector 3 of the hidden point rod. The Auxiliary Points ID template is used for the auxiliary points. The Survey Points ID template is used for the computed hidden point.


Field	Option	Description
<No. of Reflectors:>	2 or 3	Two or three reflectors are used on the rod.
<Auto Position:>	Yes or No	Available for <No. of Reflectors: 3>. The third reflector is aimed at automatically.
<Rod Length:>	User input	Total length of hidden point rod.
<Dist R1-R2:>	User input	Spacing between the centres of reflector 1 and reflector 2.
<Dist R1-R3:>	User input	Available for <No. of Reflectors: 3>. Spacing between the centres of reflector 1 and reflector 3. Reflector 3 is situated between reflector 1 and reflector 2.

Next step

CONT (F1) returns to the screen from where this screen was accessed from.

7.3 Measuring Hidden Points



Diagram



- d1 Rod length
- d2 Distance from reflector 1 to reflector 2
- d3 Distance from reflector 1 to reflector 3



Measuring hidden point step-by-step

Step	Description
1.	Press PROG .
2.	Highlight Hidden Point .
3.	Press CONT (F1) to access HIDDEN PT Hidden Point Begin .
4.	Press CONF (F2) to access HIDDEN PT Configuration .
5.	Select <No. of Reflectors: 3> . Enter the values for <Rod Length:> , <Dist R1-R2:> , <Dist R1-R3:> .
6.	Press CONT (F1) to access HIDDEN PT Hidden Point Begin .
7.	HIDDEN PT Hidden Point Begin . CONT (F1) to access HIDDEN PT Measure Reflector 1 .
8.	<p>HIDDEN PT Measure Reflector 1, Hidden Pt page.</p> <p><Aux Pt ID:> The point ID of the auxiliary point, the reflector on the hidden point rod. The Auxiliary Points ID template is used.</p> <p>The horizontal angle, vertical angle, slope distance and height difference to reflector 1, the auxiliary point are displayed.</p> <p><Rod Length:> The length of the rod can be adjusted before the hidden point result is displayed. The rod length always keeps the distances R1-R2 for 2 prisms and R1-R3 for 3 prisms into account.</p>
	PAGE (F6) changes to the Map page.
	SHIFT INDIV (F5) for an individual point ID independent of the ID template. SHIFT RUN (F5) changes back to the next ID from the configured ID template.

Step	Description
9.	ALL (F1) measures reflector 1 and accesses HIDDEN PT Measure Reflector 2 .
10.	Repeat step 9. for reflector 2 and for reflector 3. After the last reflector of the hidden point rod is measured, HIDDEN PT Hidden Point Result, Results page is accessed.
11.	HIDDEN PT Hidden Point Result, Result page. <Point ID:> The name of the hidden point. The configured point ID template is used. <Hz:> , <V:> and <Slope Dist:> The calculated horizontal and vertical angle and slope distance to the computed hidden point. ----- is displayed for unavailable information. <Ht Diff:> The calculated height difference from instrument to computed hidden point. ----- is displayed for unavailable information. <Easting:> , <Northing:> and <Ortho Ht:> The calculated coordinates of the computed hidden point. ----- is displayed for unavailable information.
	NEXT (F5) to store the hidden point and to access HIDDEN PT Measure Reflector 1 .
	SHIFT INDIV (F5) for an individual point ID independent of the ID template. SHIFT RUN (F5) changes back to the next ID from the configured ID template.
12.	PAGE (F6) to change to Code page.
13.	HIDDEN PT Hidden Point Result, Code page. <Point ID:> The name of the hidden point. The configured point ID template is used. <Point Code:> The thematical code. All codes of the job can be selected. <Attribute n:> The attributes for the thematical code. The behaviour of the fields depend on their definition in the codelist. Type in a code if required.
14.	PAGE (F6) to change to Plot page.
15.	HIDDEN PT Hidden Point Result, Plot page. Measured distances are indicated by solid arrows.
16.	STORE (F1) to store the hidden point.


Test or prove hidden points step-by-step

Step	Description
1.	Set up and orient the instrument in an open area.
2.	Repeat steps 1. to 5. from paragraph "Measuring hidden point step-by-step".
3.	Configure the hidden point rod.
4.	Position the tip of the hidden point rod on a mark that is directly visible from the instrument location.

Step	Description
5.	Repeat steps 6. to 16. from paragraph "Measuring hidden point step-by-step". Make sure the hidden point rod does not move between measurements.
6.	PROG to access TPS1200+ Programs .
7.	TPS1200+/TS30/TM30 Programs . Stakeout to access STAKEOUT Stakeout Begin .
	Make sure <Auto Position: 3D> is selected in STAKEOUT Configuration, General page.
8.	STAKEOUT Stakeout Begin . CONT (F1) to access STAKEOUT XX Stakeout, Stake page.
9.	STAKEOUT XX Stakeout, Stake page. Select the hidden point.
	Motorised instruments position to the hidden point.

8 Reference Line

8.1 Overview

Description	The Reference Line application program can be used to set out or measure points relative to a reference line or a reference arc.
Tasks	<p>The Reference Line application program can be used for the following tasks:</p> <ul style="list-style-type: none">• Measuring to a line/arc where the position of a target point can be calculated from its position relative to the defined reference line/arc.• Staking to a line/arc where a target point is known and instructions to locate the point are given relative to the reference line/arc.• Gridstaking a line/arc where a grid can be staked relative to a reference line/arc.• Staking to a polyline. Refer to "8.7 Staking to a Polyline".
Point types	Heights and positions are always taken into account. Points must have full coordinate triplets.
Terms	<p>Reference point: The term "reference point" is used in this chapter to refer to the point from which the perpendicular offset from the reference line/arc, to the target point, is measured. Refer to paragraph "Defining a reference line" and the diagrams for further explanation.</p> <p>Target point: The design point.</p> <ul style="list-style-type: none">• For measuring to a reference line, this is the point with the coordinates of the current position and the designed or calculated height.• For staking or grid staking to a reference line, this is the point to be staked. <p>Measured point: The current position.</p>
Defining a reference line	<p>A reference line can be defined in the following ways:</p> <ul style="list-style-type: none">• Two known points• One known point, an azimuth, a distance and a gradient• One known point, an azimuth, a distance and a difference in height• Polylines can be imported from a DXF job and selected from a list or on the Map page. Refer to "8.7.1 Overview".
Defining a reference arc	<p>A reference arc can be defined in the following ways:</p> <ul style="list-style-type: none">• Two known points and a radius• Three known points
Defining chainage	The chainage of the start point of a reference line/arc can be defined.
	<Azimuth:> is used throughout this chapter. This can also mean <Bearing:> .


8.2 Configuring Reference Line

Access
step-by-step

Step	Description
1.	PROG. The PROG key opens the TPS1200+/TS30/TM30 Programs menu.
2.	Select Reference Line and press CONT (F1) .
3.	Press CONF (F2) to access REFLINE Configuration .

The **General** page

This screen consists of five pages. The fields available on the **General** page and the **Checks** page are very similar to those in **STAKEOUT Configuration**. Refer to "1.2 Configuration of a Logfile" for information on the fields on these pages. The explanations for the softkeys given below are valid as indicated.



CONT (F1)

To accept changes and return to the screen from where this screen was accessed.

DMASK (F3)

To edit the display mask currently being displayed. Available when **<Display Mask:>** is highlighted on **General** page.

SHIFT ABOUT (F5)

To display information about the application program name, the version number, the date of the version, the copyright and the article number.

Description of fields

Field	Option	Description
<Orientate:>		The reference direction to be used to stakeout points. The stakeout elements and the graphical display shown in the Reference Line application program are based on this selection.
	To Line/Arc	The direction of the orientation is parallel to the reference line or the reference arc.
	To Station	The direction of the orientation is from the measured point to the instrument station.
	From Station	The direction of the orientation is from the instrument station to the measured point.

Field	Option	Description
	To Arrow	The direction of the orientation is from the current position to the point to be staked. The graphical display shows an arrow pointing in the direction of the point to be staked.
<Stake Mode:>	Polar	The method of staking out. Available for <Orientate: From Station> or <Orientate: To Station> . The horizontal distance and angle between the current position and the point to be staked, the height difference as defined in REFLINE Configuration , the height of the point to be staked and the check distances are displayed.
	Orthogonal	The distances along and perpendicular to the orientation line between the current position and the point to be staked, the height difference as defined in REFLINE Configuration , the height of the point to be staked and the check distances are displayed.
<Visual Guides:>	Off	Selects the visual guides displayed while staking points to lead to the point to be staked out. Available unless <Orientate: To Arrow> . No symbols or graphics are displayed.
	Arrows	Available unless <Orientate: To Arrow> . Arrows are displayed. The arrows show the direction of the difference in distance between the current position and the point to be staked parallel and perpendicular to the reference object.
	Graphics	A graphical display shows the instrument station, the current position and the point to be staked.
	Arrows & Graphics	Arrows and graphics are displayed.
<Display Mask:>	Choicelist	The user defined display mask to be shown in REFLINE XX Points . All display masks of the active configuration set defined in CONFIGURE Display Settings can be selected.
<Use Chainages:>	Yes or No	Activates the use of chainages within the reference line application program.

Field	Option	Description
<Chain Format:>	Choicelist	Available for <Use Chainages: Yes>. Selects display format for all chainage information fields.
<Auto Position:>	2D	Instrument positions horizontally to the point to be staked out.
	3D	Instrument positions horizontally and vertically to the point to be staked out.
	Off	Instrument does not position to the point to be staked out.

Next step

PAGE (F6) changes to the **Checks** page.

The Checks page

Description of fields

Field	Option	Description
<Pos Check:>	Yes or No	Allows a check to be made on the horizontal coordinate difference between the staked point and the point to be staked. If the defined <Pos Limit:> is exceeded, the stakeout can be repeated, skipped or stored.
<Pos Limit:>	User input	Available for <Pos Check: Yes>. Sets the maximum horizontal coordinate difference which is accepted in the position check.
<Height Check:>	Yes or No	Allows a check to be made on the vertical difference between the staked point and the point to be staked. If the defined <Height Limit:> is exceeded, the stakeout can be repeated, skipped or stored.
<Height Limit:>	User input	Available for <Height Check: Yes>. Sets the maximum vertical difference accepted in the height check.
<Beep near Pt:>	Yes or No	The instrument beeps when the horizontal radial distance from the current position to the point to be staked is equal to or less than defined in <Dist from Pt:>.
<Dist from Pt:>	User input	Available for <Beep near Pt: Yes>. The horizontal radial distance from the current position to the point to be staked when a beep should be heard.

Next step

PAGE (F6) changes to the **Heights** page.

The Heights page**Description of fields**

Field	Option	Description
<Heights:>		Depending on the task chosen this parameter controls the following. <ul style="list-style-type: none"> When measuring to a line/arc, it determines the delta height value which is displayed when points are being measured. When staking to or gridstaking a line/arc, it determines the height value to be staked out.
	Use Ref Line	Heights are computed along the reference line/arc.
	Use Start Point	Heights are computed relative to the height of the starting point. When using a reference arc, this option is automatically applied.
	Use DTM Model	The stake out height is computed from the DTM being used.
<Edit Height:>	No	The height of the current position is displayed while staking out. The value cannot be changed.
	Yes	The height of the point to be staked is displayed while staking out. The value can be changed.

Next step

PAGE (F6) changes to the **Polyline** page.

The Polyline page**Description of fields**

Field	Option	Description
<Stake Points:>	Chocelist	Sets the type of horizontal points to be staked. Refer to "8.7.4 Staking Operation" for a graphic and an explanation of the abbreviations.
	PC, PT, AP	Only these horizontal key points are calculated for staking, skipping the radius and midpoints of arcs and the angle bisector point on lines.
	PC, PT, AP, BP	Only these horizontal key points are calculated for staking, skipping the radius point and midpoint of all arcs.

Field	Option	Description
	PC, PT, AP, RP, MCP	Only these horizontal key points are calculated for staking, skipping the angle bisector point.
	ALL	All horizontal key points are available for stakeout. Refer to "8.7.4 Staking Operation" for a list of all keypoints.
<Auto Increment:>	<None:>	Sets behavior of the stationing after a point is stored. Does not change the station after a point is stored.
	Previous	Proceeds to the next key point down station after each stored staked point.
	Next	Proceeds to the next key point up station after each stored staked point.
<Ref. Tangent:>	Back or Forward	Sets the tangent to be used when staking items in void areas.
<Densify Arc:>	Yes or No	Option to use a different station increment along a curve.
<Small Radius:>	User input	Available for <Densify Arc: Yes> . Defines the threshold value of a small radius curve, for example curve of radius smaller than this value uses the station increment defined in the following field.
<Curve Inc.:>	User input	Available for <Densify Arc: Yes> . Station increment to be used along the small radius curve.

Next step

PAGE (F6) changes to the **Logfile** page. Refer to "1.2 Configuration of a Logfile".

8.3 Starting Reference Line

8.3.1 Manually Entering a Reference Line/Arc



This chapter does not apply for staking to polylines. Refer to "8.7 Staking to a Polyline".

Description

- A reference line/arc can be defined by manually entering known parameters.
- The line/arc is only temporary and is not stored when the program is quit/closed.

Access step-by-step

Step	Description
1.	PROG. The PROG key opens the TPS1200+/TS30/TM30 Programs menu.
2.	Select Reference Line and press CONT (F1) .
3.	CONT (F1) to access REFLINE Reference Task Menu .
4.	REFLINE Reference Task Menu This screen defines the task to be performed. Measure to Line or Measure to Arc : Calculates the coordinates of a point from its position relative to the reference line/arc. Stake to Line or Stake to Arc : Allows points to be staked relative to the reference line/arc. Gridstake Line or Gridstake Arc : Allows a grid to be staked out relative to the reference line/arc.
5.	Press CONT (F1) to access REFLINE Choose Reference Line . Select Reference page.
6.	Select <Ref to Use: Manually Enter> .

The Reference page

The explanations for the softkeys given below are valid as indicated. The fields available depend on the options chosen for **<Task:>** and **<Method:>** on this screen.

CONT (F1)

To accept changes and continue with the subsequent screen.

SLOPE (F3)

To set a slope from a defined reference line/arc. Cut/Fill values can then be displayed to the slope when measurements are taken along the reference line/arc.

OFFSET (F4)

To set horizontal and vertical offsets, shifts and rotations on the defined reference line or to set horizontal and vertical offsets on a defined reference arc.

SURVY (F5)

Available for **<Ref to Use: Manually Enter>** when a point field is highlighted. To measure a point.

SHIFT CONF (F2)

To configure the reference line/arc.

Description of fields

Field	Option	Description
<Method:>	Choicelist	The method by which the reference line/arc will be defined. Depending on the task selected in REFLINE Reference Task Menu various options are available.
<Start Point:>	Choicelist	The start point of the reference line/arc.
<Second Point:>	Choicelist	Available for <Method: 3 Points> . The second point of the reference arc.
<End Point:>	Choicelist	Available for <Method: 2 Points> , <Method: 3 Points> and <Method: 2 Points/Radius> . The end point of the reference line/arc.
<Line Length:>	Output	Available for <Ref to Use: Manually Enter> with <Method: 2 Points> . The horizontal grid distance between <Start Point:> and <End Point:> of the line. ---- is displayed if the distance cannot be calculated.
<Azimuth:>	User input	Available for <Method: Pt/Brg/Dst/Grade> and <Method: Pt/Brg/Dst/ΔHt> . The azimuth of the reference line.
<Horiz Dist:>	User input	Available for <Method: Pt/Brg/Dst/Grade> and <Method: Pt/Brg/Dst/ΔHt> . The horizontal distance from the start point to the end point of the reference line.
<Grade:>	User input	Available for <Method: Pt/Brg/Dst/Grade> . The gradient of the line from the start point to the end point of the reference line.
<ΔHeight:>	User input	Available for <Method: Pt/Brg/Dst/ΔHt> . The difference in height from the start point to the end point of the reference line.
<Radius:>	User input	Available for <Method: 2 Points/Radius> . The radius of the reference arc.

Field	Option	Description
<Arc Dist:>	Output	The horizontal grid distance along the arc between <Start Point:> and <End Point:> of the arc. ----- is displayed if the distance cannot be calculated.

Next step

PAGE (F6) changes to the **Map** page.

The Map page

The **Map** page provides an interactive display of the data.

Next step

IF the selected task is	THEN
Measure to Line/Arc	<ul style="list-style-type: none"> • CONT (F1) accepts the changes and accesses REFLINE Measure Points. • Refer to "8.4 Measuring to a Reference Line/Arc".
Stake to Line/Arc	<ul style="list-style-type: none"> • CONT (F1) accepts the changes and accesses REFLINE Enter Offset Values. • Refer to "8.5 Staking to a Reference Line/Arc".
Gridstake Line/Arc	<ul style="list-style-type: none"> • CONT (F1) accepts the changes and accesses REFLINE Define Grid. • Refer to "8.6 Gridstaking to a Reference Line/Arc".
Stake to Polyline	<ul style="list-style-type: none"> • CONT (F1) accepts the changes and accesses REFLINE Choose Polyline. • Refer to "8.7 Staking to a Polyline".

8.3.2 Selecting an Existing Reference Line/Arc



This chapter does not apply for staking to polylines. Refer to "8.7 Staking to a Polyline".

Description

Reference lines/arcs can be created, edited, stored, deleted in the **<Control Job>**.

Access step-by-step

Step	Description
1.	PROG. The PROG key opens the TPS1200+/TS30/TM30 Programs menu.
2.	Select Reference Line and press CONT (F1) .
3.	CONT (F1) to access REFLINE Reference Task Menu .
4.	REFLINE Reference Task Menu This screen defines the task to be performed. For a description of the tasks refer to "8.3.1 Manually Entering a Reference Line/Arc". Select a task except Stake to Polyline .
5.	Press CONT (F1) to access REFLINE Choose Reference Line . Select Reference page.
6.	Select <Ref to Use: Select from Job> .

The Reference page

The explanations for the softkeys and the fields are as for manually entering a reference line. The **<Method:>** field is not available and all line definition fields are outputs, all other differences are described below. Refer to "8.3.1 Manually Entering a Reference Line/Arc" for information. The fields shown depend on:

- the task selected in **REFLINE Reference Task Menu**.
AND
- the option chosen for **<Method:>** in **REFLINE New Reference XX**.

Description of fields

Field	Option	Description
<Ref Line:>	Choicelist	Available for the tasks XX Line in REFLINE Reference Task Menu . The reference line to be used.
<Ref Arc:>	Choicelist	Available for the tasks XX Arc in REFLINE Reference Task Menu . The reference arc to be used.
<Arc Dist:>	Output	Available for the tasks XX Arc in REFLINE Reference Task Menu .

Next step

PAGE (F6) changes to the **Map** page.


The Map page

The **Map** page provides an interactive display of the data. The reference line/arc can be viewed but not defined using this page.

Next step

IF	THEN
the desired reference line/arc needs to be created, edited or selected	<ul style="list-style-type: none"> Highlight <Ref Line:> or <Ref Arc:> and press ENTER to access REFLINE Manage Reference XX. Refer to paragraph "Managing reference lines".
the desired reference line/arc has been selected	<ul style="list-style-type: none"> For the task Measure to XX: CONT (F1) to access REFLINE Measure Points, Ref XX page. Refer to "8.4 Measuring to a Reference Line/Arc". For the task Stake to XX: CONT (F1) to access REFLINE Enter Offset Values. Refer to "8.5 Staking to a Reference Line/Arc". For the task Gridstake XX: CONT (F1) to access REFLINE Define Grid. Refer to "8.6 Gridstaking to a Reference Line/Arc".
offsets are to be defined	<ul style="list-style-type: none"> OFFSET (F4) to access REFLINE Define Offsets.

Managing reference lines



CONT (F1)

To select the highlighted reference line/arc and to return to the screen from where this screen was accessed.

NEW (F2)

To create a reference line/arc.

EDIT (F3)

To edit a reference line/arc.

DEL (F4)

To delete a reference line/arc.

Description of columns

Column	Description
Name	Names of all reference lines/arcs available in the active job.
Date	Date that the reference line/arc was created.

Next step

IF a reference line/arc	THEN
is to be selected	<ul style="list-style-type: none"> Highlight the desired reference line/arc. CONT (F1) closes the screen and returns to REFLINE Choose Reference Line.
is to be created/edited	<ul style="list-style-type: none"> NEW (F2)/EDIT (F3) to access REFLINE New Reference XX/REFLINE Edit Reference XX. Refer to paragraph "Creating a new reference line". Editing a reference line/arc is similar to creating a new reference line/arc. For simplicity, only REFLINE New Reference XX is described below and the differences are clearly outlined.

Creating a new reference line

The Input page

21:16 REFLINE IR STD

New Reference Line

Input Map

Ref ID : 100

Method : 2 Points

Start Point : 500

End Point : 501

Line Length : 54.905 m

STORE SURVY PAGE

STORE (F1)

To store changes and return to **REFLINE Manage Reference XX**.

SURVY (F5)

To measure a known point. Available when **<Start Point:>**, **<Second Point:>** or **<End Point:>** is highlighted.

Description of fields

Field	Option	Description
<Ref ID:>	User input	The ID of the new reference line/arc.

The other fields available depend on the option chosen in **REFLINE Reference Task Menu** and for **<Method:>** in this screen. When editing a reference line/arc all line definition fields are outputs. Refer to "8.3.1 Manually Entering a Reference Line/Arc" for descriptions.

Next step

PAGE (F6) changes to the **Map** page.

The Map page

The **Map** page provides an interactive display of the data. When editing a reference line/arc this page is a **Plot** page and the reference line/arc can be viewed but not defined using this page.

Next step

STORE (F1) stores the changes and returns to **REFLINE Manage Reference XX**.

8.3.3 Defining the Offsets related to a Reference Line/Arc



This chapter does not apply for staking to polylines.

Description


A reference line can be offset, shifted and rotated, a reference arc can be offset.

Access step-by-step

Step	Description
1.	PROG. The PROG key opens the TPS1200+/TS30/TM30 Programs menu.
2.	Select Reference Line and press CONT (F1) .
3.	CONT (F1) to access REFLINE Reference Task Menu .
4.	REFLINE Reference Task Menu This screen defines the task to be performed. Select a task except Stake to Polyline .
5.	Press CONT (F1) to access REFLINE Choose Reference Line . Select Reference page.
6.	Press OFFSET (F4) to access REFLINE Define Offsets .

Defining the offsets

This screen contains different fields depending on the options chosen for **<Heights:>** in **REFLINE Configuration, Heights** page, and the selected task.



Rotate Line : g

CONT (F1)

To confirm the selections and to return to the previous screen.

SHIFT CONF (F2)

To configure the reference line/arc.



Description of fields

Field	Option	Description
<Offset Line:> or <Offset Arc:>	User input	Distance to horizontally offset reference line/arc to the left or right. When an offset is applied to an arc the radius of the arc changes.
<Shift Line:>	User input	Distance to horizontally shift reference line forward or back. Available for task XX Line unless <Heights: Use Ref Line> in REFLINE Configuration, Heights page.

Field	Option	Description
<Height Offset:>	User input	The vertical offset of the reference line/arc. Available for <Heights: Use Start Point> and <Heights: Use Ref Line>.
<DTM Offset:>	User input	The vertical offset of the DTM model. Available for <Heights: Use DTM Model>.
<Rotate Line:>	User input	Angle by which to rotate the reference line. Available for task XX Line unless <Heights: Use Ref Line> in REFLINE Configuration, Heights page.

Next step

CONT (F1) closes the screen and returns to **REFLINE Choose Reference Line**.

8.3.4 Defining the Slope related to a Reference Line/Arc



This chapter does not apply for staking to polylines.


Description

- It is possible to measure points and stake points on slopes related to a reference line/arc. A slope can be defined and cut/fill values can then be displayed to the slope when measuring along the reference line/arc. The slope is a plane from the reference line/arc and extends along the length of the reference line/arc.
- Slopes can be used when measuring to a reference line/arc, staking a point relative to a reference line/arc or performing a grid stakeout relative to a reference line/arc.

Access step-by-step


Step	Description
1.	PROG. The PROG key opens the TPS1200+/TS30/TM30 Programs menu.
2.	Select Reference Line and press CONT (F1) .
3.	CONT (F1) to access REFLINE Reference Task Menu .
4.	REFLINE Reference Task Menu This screen defines the task to be performed. Select a task except Stake to Polyline .
5.	Press CONT (F1) to access REFLINE Choose Reference Line . Select Reference page.
6.	Press SLOPE (F3) to access REFLINE Define Slope .

Step 1) activating the slope method

Step	Description
1.	Ensure that <Use Slope: Yes> is selected. 

Step 2) defining the slope parameters


Step	Description
1.	Defining the slope type. Defining a slope type of <Slope Type: Left Down> creates a downward plane extending to the left of the defined reference line/arc. Defining a slope type of <Slope Type: Right Down> creates a downward plane extending to the right of the defined reference line/arc. Defining a slope type of <Slope Type: Left Up> creates an upward plane extending to the left of the defined reference line/arc. Defining a slope type of <Slope Type: Right Up> creates an upward plane extending to the right of the defined reference line/arc.

Step	Description
	
2.	<p>Defining the slope grade.</p> <p>The inclination of the slope is defined by the slope grade. The units for slope grade are defined in the Configure /Units & Formats screen.</p> <p>Slope Type : Right Down Slope Grade : 1:2</p>

**Step 3)
defining any
necessary offsets**



Step	Description
1.	<p>The slope is always defined as starting from a 'hinge line'.</p> <p>The hinge line can be horizontally and/or vertically offset from the reference line/arc. The direction of the reference line/arc is always from the starting point. The offsets are always relative to the direction of the reference line/arc.</p> <p>When Hz Offset=0 and V Offset=0, then the hinge line is the reference line/arc.</p> <p>Slope Grade : 1:2 Hinge Hz Ofst : 1.250 m Hinge V Ofst : 0.500 m</p>

**Step 4)
defining the
display mask**

Step	Description
1.	<p>Press DMASK (F3) in the Define Slope screen to access the display mask settings</p> <p>This display mask is available when using the slope method. It is user configurable and describes the current reflector position in relation to the defined slope and defined reference line/arc.</p> 

**Step 4)
measuring the
points**

Step	Description
1.	Press CONT (F1) to close the Define Slope screen.
2.	Choose the appropriate Task and choose the relevant reference line/arc.

Step	Description
	
3.	<p>Press CONT (F1) to access the Measure Points screen, move to the Slope page.</p> 

Description of all fields from the Slope Display Mask

Field	Description
<Chainage:>	Displays the current chainage.
<Current Slope:>	Displays the current slope of the reflector position to the hinge.
<Design Slope:>	Displays the slope grade as defined by the user.
<East:>	Displays the East coordinate of the current reflector position.
<Height:>	Displays the Height value of the current reflector position.
<North:>	Displays the North coordinate of the current reflector position.
<Point ID:>	To enter the point ID.
<Reflector Ht:>	To enter the reflector height.
<SD to Hinge:>	Displays the slope distance offset from the hinge to measured point.
<SD to Line:>	Displays the slope distance offset from line/arc to measured point.
<Slope Cut/Fill:>	Displays the value of the difference between the actual reflector elevation to the slope elevation at that position. A cut is above the slope. A fill is below the slope.
<Start Chainage:>	Displays the starting chainage as defined by the user.
<ΔHeight Hinge:>	Displays the delta height from the current position to the hinge.
<ΔHeight Line:>	Displays the delta height from the current position to the line/arc.

Field	Description
<ΔLine/Arc:>	Displays the horizontal distance from the start point of the line/arc to the base point of the measured point, along the line/arc.
<ΔLine/Arc-End:>	Displays the horizontal distance from the end point of the line/arc to the base point of the measured point, along the line/arc.
<ΔOffset:>	Displays the perpendicular offset from the line/arc to measured point.
<ΔOffset Hinge:>	Displays the perpendicular offset from the hinge to measured point.

8.4 Measuring to a Reference Line/Arc




This chapter does not apply for staking to polylines.

Access step-by-step

Step	Description
1.	PROG. The PROG key opens the TPS1200+/TS30/TM30 Programs menu.
2.	Select Reference Line and press CONT (F1) .
3.	CONT (F1) to access REFLINE Reference Task Menu .
4.	REFLINE Reference Task Menu This screen defines the task to be performed. Select a task Measure to XX .
5.	Press CONT (F1) to access REFLINE Choose Reference Line .
6.	Press CONT (F1) to access REFLINE Measure Points .

The Ref Line page

The fields available depend on the options chosen for **<Heights:>** and **<Edit Height:>** in **REFLINE Configuration, Heights** page and the task selected in **REFLINE Reference Task Menu**.



ALL (F1)

To measure and record the current position.

DIST (F2)

To measure and display distances. The difference between the current position and the point being staked is displayed.

REC (F3)

To record displayed values.

LINE (F4)

To define/select a reference line/arc.

STAKE (F5)

To define reference line offsets to be staked out in relation to the reference line.

SHIFT CONF (F2)

To configure a reference line/arc.

SHIFT AVGE (F2)

To check an exceeding of the threshold settings for the differences for the position and height components between the averaged point and the point being stored.

SHIFT 2FACE (F4)

To take a measurement in Face I and Face II. The point stored is an average of the two measurements.

When using instruments fitted with ATR, the point is automatically measured in both faces, the resulting point is stored and the instrument is returned to the first face.

This hotkey is only available for **<EDM Mode: Standard>** and **<EDM Mode: Fast>** and in the Survey, Reference Line and Stakeout programs.

SHIFT INDIV (F5) and SHIFT RUN (F5)

To change between entering an individual point ID different to the defined ID template and the running point ID according to the ID template.

Description of fields

Field	Option	Description
<Point ID:>	User input	The point ID of the point to be measured.
<Reflector Ht:>	User input	An individual reflector height can be typed in.
<Chainage:>	Output	Chainage of the current position along the line/arc. This is the chainage of the start of the reference line/arc plus <ΔLine:>/<ΔArc:> .
<ΔOffset:>	Output	Perpendicular offset from the reference line/arc calculated from the reference point to the measured point.
<Check Dist 1:>	Output	Horizontal distance from start point to measured point.
<Check Dist 2:>	Output	Horizontal distance from end point to measured point.
<ΔLine:>	Output	Horizontal distance along the reference line from the start point to the reference point.
<ΔLine-End:>	Output	Horizontal distance along the reference line from the end point to the reference point.
<ΔArc:>	Output	Horizontal distance along the reference arc from the start point to the reference point.
<ΔArc-End:>	Output	Horizontal distance along the reference arc from the reference point to the end point.
<ΔHt-Start:>	Output	Height difference between the start point and the measured point.

Field	Option	Description
<Height:>	Output	Height of measured point.
< Δ Ht-Line:>	Output	Height difference between the reference point and the measured point.
< Δ Perp Dist:>	Output	Slope distance between the reference point and the measured point.
< Δ Spatial Dist:>	Output	Slope distance between the start point and the reference point.
< Δ Ht-DTM:>	Output	Height difference between the measured point and the DTM.
<Design Ht:>	User input	Allows input of the design height of the target point.
< Δ Ht-Design:>	Output	Height difference between the <Design Ht:> and the height of the measured point.

Next step

PAGE (F6) changes to the **Map** page.

8.5 Staking to a Reference Line/Arc



This chapter does not apply for staking to polylines.

Access step-by-step

Step	Description
1.	PROG. The PROG key opens the TPS1200+/TS30/TM30 Programs menu.
2.	Select Reference Line and press CONT (F1) .
3.	CONT (F1) to access REFLINE Reference Task Menu .
4.	REFLINE Reference Task Menu This screen defines the task to be performed. Select a task Stake to XX .
5.	Press CONT (F1) to access REFLINE Choose Reference Line .
6.	Press CONT (F1) to access REFLINE Enter Offset Values .

Entering the offset values

The screen contains different fields depending on the options chosen for **<Heights:>** and **<Edit Height:>** in **REFLINE Configuration, Heights** page and **<Task:>** in **REFLINE Choose Reference Line, Reference** page. The explanations for the softkeys given below are valid in all cases.

13:10 REFLINE IR STD

Enter Offset Values

Point ID : 0005

Stake Offset : 0.250 m

Along Line : 5.250 m

Chainage : 5.250 m

Design Ht : 0.100 m

CONT LINE SURVY Q2 a ↑

CONT (F1)

To confirm the selections and to continue with the subsequent screen.

LINE (F4)

To define/select a reference line/arc.

SURVY (F5)

To measure a point relative to the reference line/arc.

SHIFT CONF (F2)

To configure the reference line/arc.

SHIFT INDIV (F5) and SHIFT RUN (F5)

To change between entering an individual point ID different to the defined ID template and the running point ID according to the ID template.

Description of fields

Field	Option	Description
<Point ID:>	User input	The point ID of the target point to be staked.
<Stake Offset:>	User input	The offset from the reference point to the target point.
<Along Line:>	User input	Available for <Task: Stake to Line> . Horizontal distance from the start point to the reference point along the reference line.


Field	Option	Description
<Along Arc:>	User input	Available for <Task: Stake to Arc>. Horizontal distance from the start point to the reference point along the reference arc.
<Chainage:>	User input	Chainage along the line/arc. This is the chainage of the start of the reference line/arc plus <Along Line:>/<Along Arc:>.
<Height Offset:>	User input	Available for <Edit Height: No> unless <Heights: Use DTM Model> in REFLINE Configuration . The height offset of the target point is calculated as the height of the start/reference point plus <Height Offset:>.
<Design Ht:>	User input	Available for <Edit Height: Yes> in REFLINE Configuration, Heights page. The suggested design height of the target point is the height of the start/reference point.

Next step

CONT (F1) to accept changes and continue to **REFLINE XX Stakeout, Ref XX** page.

The Ref Line page

This screen contains different fields depending on the options chosen for <Stake Mode:> in **REFLINE Configuration, General** page. The majority of the softkeys are identical to those available for measuring to a reference line/arc. Refer to "8.4 Measuring to a Reference Line/Arc" for information on the softkeys.



2FACE (F4)

To take a measurement in Face I and Face II. The point stored is an average of the two measurements. When using instruments fitted with ATR, the point is automatically measured in both faces, the resulting point is stored and the instrument is returned to the first face.

This hotkey is only available for <EDM Mode: Standard> and <EDM Mode: Fast> and in the Survey, Reference Line and Stakeout programs.

SURVY (F5)

To measure a point relative to the reference line/arc.

SHIFT CONF (F2)

To configure a reference line/arc.

SHIFT POS2D (F3)

To position the telescope (X,Y) onto the point to be staked.

SHIFT POS3D (F4)


To position the telescope (X,Y,Z) onto the point to be staked.

SHIFT INDIV (F5) and SHIFT RUN (F5)

To change between entering an individual point ID different to the defined ID template and the running point ID according to the ID template.

Description of fields

Field	Option	Description
<Point ID:>	User input	The point ID of the target point to be staked.
<Reflector Ht:> or <hr:>	User input	The default reflector height as defined in the active configuration set is suggested.
<Height:> or <Ht:>	Output	Available for <Edit Height: No> in REFLINE Configuration, Heights page.
<Design Ht:> or <D Ht:>	User input	Available for <Edit Height: Yes> in REFLINE Configuration, Heights page.
<LEFT:> or <RGHT:>	Output	Offset from the point to be staked out to the current position, perpendicular to the orientation line. If <Orientate: From Station>, this value is positive when the point to be staked is to the right of the line of orientation when looking from the instrument station towards the current position. If <Orientate: To Station>, this value is positive when the point to be staked is to the right of the line of orientation when looking from the current position towards the instrument station. If <Orientate: To Arrow> this value is always zero.
<FORW:> or <BACK:>	Output	Horizontal distance between the point to be staked and the current position along the orientation line. If <Orientate: From Station>, this value is positive when the point to be staked is behind the current position when looking from the instrument station towards the current position.

Field	Option	Description
		If <Orientate: To Station> , this value is positive when the point to be staked is between the current position and the instrument station.
<ΔHz:>	Output	<p>Horizontal angle between the point to be staked and the current position as seen from the instrument station.</p> <p> For <Orientate: From Station> and <Orientate: To Station> the value is calculated and displayed permanently. For other orientation methods, the distance must be measured before the value can be displayed.</p>

Next step

PAGE (F6) changes to the **Map** page.

8.6 Gridstaking to a Reference Line/Arc



This chapter does not apply for staking to polylines.

Access step-by-step

Step	Description
1.	PROG. The PROG key opens the TPS1200+/TS30/TM30 Programs menu.
2.	Select Reference Line and press CONT (F1) .
3.	CONT (F1) to access REFLINE Reference Task Menu .
4.	REFLINE Reference Task Menu This screen defines the task to be performed. Select a task Gridstake to XX .
5.	Press CONT (F1) to access REFLINE Choose Reference Line .
6.	Press CONT (F1) to access REFLINE Define Grid .

Defining the grid

The softkeys are identical to those available for staking to a reference line/arc. Refer to "8.5 Staking to a Reference Line/Arc" for information on the softkeys.

Description of fields

Field	Option	Description
<Begin Grid at:>	User input	Distance along the reference line/arc from the start point to the first target point to be staked.
<Chainage:>	User input	Chainage of the first target point to be staked along the line/arc. This is the chainage of the start of the reference line/arc plus <Begin Grid At:>.
<Increment by:>	User input	Spacing between points on the grid line.
<Line Offsets:>	User input	Spacing between grid lines.
<Next Line:>	Start at Begin	Each new grid line is started at the same end as where the previous grid line started.
	Current Grid Pt	Each new grid line is started at the same end as where the previous grid line finished.
<Point ID:>	Grid ID	Point ID is shown as the position of the grid being staked.
	Pt ID Template	The point ID template as defined in the active configuration set is used for grid point ID's.


Next step

CONT (F1) accepts the changes and continues to **REFLINE Stake +yyy.yy +xxx.xx, Ref XX** page.

The Ref Line page

The title of this screen indicates the position of the grid being staked where +yyy.yy is the station position along the grid line and +xxx.xx is the grid line offset.

The functionality of this screen is very similar to **REFLINE XX Stakeout, Ref XX** page. Differences between the two screens are outlined below. Refer to "8.5 Staking to a Reference Line/Arc" for all other key and field explanations.



SKIP (F4)

To skip the currently displayed station and increment to the next station.

LINE (F5)

To start staking the next grid line. The position of the first point on the new line is determined by the option selected for **<Next Line:>**.

Description of fields

Field	Option	Description
<Point ID:>	User input	The point ID is based on the selection for <Point ID:> in REFLINE Define Grid . If a different point ID is typed in, the next point ID will still be shown as the next automatically computed point ID.
<Height:> or <Ht:>	Output	Available for <Edit Height: No> in REFLINE Configuration, Heights page.
<Design Ht:> or <D Ht:>	User input	Available for <Edit Height: Yes> in REFLINE Configuration, Heights page. To type in the design height. If a design height has been entered and SKIP (F4) or LINE (F5) is used the true grid height for the next point is shown as the suggested height.

Next step

PAGE (F6) changes to the **Map** page.

8.7 Staking to a Polyline

8.7.1 Overview

Description	The reference line task Staking to a Polyline allows points to be staked relative to a polyline. This option makes use of line and area data from CAD as simple as possible.
Preparing the data	Line data can be created by one of the following methods: <ul style="list-style-type: none">• Data from CAD saved into a DXF file• Manually creating lines with existing points• Measuring lines in the field• Using Design to Field• Using Alignment Tool Kit• Creating Lines in LGO
Options to convert the DXF file to a job	To facilitate the electronic transfer of lines from the plans to the surveying instrument, different tools have been created to read DXF format into a System1200 job. DXF Import: Copy the DXF files to the \data directory on the CompactFlash card of the TPS1200+ instrument. Once the card is back in the instrument the DXF import program can be used to bring the lines into the job. Design to Field: This module is included in LEICA Geo Office and allows the conversion of DXF files into a System1200 job. This method makes the task of transferring several lines into a single job quick and efficient.


8.7.2 Accessing Staking to Polylines & Choosing a Polyline

Access step-by-step

Select the task **Stake to Polyline** in **REFLINE Reference Task Menu** and press **CONT (F1)** to access **REFLINE Choose Polyline**.

REFLINE Choose Polyline, Lines/Areas page

The **Lines/Areas** page allows for a tabular selection of a polyline. Lines can be either 2D or 3D depending on the input data and are shown as such.



CONT (F1)

To select the highlighted polyline and to continue with the subsequent screen.

EDIT (F2)

To change the start or end chainage value of the selected line. if **<Start Chainage:>** is edited then the **<End Chainage:>** is computed from the new input plus the length.

IMPRT (F5)

To import lines or Road objects from another job as long as the coordinate systems are compatible.

PAGE (F6)

To change to another page on this screen.

Next step

PAGE (F6) changes to the **Map** page.

REFLINE Choose Polyline, Map page

The **Map** page allows a selection of the line to be staked in the graphical view with the **<-- (F2)** or **--> (F3)** keys or by mean of the stylus. Only visible lines can be selected.

The selected line is highlighted and its name shown in the upper left corner of the screen.

8.7.3 Stake Parameters

Access

CONT (F1) in **REFLINE Choose Polyline.**

REFLINE

Stake,
Parameters page

Operating parameters are defined on this page.

This screen contains the **Parameters** page, the **Coords** page and the **Map** page. The explanations for the softkeys are valid for all three pages.

CONT (F1)

To accept the parameters and to continue with the subsequent screen.

PREV (F4)

To decrease the chainage value, down chainage, by the defined chainage interval **<Chainage Inc.>**.

NEXT (F5)

To increase the chainage value, up chainage, by the defined chainage interval **<Chainage Inc.>**.

PAGE (F6)

To change to another page on this screen.


SHIFT BOP (F4)

To return the chainage value to the beginning of the project.

SHIFT EOP (F5)

To send the chainage value to the end of project.

Description of fields

Field	Option	Description
<Line Name:>	Output	The name of the selected polyline.
<Strt Chainage:>	Output	The beginning chainage of the line.  The start chainage can be edited from REFLINE Choose Polyline with EDIT (F2) .
<Length:>	Output	The length of the line.
<End Chainage:>	Output	The chainage of the end of the line.
<Chainage:>	User input	The chainage to be staked initially. Any chainage can be entered.
<Offset:>	User input	The distance to stake off the line. Any value between -2000 m and 2000 m can be entered.

Field	Option	Description
<Vert. Shift:>	User input	To shift the line vertically. The best example of the use of this feature is a situation where all grades of the line are finish grade but the stakes are set referenced to sub-grade.
<Chainage Inc.:>	User input	The interval at which chainages will be staked. Incrementing begins from <Chainage:> set above.

Next step

PAGE (F6) changes to the **Coords** page.

**REFLINE
Stake,
Coords page**

This page allows to validate the coordinate values of the point to be staked.

Next step

PAGE (F6) changes to the **Maps** page.

**REFLINE
Stake,
Map page**

This page allows to visualize the position of the points. Top line shows the current horizontal geometry as well as any horizontal or vertical key points.

Next step


CONT (F1) changes to **REFLINE Stakeout**.

8.7.4 Staking Operation

Access

CONT (F1) in REFLINE Stake.

Basic rules for polyline stakeout



TPS12_234


- P1 BOP - Beginning of project
- P2 PC - Beginning of curve
- P3 RP - Radius point
- P4 PT - End of curve
- P5 PI - Point of intersection
- P6 AP - Angle point
- P7 EOP - End of project
- P1' BOP - Beginning of project
- P2' PC - Beginning of curve
- P3' PI - Point of intersection
- P4' PT - End of curve
- P5' AP-B - Angle point, back tangent
- P6' BP - Bisected point
- P7' AP-F - Angle point, forward tangent
- P8' EOP - End of project

General terms:

- Curve - Curve segment
- Extension - Line extension
- MCP - Mid curve point
- Straight - Straight segment

REFLINE Stakeout, Stake page

The explanations for the softkeys given below are valid for all pages.



ALL (F1)

To measure a distance and store distance and angles. Accesses **REFLINE Results**.

DIST (F2)

To measure a distance.

REC (F3)

To store angles and distance. Distance must be measured before.

PREV (F4)

To decrease the chainage value, down chainage, by the defined chainage interval <Chainage Inc.:.>.

NEXT (F5)

To increase the chainage value, up chainage, by the defined chainage interval <Chainage Inc.:.>.

PAGE (F6)

To change to another page on this screen.

SHIFT CONF (F2)

To configure referenceline.

SHIFT POS2D (F3)

To position the telescope (X,Y) onto the point to be staked.

SHIFT POS3D (F4)

To position the telescope (X,Y,Z) onto the point to be staked.

SHIFT INDIV (F5) and SHIFT RUN (F5)

To change between entering an individual point ID different to the defined ID template and the running point ID according to the ID template.

Description of fields

Field	Option	Description
First line on screen	User input	The point ID of the point to be staked. Editable.
<hr:>	User input	The default reflector height as defined in the active configuration set is suggested.
Third line on screen	User input	The current chainage to be staked. Editable.
< Δ Ht:>	Output	Displays the difference between the height of the current position and the height to be staked.
<Ht:>	Output	The orthometric height of the current position is displayed. If the orthometric height cannot be displayed, the local ellipsoidal height is displayed. If it is not possible to display the local ellipsoidal height, the WGS 1984 height is displayed.

Next step

PAGE (F6) changes to the **Details** page.

This page shows a live version of more information regarding the staked point.

Description of fields

Field	Option	Description
<Design Sta:>	User input	Current chainage to be staked. Editable.
<Design Offset:>	User input	Current offset being staked. Editable.
<Design Ht:>	User input	The design height, which is the orthometric height of the point to be staked, is displayed. If the orthometric height cannot be displayed, the local ellipsoidal height is displayed. If it is not possible to display the local ellipsoidal height, the WGS 1984 height is displayed.

Next step

Step	Description
1.	PAGE (F6) changes to the Map page providing an interactive display of the data.
2.	ALL (F1) changes to REFLINE Results .

8.7.5 Results of Stakeout

Access

ALL (F1) in REFLINE Stakeout.

REFLINE
Results,
General page

17:23
REFLINE
Results: EOP, VPI
General | Coords | Map
Point Id : 123
Code : <None>
Meas Chainage: 1020.400 m
Meas Offset : 5008.400 m
Design Ht. : 0.000 m
Meas Ht. : -1.250 m

CONT (F1)

To return to **REFLINE Stakeout**.

+ELEV (F3)

To add a vertical offset to the design height and to display the new height.

PAGE (F6)

To change to another page on this screen.

CONT +ELEV PAGE a ↑

Description of fields

Field	Option	Description
<Point ID:>	Output	The point ID of the point staked.
<Code:>	User input	With codelist: Select a code from the choicelist. Only point codes are available for selection. <None> to store a point without code or to perform Linework without coding. Without codelist: Type in a code. ----- to store a point without code or to perform Linework without coding.
<Meas Chainage:>	Output	The chainage measured at the staked point.
<Meas Offset:>	Output	The offset from the polyline measured at the staked point.
<Design Ht:>	Output	Allows input of the design height of the target point. The suggested value for the <Design Ht:> is as configured in the <Heights:> field in REFLINE Configuration, Heights page.
<Meas Ht:>	Output	The height measured at the staked point.

Next step

PAGE (F6) changes to the **Coords** page.

REFLINE
Results,
Coords page

This page displays the design coordinates as well as the differences between design and measured coordinates.

**REFLINE
Results,
Map page**

Next step

PAGE (F6) changes to the **Map** page.

The Map page provides an interactive display of the data.

Next step

PAGE (F6) changes to the first page on this screen.

9 Reference Plane & Face Scan

9.1 Overview

Description

- The Reference Plane & Face Scan application program can be used to measure points relative to a reference plane.
- A reference plane can also be scanned via Face Scan.

Reference plane tasks

The Reference Plane & Face Scan application program can be used for the following tasks:

- Measuring points to calculate and store the perpendicular distance to the plane.
- Viewing and storing the instrument and/or local coordinates of the measured points.
- Viewing and storing the height difference from the measured points to the plane.
- Scanning a defined area.



Planes can only be computed with grid coordinates.

Defining a reference plane

Reference planes are created using a right hand system. For two points defining a plane a vertical plane is used. A reference plane is defined with the X axis and the Z axis of the plane. The Y axis of the plane defines the positive direction of the Y axis. A reference plane can be defined in the following ways.

- vertical
- tilted

Vertical plane

The axis of the vertical reference plane are:


X axis: Horizontal and parallel to the plane; X axis starts in point defined as origin point

Z axis: Parallel to the instrument zenith and parallel to the plane


Y axis: Perpendicular to the plane; increases in the direction as defined



Offsets are applied in the direction of the Y axis.



a Height
b Easting
N Northing
P1 Origin of plane
P2 Point of plane
X X axis of plane



a Height
b Easting
N Northing
P1 Origin of plane
P2 Point of plane
X X axis of plane


Y Y axis of plane
Z Z axis of plane

Y Y axis of plane
Z Z axis of plane


Tilted plane

Any number of points define the plane, perimeter to be scanned is defined by a bottom left-topright window. The axis of the tilted reference plane are:

X axis: Horizontal and parallel to the plane
Z axis: Defined by steepest direction of the plane
Y axis: Perpendicular to the plane; increases in the direction as defined
☞ Offsets are applied in the direction of the Y axis.




TPS12_165
a Height
b Easting
N Northing
P1 Origin of plane
X X axis of plane
Y Y axis of plane
Z Z axis of plane




TPS12_165a
a Height
b Easting
N Northing
P1 Origin of plane
X X axis of plane
Y Y axis of plane
Z Z axis of plane

Offset of the plane



TPS12_164
P1 Origin of plane
X X axis of plane
Y Y axis of plane
Z Z axis of plane
d1 Positive offset
d2 Negative offset



TPS12_164a
P1 Origin of plane
P2 Point defining offset of plane
P2' P2 projected on original plane
d1 Offset defined by P2
X X axis of plane
Y Y axis of plane
Z Z axis of plane



With four or more points a least squares adjustment is calculated resulting in a best fit plane.

Origin

The origin of the reference plane can be defined to be in the plane coordinates or in the instrument coordinates.

Positive direction of plane


The positive direction of the plane is defined by the direction of the Y axis. The direction can be changed by selecting a point which defines the negative direction of the Y axis.

9.2 Configuring Reference Plane

Access
step-by-step

Step	Description
1.	PROG. The PROG key opens the TPS1200+/TS30/TM30 Programs menu.
2.	Select Reference Plane and press CONT (F1) .
3.	Press CONF (F2) to access REFPLANE Configuration .

REFPLANE
Configuration,
Parameters page



CONT (F1)

To accept changes and return to the screen from where this screen was accessed.

DMASK (F3)

To edit the display mask currently being displayed. Available when **<Display Mask:>** is highlighted on **Parameters** page.

SHIFT ABOUT (F5)

To display information about the application program name, the version number, the date of the version, the copyright and the article number.

Description of fields

Field	Option	Description
<Display Mask:>	Choicelist	The user defined display mask is shown in REFPLANE Measure Points to Plane .
<Max ±Δd for Plane Def.:>	User input	The maximum perpendicular deviation of a point from the calculated plane.
<Face Scan:>	User input	The maximum perpendicular deviation of a measured point in face scan from defined plane. Scanned points outside the defined limit are not stored.
<Display:>	All Points Points in Slice	This parameter defines the points displayed in the Plot and Map pages of the Reference Plane application program in the plan view. Displays all points. Displays points within the defined <Slice Width:> .

Field	Option	Description
<Slice Width:>	User input	Available for <Display: Points in Slice>. This distance is applied to both sides of the plane. If lines and areas are to be displayed in a particular Map page, then parts of lines and areas falling within the defined slice are also displayed.

Next step

PAGE (F6) changes to the **Logfile** page. Refer to "1.2 Configuration of a Logfile".

9.3 Managing Reference Planes

Description

Overview

- A reference plane is used to measure points relative to the plane or to scan the plane.

Measure to plane

- **<Task: Measure To Plane>** in **REFPLANE Choose Task & Reference Plane**.
- Reference planes can be created, edited, stored and deleted in the active job.
- The reference planes can be recalled for later use.
- The plane can be shifted through a point or a defined offset.

Scan a plane

- **<Task: Scan>** in **REFPLANE Choose Task & Reference Plane**.

Access step-by-step

Step	Description
1.	PROG. The PROG key opens the TPS1200+/TS30/TM30 Programs menu.
2.	Select Reference Plane and press CONT (F1) .
3.	Press CONT (F1) to access REFPLANE Reference Plane Begin .
4.	Press CONT (F1) to access REFPLANE Choose Task & Reference Plane .

REFPLANE Choose Task & Reference Plane

Description of fields

Field	Option	Description
<Task:>	Measure to Plane	The coordinates of measured points are calculated relative to the reference plane.
<Plane to Use:>	Create New Plane	Defines a new reference plane.
	Select From Job	Reference plane is selected in <Ref Plane:> .
<Ref Plane:>	Choicelist	Available for <Plane to Use: Select From Job> . The reference plane to be used.
<No. of Points:>	Output	Available for <Plane to Use: Select From Job> . Number of points used for plane definition for the plane shown in the <Ref Plane:> .
<Std Deviation:>	Output	Standard deviation of used points for plane definition. ----- is displayed for less than four points.
<Max Δd:>	Output	Maximum distance between a point and the calculated plane. ----- is displayed for less than four points.
<Offset:>	Output	The offset method used as defined in REFPLANE XX Reference Plane, Offset page.

Field	Option	Description
<Origin:>	Output	The origin method used as defined in REFPLANE XX Reference Plane, Origin page.

Next step

IF	THEN
a new plane is to be created	<ul style="list-style-type: none"> CONT (F1) accesses REFPLANE New Reference Plane, General page. Refer to paragraph " REFPLANE New Reference Plane, General page".
a plane is to be edited	<ul style="list-style-type: none"> <Plane to Use: Select From Job>. Highlight <Ref Plane:>. ENTER to access REFPLANE Manage Reference Planes. EDIT (F3) to access REFPLANE Edit Reference Plane, General page. Refer to "REFPLANE New Reference Plane, General page". Editing a reference plane is similar to creating a new reference plane. For simplicity, only REFPLANE New Reference Plane is explained.
points are to be measured to a plane	<ul style="list-style-type: none"> CONT (F1) accesses REFPLANE Measure Points to Plane, Reference page. Refer to "9.4 Measuring Points to a Reference Plane".
a plane is to be scanned	<ul style="list-style-type: none"> CONT (F1) accesses REFPLANE Define Scanning Parameters. Refer to "9.5 Scanning a Plane".

REFPLANE New Reference Plane, General page

11:38 REFPLANE + IR STD I Bluetooth USB Printer Help

New Reference Plane

General Points Origin Offset Plnt

Ref Plane : refplane

No. of Points: 0

Std Deviation: ---- m

Max Δd : ---- m

STORE (F1)

To compute and store the reference plane.

Q2 a 1

STORE PAGE

Description of fields

Field	Option	Description
<Ref Plane:>	User input	The ID of the new reference plane.
<No. of Points:>	Output	Number of points used for plane definition.

Field	Option	Description
<Std Deviation:>	Output	Standard deviation of used points for plane definition. ----- is displayed unless more than four points are used to define the plane.
<Max Δd:>	Output	Maximum distance between measured point and defined plane. ----- is displayed unless more than four points are used to define the plane.

Next step

PAGE (F6) changes to **REFPLANE New Reference Plane, Points** page.

REFPLANE New Reference Plane, Points page

Point ID	Δd (m)	Use
0003	0.000	Yes
0002	0.000	Yes
0001	0.000	Yes

STORE (F1)

To compute and store the reference plane.

ADD (F2)

To add points from **REFPLANE Data: Job Name** to define the reference plane.

USE (F3)

To change between **Yes** and **No** for the highlighted point.

DEL (F4)

To remove the highlighted point from the list.

SURVY (F5)

To measure a point to be used for the plane.

SHIFT ORIGN (F4)

To use the highlighted point as the origin of the plane.


Description of columns

Column	Description
Δd(m)	Displays the perpendicular distance of the point from the definition of the plane.
*	Shown to the right of the point for a point which will be used as origin of the plane.
‡	Shown to the left of the point if the point is outside maximum distance between a point and the calculated plane as defined in REFPLANE Configuration, Parameters page.

Next step

PAGE (F6) changes to **REFPLANE New Reference Plane, Origin** page.

REFPLANE
New Reference
Plane,
Origin page



STORE (F1)

To compute and store the reference plane.

DIREC (F5)

Available for <Point:> being highlighted. To access **REFPLANE Survey: XX**. Measure a point to define the positive plane direction.


Description of fields

Field	Option	Description
<Use As Origin:>	Plane Coords	Point results are additionally stored with X, Y, Z coordinates based on the local plane coordinate system.
	Instrumnt Coords	Points on the plane are transformed into the national coordinate system.
<X-coord:> or <Z-coord:>	User input	Available for <Use As Origin: Plane Coords>. Enter local X or Z coordinate of origin. The origin is defined as the projection of the measured point onto the calculated plane.
<Point:>	Choicelist	Defines the positive direction of the Y axis.

Next step

PAGE (F6) changes to **REFPLANE New Reference Plane, Offset page**.

REFPLANE
New Reference
Plane,
Offset page



STORE (F1)

To compute and store the reference plane.

OFSET (F5)

Available for <Offset PtID:> being highlighted. Measure a point to define the offset point.

Description of fields

Field	Option	Description
<Define Offset:>	Choicelist	An offset can be defined by a point or a distance. The defined plane is shifted along the Y axis by the offset.
<Offset PtID:>	Choicelist	Available for <Define Offset: By Point ID>. Point ID of offset point.
<Offset:>	User input or output	Distance by which to offset the plane along the Y axis.

Next step

PAGE (F6) changes to **REFPLANE New Reference Plane, Plot** page.

REFPLANE New Reference Plane, Plot page

Points displayed depend on the settings in **REFPLANE Configuration, Parameters** page. Points defining the plane are displayed in black, the other points are displayed in grey.

Softkey	Description
SHIFT FACE (F1)	To access the face view of the plane.
SHIFT PLAN (F1)	To access the plan view of the plane.

Next step

STORE (F1) to compute and store the reference plane.

9.4 Measuring Points to a Reference Plane

Access
step-by-step

Step	Description
1.	PROG. The PROG key opens the TPS1200+/TS30/TM30 Programs menu.
2.	Select Reference Plane and press CONT (F1) .
3.	Press CONT (F1) to access REFPLANE Choose Task & Reference Plane .
4.	Select a reference plane.
5.	Press CONT (F1) to access REFPLANE Measure Points to Plane . Select Reference page.

REFPLANE
Measure Points to
Plane,
Reference page

The screenshot shows the 'Measure Points to Plane' screen with the following data:

Point ID :	0005
Reflector Ht :	0.000 m
Offset ΔPer d :	-91.554 m
Offset ΔHt :	91.554 m
Easting :	150.814 m
Northing :	63.556 m
Height :	101.554 m

At the bottom, there are softkey options: ALL, DIST, REC, CMPR, PLANE, and PAGE. The 'PAGE' softkey is currently selected.

ALL (F1)

To measure and store distances and angles.

DIST (F2)

To measure and display distances.

REC (F3)

To record data.

CMPR (F4)

To calculate offsets to previously measured points.

PLANE (F5)

To edit the selected reference plane.

SHIFT INDIV (F5) and **SHIFT RUN (F5)**

To change between entering an individual point ID different to the defined ID template and the running point ID according to the ID template.

Description of fields

Field	Option	Description
<Offset ΔPer d:>	Output	The perpendicular distance between current position and adjusted plane.
<Offset ΔHt:>	Output	The vertical distance between current position and adjusted plane.

Next step

PAGE (F6) changes to **REFPLANE Measure Points to Plane, Map** page.

REFPLANE
Measure Points to
Plane,
Map page

Softkey	Description
SHIFT FACE (F1)	To access the face view of the plane.
SHIFT PLAN (F1)	To access the plan view of the plane.

Next step


PAGE (F6) changes to another page on this screen.

9.5 Scanning a Plane

Description

Face Scan automates the process of measuring a sequence of points along the defined vertical, tilted or horizontal face. The boundaries of the window of interest and the interval values for vertical and horizontal grid are defined by the user. Face scan can be run on motorised instruments with the option "reflectorless EDM" only.

Diagram




Known




- P1 First corner of plane
- P2 Second corner of plane
- d1 <Horizontal:> grid spacing
- d2 <Up Slope:> grid spacing

Unknown

- Grid point coordinates

Scan a new plane step-by-step

Step	Description
1.	PROG. The PROG key opens the TPS1200+/TS30/TM30 Programs menu.
2.	Select Reference Plane and press CONT (F1) .
	Press CONF (F2) to access REFPLANE Configuration .
3.	Press CONT (F1) to access REFPLANE Choose Task & Reference Plane .
4.	Select <Task: Scan>. Select <Plane to Use: Create New Plane>.
5.	Press CONT (F1) to access REFPLANE New Reference Plane
6.	Define new reference plane. Refer to paragraph " REFPLANE New Reference Plane, General page".
7.	Press STORE (F1) to store the new reference plane.
8.	Define the first and second corner of the area to be scanned.
9.	REFPLANE Define Scanning Parameters For tilted and vertical planes: <Horizontal:> Horizontal grid distance. <Up Slope:> Up slope grid distance. <Start Pt ID:> Name of the first point ID. <Pt ID Inc:> The incrementation used for <Start Pt ID:>. No point ID template used.

Step	Description
	<ul style="list-style-type: none"> • For <Start Pt ID: RMS> and <Pt ID Inc: 10> the points are <Point ID: RMS>, <Point ID: RMS10>, <Point ID: RMS20>, ..., <Point ID: RMS100>, ... • For <Start Pt ID: 100> and <Pt ID Inc: 10> the points are <Point ID: 100>, <Point ID: 110>, ..., <Point ID: 200>, <Point ID: 210>, ... • For <Start Pt ID: abcdefghijklmn89> and <Pt ID Inc: 10> the points are <Point ID: abcdefghijklmn99>, point ID incrementing fails. <p><Scan Area:> Size of the area to be scanned.</p> <p><Estimated Pts:> Estimated number of points to be scanned.</p>
10.	START (F1) to access REFPLANE Scanning Status, Scanning page.
	PAUSE (F3) to pause the scanning of points. SCAN (F3) to continue scanning.
	STOP (F1) to stop the scanning of points.
11.	<p>REFPLANE Scanning Status, Scanning page.</p> <p>Status of the scanning is displayed when under process.</p> <p><Pts Scanned:> Number of points being scanned.</p> <p><Pts Remaining:> Number of points remaining to be scanned.</p> <p><Pts Rejected:> Number of skipped points.</p> <p><% Completed:> Percentage of points scanned.</p> <p><Time Left:> Estimated time remaining until scan is finished.</p> <p><Point ID:> Point ID of last stored point.</p>
12.	PAGE (F6) to access REFPLANE Scanning Status, Plot page.
13.	<p>REFPLANE Scanning Status, Plot page.</p> <p>Points currently scanned are displayed in black, previously measured points, lines and areas are displayed in grey.</p>
	SHIFT FACE (F1) to access the face view of the plane. SHIFT PLAN (F1) to access the plan view of the plane.
14.	CONT (F1) to access REFPLANE Choose Task & Reference Plane .


10 Sets of Angles

10.1 Overview

Description

- Sets of Angles:
 - This program (which can include Monitoring as an option) is used to measure multiple sets of directions and distances (optional) to pre-defined target points in one or two faces.
 - The mean direction and mean distance (optional) to each target point, within a set is calculated. The residual for each direction and distance (optional) within a set is also calculated.
 - The reduced average direction and average distance (optional) to each target point, for all active sets is calculated.
- Monitoring:
 - This module can be integrated within the Sets of Angles program.
 - With this module, it is possible to use a timer to enable repeated and auto-mated angle and distances measurements to pre-defined target points at defined intervals.

Diagram



Known:

P1-P5 pre-defined points - E,N,Height (optional)

Unknown:

Mean direction and mean distance to each point, within a set

Residual for each direction and distance, within a set

Reduced average direction and average distance to each point, for all active sets

Measure at least:

Two points and Two sets

ATR - automatic target recognition

ATR search and ATR measurements can be performed to a reflector. After the first measurement to each point is done, the measurements to the other points are auto-mated.

Station setup and station orientation

A station set up and station orientation is required before starting the Sets of Angles program, if oriented grid coordinates are to be recorded.


10.2 Sets of Angles

10.2.1 Accessing Sets of Angles

Access
step-by-step

Step	Description
1.	PROG. The PROG key opens the TPS1200+/TS30/TM30 Programs menu.
2.	Select Sets of Angles and press CONT (F1) .
3.	Press CONT (F1) to access SETS Sets of Angles Menu The menu lists all options to select/measure/calculate sets. Highlight the desired option.
4.	Press CONT (F1) .

SETS
Sets of Angles
Menu



CONT (F1)

To select the highlighted option and to continue with the next screen.

SHIFT CONF (F2)

To configure the program.




10.2.2 Configuring Sets of Angles

Access step-by-step

Step	Description
1.	PROG. The PROG key opens the TPS1200+/TS30/TM30 Programs menu.
2.	Select Sets of Angles and press CONT (F1) .
3.	Press CONF (F2) to access SETS Configuration .

SETS Configuration, Parameters page

The explanations for the softkeys given below are valid for all pages, unless otherwise stated.



CONT (F1)

To accept changes and return to the screen from where this screen was accessed.

DEFLT (F5)

Available for default configuration sets. To recall the default settings.

Description of fields

Field	Option	Description
<MeasMethod:>	A'A''B''B''	Points are measured in face I and face II. point A I - point A II - point B II - point B I ...
	A'A''B''B''	Points are measured in face I and face II. point A I - point A II - point B I - point B II ...
	A'B'A''B''	Points are measured in face I and face II. point A I - point B I... point A II - point B II ...
	A'B''B''A''	Points are measured in face I and face II. point A I - point B I .. point B II - point A II ..
	A'B''C''D''	Points are only measured in face I. point A I - point B I - point C I - point D I ...
<Display Mask:>	Choicelist	The user defined display mask to be shown in SETS Select Points - Survey .
<Stop For:>	Choicelist	To define what action is taken when a message dialog appears during a measurement set.
	All Messages	All message dialogs are displayed as per normal and are closed as defined by the settings in <Time Out:>.

Field	Option	Description
	Tol Exceed Only Never	<p>Only the message dialog relating to the exceeding of tolerances is displayed and is closed as defined by the settings in <Time Out:>.</p> <ul style="list-style-type: none"> • No message dialogs are displayed except for specific warnings. • Specific warnings which affect the instrument and it's ability to continue with the monitoring process will be displayed and will remain on the screen. These include the over-heating of the instrument, low battery levels, unavailable space on the CompactFlash card.
<Time Out:>	No Time Out 1 sec to 60 sec	<p>To define the time delay for the automatic closing of message dialogs during a measurement set. This choicelist is not available when <Stop For: Never>.</p> <p>There is no automatic closure of message dialogs. When a message dialog appears, it is only closed by pressing YES (F4).</p> <p>All message dialogs are automatically closed as defined by these individual time settings.</p>
<Timer Monit.:>	Yes No	<p>This input field is only available when Monitoring is registered through the licence key.</p> <p>Automatic monitoring of target points is activated.</p> <p>Automatic monitoring of target points is not activated. The Sets of Angles application will apply.</p>

Next step

PAGE (F6) changes to the **Tolerances** page.

**SETS
Configuration,
Tolerances page**

Description of fields

Field	Option	Description
<Use Tolerances:>	Yes or No	The entered horizontal, vertical and distance tolerances are checked during the measurements to verify accurate pointing and measurements.
<Hz Tolerance:>, <V Tolerance:> or <Dist Tolerance:>	User input	Tolerance for horizontal, vertical directions and distances.

Next step


PAGE (F6) changes to the **Logfile** page. Refer to "1.2 Configuration of a Logfile".

10.2.3 Managing the Points List

Access

Highlight **Manage Points List** in **SETS Sets of Angles Menu** and **CONT (F1)**.

MANAGE Points List



CONT (F1)

To return to the Sets of Angles Menu.

NEW (F2)

To create a new points list.

EDIT (F3)

To edit an existing points list.

DEL (F4)

To delete an existing points list.

MORE (F5)

To display additional information.


SHIFT HOME (F2)

To move the focus to the top of all the lists.

SHIFT END (F3)

To move the focus to the end of all the lists.

MANAGE New Points List General page




STORE (F1)

To store the new points list.

Description of fields

Field	Option	Description
<Points List:>	User input	The name of the points list.
<Auto Survey:>	Yes or No	To automatically survey the target points (the instrument will automatically turn and measure the target point). For instruments with ATR.
<Auto Sort Pts:>	Yes or No	To automatically sort the target points (the instrument will work in a clockwise direction and find the shortest path to move between the target points).

MANAGE
Select Points
Points page



STORE (F1)

To store the points to the list.

ADD (F2)

To add points from the fixpoint job to the list.

ADD 1 (F3)

To add one point from the fixpoint job to the list.

REMOV (F4)

To remove the highlighted point from the list. The point itself is not deleted.

MORE (F5)

To display additional information.

10.2.4 Measuring the New Points

Access

Highlight **Measure New Points in SETS Sets of Angles Menu** and **CONT (F1)**.

SETS Define Points for Set

20:12
SETS
Define Points for Set
Pts Measured : 0
Point ID : 0004
Reflector Ht : 1.250 m
Auto Survey : Off
Reflector : Leica Circ Prism
Add. Constant : 0.000 m
Q2 a ↑
CONT DONE

CONT (F1)

To measure the entered point.

DONE (F5)

To finish selection of points.

SHIFT GETPT (F4)

To select points stored in the database.

SHIFT INDIV (F5) and SHIFT RUN (F5)

To change between entering an individual point ID different to the defined ID template and the running point ID according to the ID template.

Description of fields

Field	Option	Description
<Auto Survey:>	On or Off	For instruments with ATR and <Auto Survey: On> ATR search and ATR measurements are done to specified targets in additional sets.

Next step

CONT (F1) accesses **SETS Select Points - Survey**.

SETS Select Points - Survey, Sets page

18:33
SETS
Select Points - Survey
Sets Map
Point ID : 0001
Reflector Ht : 1.250 m
Hz : 200.0004 g
V : 300.0002 g
Slope Dist : 75.015 m
ΔHz : -0.0001 g
ΔV : -0.0004 g
ΔSlope : 0.000 m
Q2 a ↑
ALL DIST REC POSIT PAGE

ALL (F1)

To measure and store angles and distance.

DIST (F2)

To measure a distance.

REC (F3)

To store data.

POSIT (F5)

To position the instrument to the selected target point.

Description of fields

The fields are the same as in **SETS Set XX of XX, Pt XX of XX**.

Next step

ALL (F1) measures, stores and returns to **SETS Define Points for Set**.



If <Auto Survey: On>, instruments with ATR automatically measure the selected points in the second face of the first set.

10.2.5 Measuring the Sets

Access

Highlight **Measure Sets** in **SETS Sets of Angles Menu** and **CONT (F1)**.

SETS

Measure Sets

Description of fields

Field	Option	Description
<No. of Sets:>	User input	The number of sets to be measured with the selected points. There is a maximum of 99 sets allowed.
<No. of Pts:>	Output	The number of target points.

Next step

CONT (F1) measures further sets of the defined points.

SETS

Set XX of XX, Pt XX of XX, Sets page

The functionality of this screen is very similar to **SETS Select Points - Survey, Sets** page. Differences between the two screens are outlined below. Refer to "10.2.4 Measuring the New Points" for information on all other softkeys and fields.

Field	Value	Unit
Point ID	0001	
Reflector Ht	1.250	m
Hz	0.0005	g
V	100.0008	g
Slope Dist	75.015	m
ΔHz	-0.0002	y
ΔV	-0.0002	g
ΔSlope	0.000	m

SKIP (F4)

To skip measuring the displayed point and continue with the next point.

DONE (F5)

To end the sets of angles measurements.

SHIFT POSIT (F5)

To position the instrument to the selected target point.

Description of fields

Field	Option	Description
<Δ Hz:>, <Δ V:> and <Δ Slope:>	Output	Difference between the current horizontal/vertical angle or distance and the horizontal/vertical angle or distance to this target when selected.

Next step

ALL (F1) measures further sets of the selected points.



Motorised instruments point automatically in the direction of the targets. Instruments with ATR and **<Auto Survey: On>** measure the targets automatically.



For the calculation two entire sets must be measured. Horizontal and vertical angles and distances can be calculated individually.

10.2.6 Calculating Angles and Distances in Two Faces

Description

For two and more sets measured with angles and distances in two faces calculations can be done for angles and distances. For sets measured in one face the results can be viewed no calculations are done. Refer to "10.2.8 Viewing Angle and Distance Results in One Face" for more information.


Access

Highlight **Calculate Angles** in **SETS Sets of Angles Menu** and **CONT (F1)**.

SETS

Calculate XX, XX Set page

The softkeys are the same for vertical angles, horizontal angles and for distances.



CONT (F1)

To access **SETS Sets of Angles Menu**.

MORE (F5)

To view results of calculation.



Description of fields

Field	Option	Description
<Points Active:> and <Sets Active:>	Output	Number of active points/sets which are set to On in the Use column and used for calculation.
< σ Singl Direc:> or < σ Singl Dist:>	Output	Standard deviation of a single horizontal/vertical direction or single distance.
< σ Avg Direc:> or < σ Avg Dist:>	Output	Standard deviation of the average horizontal/vertical direction or average distance.

Next step

MORE (F5) accesses **SETS View XX Results**.

10.2.7 Viewing Angle and Distance Results in Two Faces

Access

Press **MORE (F5)** in **SETS Calculate Angles** or **SETS Calculate Distances**.

SETS

View XX Results

Set	Use	Hz Σr	V Σv
1	Yes	-0.0000g	0.0000g
2	Yes	0.0000g	-0.0000g

CONT (F1)

To access **SETS Calculate XX**.

EDIT (F3)

To view residuals in the highlighted set.

USE (F4)

To set **Yes** or **No** in the **Use** column for the highlighted set.

Description of columns

Column	Description
Set	Displays the numbers of all sets measured.
Use	For Yes : The selected set is used for calculations. For No : The selected set is not used for calculations.
Hz Σr	Shows the calculated Σr in Hz of the selected set. Σr is the sum of the difference between the reduced average direction and each sets directions. For sets not used for calculation ----- is shown.
V Σr	Shows the calculated Σr in V of the selected set. Σr is the sum of the difference between the average V angles and each sets V angles. For sets not used for calculation ----- is shown.

Next step

CONT (F1) accesses **SETS Calculate XX**.

SETS

View Residuals in Set XX

Print ID	Use	Residual Hz	Residual V
0001	Yes	0.0000g	0.0001g
0002	Yes	0.0000g	-0.0000g
0003	Yes	-0.0000g	0.0000g

CONT (F1)

To access **SETS View XX Results**.

USE (F4)

To set **Yes** or **No** in the **Use** column for the highlighted point.

MORE (F5)

To view additional information.

Description of columns when calculating angles

Column	Description
Point ID	Point ID of the measured points in the order they were defined and measured in SETS Measure New Points truncated to six digits from the right.
Use	<ul style="list-style-type: none">For Yes: The point is used for calculations in all sets.For No: The point is not used for calculations in all sets.
Resdl Hz	Residual in the Hz value of the point within the single set.
Resdl V	Residual in the V value of the point within the single set.
Avg Hz	Reduced Average Hz value of the point in all active sets.
Avg V	Average V value of the point in all active sets.
Mean Hz	Mean Hz value of the point within the single set.
Mean V	Mean V value of the point within the single set.

Description of columns when calculating distances

Column	Description
Point ID	Point ID of the measured points in the order they were defined and measured in SETS Measure New Points truncated to six digits from the right.
Use	<ul style="list-style-type: none">For Yes: The point is used for calculations in all sets.For No: The point is not used for calculations in all sets.
Resdl SD	Residual in the distance value of the point within the single set.
Avg SD	Average distance value of the point in all active sets.
Mean SD	Mean distance value of the point within the single set.

Next step

CONT (F1) accesses **SETS View XX Results**.

10.2.8 Viewing Angle and Distance Results in One Face

Access

Highlight **Calculate XX** in **SETS Sets of Angles Menu** and press **CONT (F1)**.

SETS
View Single Face
Results

Point ID	σ Hz	Avg Hz
501	0.0001g	0.0003g
502	0.0001g	100.0004g
503	0.0002g	200.0002g
504	0.0003g	300.0004g

CONT (F1)

To access **SETS Sets of Angles Menu**.

MORE (F5)

To view additional columns.

Description of columns

Column	Description
Point ID	Point ID of the measured points in the order they were defined and measured in SETS Measure New Points truncated to six digits from the right.
σ Hz, σ V and σ Dist	Standard deviation of all Hz, V readings or distance measurements to the current point.
Mean Hz, Mean V and Mean SD	Mean value of all Hz, V readings or distance measurements to the current point.

Next step

CONT (F1) accesses **SETS Sets of Angles Menu**

10.3 Monitoring

- Description**
- Monitoring is a module integrated within the Sets of Angles application program.
 - Monitoring uses a timer to enable repeated and automated angle and distances measurements to pre-defined target points at defined intervals. The ability to configure the handling of message dialogs during measurement sets is also enabled.
-
- Important aspects**
- For monitoring, instruments must be motorised.
-
- Access**
- Monitoring is licence protected and is only activated through a licence key. The licence key can be entered manually or loaded from the CompactFlash card.
 - Refer to "10.2.1 Accessing Sets of Angles" for details on accessing Monitoring.
-
- Monitoring preparation**
- This step-by-step description is an example on preparing a set for monitoring.
 - Refer to "10.2 Sets of Angles" for a complete description of the Sets of Angles program.

Step	Description
1.	PROG. The PROG key opens the TPS1200+/TS30/TM30 Programs menu.
2.	Select Sets of Angles and press CONT (F1) .
3.	Set station coordinates and station orientation - SETUP (F3) .
4.	Configure Sets of Angles for monitoring - CONF (F2) . For the Parameters page: <MeasMethod: A'B'B''A''> (for example purposes only). <Display Mask: None> (for example purposes only). <Stop For: All Messages> (for example purposes only). <Time Out: 10 secs> (for example purposes only). <Timer Monit.: Yes> (this option must be selected for monitoring). This will enable the access to the SETS Define Monitoring Timer screen.
5.	Press CONT (F1) to access the SETS Sets of Angles Menu screen.
6.	Select Measure New Points .
7.	Press CONT (F1) to access the SETS Define Points for Set screen
8.	Enter details of the target point as required. For each target point, ensure that <Auto Survey: On> is set. This will enable the automated measurement and recording of the target point in the other face and the automated measurement and recording of all target points during monitoring.
9.	Press CONT (F1) to access the SETS Select Points - Survey screen.
10.	Measure and record the measurement to the target point as required.
11.	Continue with steps 7/8/9 until all target points for the first measurement set have been measured and recorded.

Step	Description
12.	Press DONE (F5) to complete the selection of the target points for the first measurement set in one face and to begin the measurement of the target points in the other face. On completion the SETS Sets of Angles Menu screen will be accessed.
13.	Select Measure Sets .
14.	Press CONT (F1) to access the SETS Define Monitoring Timer screen. Refer to "SETS Define Monitoring Timer" for information about the screen.

SETS Define Monitoring Timer

Description

This screen enables the entry of dates, times, intervals and the handling of message dialogs during a measurement set. When all required information is entered press **CONT (F1)** to begin the monitoring process.

16:49
SETS
Define Monitoring Timer

Begin Date : 23.11.05
Begin Time : 07:00:00
End Date : 23.11.05
End Time : 09:30:00

Interval : 000:30:00

Stop For : All Messages
Time Out : 1 sec

CONT

CONT (F1)

To begin the monitoring process.

Description of fields

- The format of all date and time input fields is defined in **CONFIGURE Units and Formats**.
- The format of the interval input field is hh:mm:ss.

Field	Option	Description
<Begin Date:>	User Input	Start date for monitoring.
<Begin Time:>	User Input	Start time for monitoring.
<End Date:>	User Input	End date for monitoring.
<End Time:>	User Input	End time for monitoring.
<Interval:>	User Input	The time between the start of each scheduled measurement set.
<Stop For:>	Choicelist	<ul style="list-style-type: none"> • To define what action is taken when a message dialog appears during a measurement set. • The setting for this input field has already been defined in the configuration. Here, it can be changed if required, before starting the monitoring process.

Field	Option	Description
<Time Out:>	Chocelist	<ul style="list-style-type: none"> To define the time delay for the automatic closing of message dialogs during a measurement set. This choicelist is not available when <Stop For: Never>. The setting for this input field has already been defined in the configuration. Here, it can be changed if required, before starting the monitoring process.

Monitoring interval Description


- The times and dates entered define the time frame for the monitoring.
- The time interval defines the starting time for each measurement set which is from <Begin Time:> to the next <Begin Time:>.

Example

- Data - 3 target points; 4 measure sets; Begin Date: 20.04.2002; Begin Time: 14:00:00; End Date 23.04.2002; End Time 14:00:00; Interval 30 min
- Results - The time taken to measure 4 sets of 3 target points in both faces is 10 minutes. The measurements will start at 14:00:00 on 20.04.2002. At 14:10:00 the first measurement set is complete. The instrument will wait until 14:30:00 for the next scheduled measurement set.

Monitoring in progress

This screen displays a notice that monitoring is in progress.



ABORT (F6)
To stop the monitoring process and return to the **SETS Sets of Angles Menu** screen.



Calculations

Refer to "10.2 Sets of Angles" for information about calculations and the viewing of results.

11 Setup

11.1 Overview

Description



Setup	
<p>The Setup program is used when setting up a TPS station, to determine the TPS station coordinates (with TPS and/or GPS measurements) and setting the TPS orientation.</p>	
Setup with GPS, using SmartPole	Setup with GPS, using SmartStation
<p>SmartPole enables target points to be determined from GPS measurements, which can then be used as control points for the TPS station setup.</p>	<p>SmartStation enables TPS station coordinates (position and height) to be determined from GPS measurements.</p>
	

Setup methods

Setup Method	"Standard" setup type	"On-the-Fly" setup type	Methods for TPS1200+	Methods for SmartPole	Methods for SmartStation
Set Azimuth	✓		✓		✓
Known Backsight Point	✓		✓	✓	✓
Orientation & Height Transfer	✓	✓	✓	✓	✓
Resection	✓	✓	✓	✓	
Resection Helmert	✓	✓	✓	✓	
Local Resection	✓		✓		

- Each method requires different input data and a different number of target points

Setup types

"Standard" setup	"On-the-Fly" setup
<p>This type of setup is the traditional type. The user must always measure all setup points consecutively to complete the setup. The TPS station coordinates and TPS orientation must be set before measuring survey points.</p>	<p>This setup allows the user to measure setup points and survey points as they work or "on the fly". The TPS station coordinates and TPS orientation do not have to be set before measuring survey points. This can be done at anytime during the survey.</p>
<p>Fixpoints=Meas All Now must be set.</p>	<p>Fixpoints=Add Points Later must be set.</p>
 <p>The screenshot shows the 'Station Setup' menu with the following fields: Method: Ori & Ht Transfr; Station Coord: Frm Fixpoint Job; Station ID: ; Instrument Ht: 1.456 m; Fixpoint Job: fixpoint job; Fixpoints: Meas All Now; Current Scale: 1.000000000000. At the bottom, there are buttons for CONT, SCALE, PPM, and Q2 a ↑.</p>	 <p>The screenshot shows the 'Station Setup' menu with the following fields: Method: Ori & Ht Transfr; Station Coord: Frm Fixpoint Job; Station ID: ; Instrument Ht: 1.456 m; Fixpoint Job: fixpoint job; Fixpoints: Add Points Later; Current Scale: 1.000000000000. At the bottom, there are buttons for CONT, SCALE, PPM, and Q2 a ↑.</p>
	<p>This setup can only be used when measuring survey points. When staking out points, the TPS station coordinates and TPS orientation must first be set.</p>

Incomplete setups

- For a "Standard" setup, the user must always measure all setup points consecutively to complete the setup. This type of setup is always regarded as a complete setup.
- For an "On-the-Fly" setup, the setup points can be measured together with the survey points. It is not necessary to complete the setup before measuring survey points. In this state, this type of setup is regarded as an incomplete setup.

An incomplete setup can be accessed in the following ways:

1.	When pressing SETUP (F3) in the Begin screen of a program (other than Setup), a message is displayed to notify that the setup is incomplete. It is then possible to: a) start Setup and continue to measure additional fixpoints, OK (F4) b) start Setup and create a new station setup, or NEW (F2) c) leave Setup and continue with the existing program ABORT (F6)
2.	When pressing CONT (F1) in the Begin screen of any program, a message is displayed to notify that the setup is incomplete. It is then possible to: a) continue with the existing program*, or CONT (F1) b) start Setup and create a new station setup, or NEW (F3) c) start Setup and continue to measure additional fixpoints. SETUP (F6)
3.	Assign the function FUNC Continue Open Setup to the User Menu or Hot Key

* The Setup Reminder screen (if it has been set) is not displayed in this instance. In the Survey program, Setup can be accessed by **SETUP (F5)**.

Point properties

TPS Points

The properties stored with a TPS point are:

Type	Station	Target
Class	REF	MEAS or NONE
Sub class	TPS	TPS
Source	Setup (setup method)	Setup (setup method)
Instrument	TPS	TPS

GPS points (only applicable when using SmartPole or SmartStation)

The properties stored with a GPS point are:

Type	Station	Station
Class	MEAS	NAV
Sub class	GPS Fixed / GPS Code only	GPS Code only
Source	Setup (setup method)	Setup (setup method)
Instrument	GPS	GPS

11.2 Configuring Setup

Access step-by-step

Step	Description
1.	PROG. The PROG key opens the TPS1200+/TS30/TM30 Programs menu.
2.	Select Setup and press CONT (F1) .
3.	Press CONF (F2) to access SETUP Configuration .

SETUP Configuration, General page

Description of fields

Field	Option	Description
<Setup Reminder:>	Choicelist Yes No	Current instrument setup details can be displayed to remind the user to either keep the current instrument setup or to create a new instrument setup. Refer to "11.5 Setup Reminder" for details. Yes Whenever CONT (F1) is pressed in a Begin screen, the current setup information is displayed. No Whenever CONT (F1) is pressed in a Begin screen, the current setup information is not displayed and the program continues as normal.
<Two Faces:>	Yes or No	Defines if the instrument measures the second face automatically after storing the first or not.
<Use Scale:>	Yes or No	The appearance of the SETUP Results XX screen differs with this setting. The ppm value may be set in the system as the geometric ppm value or not.
<Auto Position:>	2D, 3D or Off	Instrument positions horizontally, horizontally and vertically or not at all to the point.
<Display AR:>	Choicelist Yes	To set the direction to the backsight point to zero. Yes Sets <AR: 0.0000> towards the backsight point. If set in the current display mask, <AR:> displays the horizontal angle difference between the backsight point and the measured point. This has no effect on the set orientation.

Field	Option	Description
	No	Does not set a value for <AR:>. If the display mask is configured to display <AR:> in the Survey application program, the value is identical to the azimuth. If <Set Angle Right: Yes> and more than one backsight point is used, the behaviour is as for <Set Angle Right: No>.
<Antenna:>	Choicelist	Applicable when the SmartAntenna is connected. Opening the choicelist accesses MANAGE Antennas . Refer to "6.2 Management of Antennas" for further information on antennas. The default antenna is the Smart-Antenna.

Next step

PAGE (F6) changes to the **Parameters** page.

SETUP Configuration, Parameters page

Description of fields

Field	Option	Description
When Method=Resections, Ori & Ht Transfer, the following fields apply:		
<Hz Acc Ori:>	User input	For Resection or Orientation and Height Transfer. The standard deviation limit of the orientation.
<Pos Acc Target:>	User input	For Resection or Orientation and Height Transfer. The position accuracy of the target point.
<Ht Acc Target:>	User input	For Resection or Orientation and Height Transfer. The height accuracy of the target point.
When Method=Local Resection, the following fields apply:		
<Define:>	Choicelist	For Local Resection. To define the positive North or positive East axis.
	Northing Axis	The second point measured defines the direction of the positive North axis.
	Easting Axis	The second point measured defines the direction of the positive East axis.
When Method=Resection Helmert, the following fields apply:		
<Weighting:>	1/Distance or 1/Distance²	To change the distance weighting that is used in the calculation of the station height in the resection.

Next step

PAGE (F6) changes to **Checks** page.

SETUP
Configuration
Checks page**Description of fields**

Field	Option	Description
When Method=Known BS Point, the following fields apply:		
<Pos Check:>	Yes or No	Allows a check to be made on the horizontal coordinate difference between the existing and the measured known backsight point.
<Pos Limit:>	User input	Available for <Pos Check: Yes> . Sets the maximum horizontal coordinate difference accepted in the position check.
<Height Check:>	Yes or No	Allows a check to be made on the vertical difference between the existing and the measured known backsight point.
<Height Limit:>	User input	Available for <Height Check: Yes> . Sets the maximum vertical difference accepted in the height check.

Next step

PAGE (F6) changes to **Logfile** page.

Refer to "1.2 Configuration of a Logfile".

11.3 Setup with SmartStation

Access
step-by-step

Step	Description
1.	PROG. The PROG key opens the TPS1200+/TS30/TM30 Programs menu.
2.	Select Setup and press CONT (F1) .
3.	CONT (F1) to access the SETUP Station Setup .
4.	SETUP Station Setup Begin. Check the settings and ensure that a coordinate system other than <None> or WGS84 is selected and attached to the active job.
5.	CONT (F1) to access the SETUP Station Setup screen.
6.	SETUP Station Setup. <ul style="list-style-type: none"> • Choose one of the following setup methods: <ul style="list-style-type: none"> • <Method: Set Azimuth> or • <Method: Known BS Point> or • <Method: Ori & Ht Transfr>. • These are the only methods applicable for a setup with SmartStation.
7.	<Station Coord: From GPS>. Ensure that the SmartAntenna is connected and the interface is set. <Station ID:> Enter the instrument station. <Instrument Ht:> Enter the height of the instrument station.
8.	CONT (F1) to access SETUP New Station Point . If a coordinate system has not been selected: <ul style="list-style-type: none"> • LOCAL (F5) to access SETUP SmartStation One Pt OneStep to enter local coordinates for the setup point and a name for the local coordinate system. • CSYS (F6) to access SETUP Coordinate Systems to select an existing coordinate system. In this screen the creating and editing of coordinate systems is also available.
9.	SETUP New Station Point OCUPY (F1) To start the point occupation. STOP (F1) To end the point occupation. STORE (F1) To store the point information.

SETUP
New Station Point


Overview of the screen

Important features about this screen:

- Upon entering this screen SmartStation switches into GPS mode.
- The display mask for this screen is fixed and is not configurable.
- A coordinate system is required and should be attached to the active job.
- SmartAntenna is automatically turned on upon entry to the screen.
- Some of the screen icons change from TPS specific to GPS specific.

- The occupation/storing behaviour is dependent on the configuration settings.

Screen display



Station ID : 2
Instrument Ht: 1.567 m
3D CQ : 0.010 m
Time at Point: 00:00:09
RTK Positions: 10



Refer to the description of softkeys for details on softkeys and their functionality.

Description of screen softkeys

Key	Description
OCUPY (F1)	To start logging of static observations. The position mode icon changes to the static icon. (F1) changes to STOP .
STOP (F1)	To end logging of static observations when enough data is collected. When <Auto STOP: Yes> in CONFIGURE Point Occupation Settings , logging of static observations ends automatically as defined by the stop criteria. The position mode icon changes to the moving icon. (F1) changes to STORE .
STORE (F1)	To store the measured point. When <Auto STORE: Yes> in CONFIGURE Point Occupation Settings , the measured point is stored automatically. (F1) changes to OCUPY . It may happen that a point with the same point ID exists in the job. If the codes and/or attribute values of the new and the existing point do not match, a screen opens where they can be corrected.
SHIFT CONEC (F3), SHIFT DISCO (F3)	To dial the number of the reference station configured in the active configuration set and to hang up immediately after the survey is completed. Available for GPS real-time devices of type digital cellular phone or modem. Available for <Auto CONEC: No> in CONFIGURE GSM Connection .
SHIFT INIT (F4)	To select an initialisation method and to force a new initialisation. Available for configuration sets allowing phase fixed solutions.

Description of fields

Field	Option	Description
<Station ID:>	Output	Station ID as entered in SETUP Station Setup .

Field	Option	Description
<Instrument Ht:>	Output	Instrument height as entered in SETUP Station Setup . SmartAntenna offset is automatically added but not displayed.
<3D CQ:>	Output	The current 3D coordinate quality of the computed position.
<Time at Point:>	Output	The time from when the point is occupied until point occupation is stopped.
<RTK Positions:>	Output	The number of GPS real-time positions recorded over the period of point occupation.
<Msd PP Obs:>	Output	The number of static observations recorded over the period of point occupation. Available only when the recording of static observations is configured.

11.4 Setup with SmartPole

Access step-by-step

Step	Description
1.	Access SETUP Station Setup Begin .
2.	SETUP Station Setup Begin Check the settings and ensure that a coordinate system other than <None> or WGS84 is selected and attached to the active job.
3.	CONT (F1) to access SETUP Station Setup .
4.	SETUP Station Setup Choose one of the following setup methods: <Method: Known BS Point> or <Method: Ori & Ht Transfr> , or <Method: Resection> or <Method: Resection Helmert> . These are the only methods applicable for a setup with SmartPole.
5.	<Station Coord:> If available, select the source for the instrument station coordinates. <Station ID:> Enter/Select the instrument station <Instrument Ht:> Enter the height of the instrument station <Fixpoint Job:> Select the fixpoint job of the control/target points
6.	<Fixpoints:> If available, select the method for measuring the control/target points. Select Meas All Now if a "Standard" setup is required. Select Add Points Later if an "On-the-Fly" setup is required.
	Steps 7. and 8. do not relate to <Method: Known BS Point> .
7.	CONT (F1) to access SETUP Measure Target 1 .
8.	SETUP Measure Target 1 Refer to "11.8 Setup Method - Orientation & Height Transfer" for details on fields and keys.
9.	GPS (F4) to access SETUP Survey Survey .
10.	SETUP Survey Survey This is the GPS Survey screen within the Setup program. The target points can be measured with GPS, which can then be used as fixpoints for the station setup. <ul style="list-style-type: none"> • OCUPY (F1) To start the point occupation. • STOP (F1) To end the point occupation. • STORE (F1) To store the point information.

SETUP Survey Survey

Overview of the screen

Important features about this screen:

- Upon entering **SETUP Survey Survey** SmartPole switches into GPS mode.

- The display mask for **SETUP Survey Survey** is configurable.
- A coordinate system is required and should be attached to the active job.
- SmartAntenna is automatically turned on upon entry to the screen.
- Some of the screen icons change from TPS specific to GPS specific.
- The occupation/storing behaviour is dependent on the configuration settings.

Screen display



Antenna Ht : 2.000 m

RTK Positions: 5
3D CQ : 0.007 m



Refer to the description of softkeys for details on softkeys and their functionality.

Description of screen softkeys

Key	Description
OCUPY (F1)	Refer to "11.3 Setup with SmartStation".
STOP (F1)	Refer to "11.3 Setup with SmartStation".
STORE (F1)	Refer to "11.3 Setup with SmartStation".
NEAR (F2)	To find the nearest reference station with the connected device. Coordinates of these stations must be known.
SHIFT CONEC (F3), SHIFT DISCO (F3)	To find the nearest reference station with the connected device. Coordinates of these stations must be known.
SHIFT INIT (F4)	Refer to "11.3 Setup with SmartStation".

Description of fields

Field	Option	Description
<Indiv Pt ID:>	User input	An Individual Pt ID is used by default. This enables the user to give the target point a different point ID.
<Antenna Ht:>	User input	The antenna height.
<RTK Positions:>	Output	The number of GPS real-time positions recorded over the period of point occupation.
<3D CQ:>	Output	The current 3D coordinate quality of the computed position.

Field	Option	Description
<Msd PP Obs:>	Output	The number of static observations recorded over the period of point occupation. Available only when the recording of static observations is configured.

Next steps

- **STORE (F1)** to store the point and then return to SETUP Measure Target. Refer to "11.8 Setup Method - Orientation & Height Transfer" for details on all fields and keys.
 - **ALL (F1)** to measure and store this same point with the TPS station. (The GPS target point which was previously stored, is automatically suggested as the target point to measure with the TPS station. This is then the first target point for the station setup).
 - **GPS (F4)** to measure additional target points with GPS.
 - **DONE (F5)** to temporarily exit the Setup program. (This is applicable when Add Points Later is set. In this state, this type of setup is regarded as an incomplete setup. The setup can be continued and completed at a later time). This key is replaced by CALC (F5) when sufficient data is available.
 - **CALC (F5)** to compute the setup results (This is applicable when at least two target points have been measured and stored).
 - **SET (F1)** to set the TPS station and TPS orientation in the SETUP Results screen. This setup is now complete. It is still possible to add additional points to the setup to improve the setup results. Refer to "11.11 Setup Results - Least Square and Robust Calculation" for details.
-

11.5 Setup Reminder

Description

- When activated, the setup reminder function displays a screen which enables the user to check the current station setup details before proceeding with the survey. When this screen appears, three options are available to the user:
 - 1. To keep the current station setup and proceed with the survey.
 - 2. To create a new station setup.
 - 3. To check the backsight point.
- The setup reminder function is available to every application program, except:
 - Alignment Tool Kit
 - Determine Coordinate System
 - Setup
 - Traverse

Access

When the setup reminder function is activated (refer to "11.2 Configuring Setup"), the current station setup details are displayed whenever **CONT (F1)** is pressed in a **Begin** screen in an application program.



Setup Reminder screen

Reminder for setup method

- Set Azimuth
- Known BS Point

Reminder for setup method

- Ori & Ht Transfer
- Resection
- Resection Helmert
- Local Resection



Description of softkeys

Softkey	Description
CONT (F1)	To continue with the existing program.
NEW (F3)	To start the Setup program and create a new station setup.
CHKPT (F6)	To open the Check Recorded Pt/Backsight Pt screen.

11.6 Setup Method - Set Azimuth

Requirements

- For TPS1200+ the position coordinates of the station point are required. The instrument is set up and oriented to either a known or unknown target point, to which a true or assumed azimuth is set.
- For SmartStation the position coordinates of the station are unknown and are determined with GPS real-time. The instrument is set and oriented to either a known or unknown target point, to which a true or assumed azimuth is set.

Updating

Hz measurements

- A station setup using this setup method is always automatically flagged with an 'update later' attribute. Therefore, all angle measurements taken from that station are always automatically updated.

Access


step-by-step

Step	Description
1.	Press PROG to access the TPS1200+/TS30/TM30 Programs menu.
2.	Select and activate Setup to move to the first screen.
3.	Press CONT (F1) to access SETUP Station Setup .
4.	<p><Method:> Ensure that Set Azimuth is selected.</p> <p><Station Coord:> Select the source for the station coordinates.</p> <p><Station ID:> Enter/Select the instrument station.</p> <p><Instrument Ht:> Enter the height of the instrument station.</p> <p><Fixpoint Job:> Select the fixpoint job of the control/target points.</p>
5.	<p>The geometric scale correction is displayed.</p> <p>The correction displayed depends upon the options chosen in CONFIGURE TPS Corrections, GeoPPM page:</p> <p>if <Calc Scale: Automatically>, <Computd Scale:> is displayed.</p> <p>if <Calc Scale: Manually>, <Current Scale:> is displayed.</p>
6.	Press CONT (F1) to access SETUP Set Stn & Ori - Set Azimuth .

SETUP

Set Stn & Ori - Set Azimuth, Setup page

The explanations for the keys given below are valid for the pages as indicated.



Refer to the description of softkeys for details on softkeys and their functionality.

Description of screen softkeys

Key	Description
SET (F1)	To set the station and orientation and exit the Setup application program.
DIST (F2)	To measure a distance to the point being used to set the azimuth. A distance measurement is NOT required when setting the Station and the Orientation SET (F1) . Checking is NOT performed on the distance measurement when setting the Station and the Orientation SET (F1) .
Az=0 (F4)	Available on the Setup page. To set <Azimuth: 0> and running. This value is not set to the system until SET (F1) is pressed.
HOLD (F5), FREE (F5)	Available on the Setup page and if <ATR: Off> . HOLD (F5) freezes the current <Azimuth:> value, making it possible to set the <Azimuth:> value first, turn the instrument to the desired direction and release the <Azimuth:> value using FREE (F5) .
SHIFT INDIV (F5), SHIFT RUN (F5)	Available on the Setup page. To change between entering an individual backsight point ID different to the defined ID template and the running point ID according to the ID template.

Description of fields

Field	Option	Description
<Backsight ID:>	User input	Point ID of the backsight point according to the point ID template.
<Reflector Ht:>	User input	The default reflector height as defined in the active configuration set is suggested.
<Azimuth:>	User input	The current system azimuth value. If a different azimuth is typed in and ENTER is pressed or if Az=0 (F4) is pressed, this azimuth value is displayed in the field and updated with the telescope movement. The value is not set to the system until SET (F1) is pressed.
<Horiz Dist:>	Output	Press (F2) to measure a distance to the target point being used to set the azimuth.

Next step

PAGE (F6) changes to **BS Info** page.

SETUP
Set Stn & Ori -
Set Azimuth,
BS Info page

Description of fields

Field	Option	Description
<Backsight ID:>	Output	Backsight ID as entered in SETUP Station Setup .
<Code:>	Choicelist	The code for the backsight point.
<Code Desc:>	Output	A short description of the code.

Next step

PAGE (F6) changes to **Stn Info** page.

SETUP
Set Stn & Ori -
Set Azimuth,
Stn Info page

Description of fields

Field	Option	Description
<Station ID:>	Output	Station ID as selected in SETUP Station Setup .
<Instrument Ht:>	User input	The instrument height.
<Code:>	Choicelist	The code for the station.
<Code Desc:>	Output	A short description of the code.
<Stn Easting:>	Output	The easting coordinate for the setup station.
<Stn Northing:>	Output	The northing coordinate for the setup station.
<Stn Height:>	Output	The height of the setup station.
<Current Scale:>	Output	The geometric scale correction is displayed. The correction displayed depends upon the options chosen in CONFIGURE TPS Corrections, GeoPPM page.

Next step

SET (F1) sets the station and sets the orientation.

11.7 Setup Method - Known Backsight Point

Requirements


- For TPS1200+ the position coordinates of the station point are required. The instrument is set up and oriented to a known backsight target.
- For SmartStation the position coordinates of the station are unknown and are determined with GPS real-time. The instrument is set up and oriented to a known backsight target.

Access step-by-step

Step	Description
1.	Press PROG to access the TPS1200+/TS30/TM30 Programs menu.
2.	Select and activate Setup to move to the first screen.
3.	Press CONT (F1) to access SETUP Station Setup .
4.	<p><Method:> Ensure that Known BS Point is selected.</p> <p><Station Coord:> Select the source for the station coordinates.</p> <p><Station ID:> Enter/Select the instrument station.</p> <p><Instrument Ht:> Enter the height of the instrument station.</p> <p><Fixpoint Job:> Select the fixpoint job of the control/target points.</p>
5.	<p>The geometric scale correction is displayed.</p> <p>The correction displayed depends upon the options chosen in CONFIGURE TPS Corrections, GeoPPM page:</p> <p>if <Calc Scale: Automatically>, <Computd Scale:> is displayed.</p> <p>if <Calc Scale: Manually>, <Current Scale:> is displayed.</p>
6.	Press CONT (F1) to access SETUP Set Stn & Ori - Known BS Point .

SETUP Set Stn & Ori - Known BS Point, Setup page

- The functionality of all pages and softkeys is similar to **SETUP Set Stn & Ori - Set Azimuth**. Differences between the two screens are outlined below.
- Refer to "11.6 Setup Method - Set Azimuth" for information on softkeys/fields.



Refer to the description of softkeys for details on softkeys and their functionality.

Description of screen softkeys

Key	Description
SET (F1)	To set the station and orientation and exit the Setup application program.

Key	Description
DIST (F2)	To measure the distance to the backsight point.
GPS (F4)	Available when using SmartPole . To enter the GPS Survey screen (the same screen as for SmartRover) and measure a point with GPS. The antenna height is automatically converted from the reflector height. STORE (F1) to store the point and leave the GPS Survey screen. The point is stored to the <Job:> and copied to the <Fixpoint Job:> , where it can be used as a backsight. ESC or SHIFT QUIT (F6) to leave the GPS Survey screen.
MORE (F5)	The display changes to the measured values of azimuth, horizontal distance and height. Available on the Setup page.

Description of fields

Field	Option	Description
<Backsight ID:>	Choicelist	Backsight point ID. All 3D and 2D points from <Fixpoint Job:> can be selected.
<Reflector Ht:>	User input	The default reflector height as defined in the active configuration set is suggested.
<Calc Azimuth:>	Output	Calculated azimuth from the station to the backsight point.
<Calc HDist:>	Output	Calculated horizontal distance from the station to the backsight point.
<ΔHoriz Dist:> and <ΔHeight:>	Output	The difference between the calculated horizontal distance or coordinate height from station to backsight point and the measured distance or height.
<Horiz Dist:> and <Height:>	Output	Displayed after a distance was measured with DIST (F2) and after MORE (F5) was pressed. The measured horizontal distance to or height of the backsight point.

Next step

SET (F1) sets the station and sets the orientation.

11.8 Setup Method - Orientation & Height Transfer


Requirements

- For TPS1200+/TS30/TM30 the position coordinates of the station point are required. The instrument is set up and oriented to one or more known backsight targets.
- For SmartStation the position coordinates of the station are unknown and are determined with GPS real-time. The instrument is set up and oriented to one or more known backsight targets.
- For TPS1200+/TS30/TM30 and SmartStation the orientation is determined by sighting to one or more known target points (maximum of ten target points). Only angles or both angles and distances may be measured. The height of the station point can also be derived from the target points.

Access step-by-step

Step	Description
1.	Press PROG to access the TPS1200+/TS30/TM30 Programs menu.
2.	Select and activate Setup to move to the first screen.
3.	Press CONT (F1) to access SETUP Station Setup .
4.	<p><Method:> Ensure that Ori & Ht Transfr is selected.</p> <p><Station Coord:> Select the source for the station coordinates.</p> <p><Station ID:> Enter/Select the instrument station.</p> <p><Instrument Ht:> Enter the height of the instrument station.</p> <p><Fixpoint Job:> Select the fixpoint job of the control/target points.</p>
5.	<p><Fixpoints:> Select the method for measuring the control/target points.</p> <p>Select Meas All Now if a "Standard" setup is required.</p> <p>Select Add Points Later if an "On-the-Fly" setup is required.</p>
6.	<p>The geometric scale correction is displayed.</p> <p>The correction displayed depends upon the options chosen in CONFIGURE TPS Corrections, GeoPPM page:</p> <p>if <Calc Scale: Automatically>, <Computd Scale:> is displayed.</p> <p>if <Calc Scale: Manually>, <Current Scale:> is displayed.</p>
7.	Press CONT (F1) to access SETUP Measure Target 1 .

SETUP Measure Target



Refer to the description of softkeys for details on softkeys and their functionality.

Description of screen softkeys

Key	Description
ALL (F1)	To measure and store distances and angles to the backsight points.
DIST (F2)	To measure and display distances.
REC (F3)	To records displayed values to the current job.
GPS (F4)	Available when using SmartPole . To enter the GPS Survey screen (the same screen as for SmartRover) and measure a point with GPS. The antenna height is automatically converted from the reflector height. STORE (F1) to store the point and leave the GPS Survey screen. The point is stored to the <Job:> and copied to the <Fixpoint Job:> , where it can be used as a target for the setup. ESC or SHIFT QUIT (F6) to leave the GPS Survey screen.
CALC (F5)	Available once sufficient data is available for calculation.
DONE (F5)	Available when Fixpoints=Add Points Later. To temporarily exit the Setup program. The station setup will be incomplete but can be continued and completed at a later time. This softkey is replaced by CALC (F5) when sufficient data is available.
SHIFT FIND (F2)	Available once sufficient data is available for calculation. To guide the reflector to the selected target point.
SHIFT POSIT (F4)	Available once sufficient data is available for calculation. To position the instrument to the selected target point.

Description of fields

Field	Option	Description
<Point ID:>	Choicelist	The point ID of the target point to be measured. All points from <Fixpoint Job:> can be selected, except class NONE .
<Reflector Ht:>	User input	The default reflector height as defined in the active configuration set is suggested.
<Azimuth:> and <V:>	Output	The current horizontal or vertical angle.
<Slope Dist:>	Output	The measured slope distance after DIST (F2) was pressed.

Field	Option	Description
< Δ Azimuth:> and < Δ Horiz Dist:>	Output	Displays the difference between the calculated azimuth or horizontal distance and the measured horizontal angle or horizontal distance.
< Δ Height:>	Output	The difference between the given and the measured height of the target point.

Next steps

IF	THEN
more target points are to be measured	ALL (F1) to measure and store distances and angles, or REC (F3) to store the current measurement, or GPS (F4) to measure a point with GPS.
the program is to be temporarily exited	DONE (F5) to temporarily exit the Setup program. The station setup will be incomplete but can be continued and completed at a later time.
sufficient target points were measured	CALC (F5) to calculate the setup.



A maximum of ten target points can be measured and used for the calculation. When the maximum number of points was measured, the **SETUP Results XX** screen is accessed automatically after **ALL (F1)**. In the **SETUP Additional Information** screen measured target points can be deleted and the **SETUP Measure Target XX** screen can be reaccessed to measure new target points.

11.9 Setup Method - Resection/Resection Helmert

Requirements

- For TPS1200+ the coordinates of the station point are unknown. The coordinates and orientation are determined by sighting to one or more known target points (maximum of ten target points). Only angles or both angles and distances may be measured.
- For a resection, least squares or robust calculations are used. For a resection Helmert, Helmert calculations are used.

Access step-by-step

Step	Description
1.	Press PROG to access the TPS1200+/TS30/TM30 Programs menu.
2.	Select and activate Setup to move to the first screen.
3.	Press CONT (F1) to access SETUP Station Setup .
4.	<Method:> Select either Resection or Resection Helmert . <Station ID:> Enter the instrument station. <Instrument Ht:> Enter the height of the instrument station. <Fixpoint Job:> Select the fixpoint job of the control/target points.
5.	<Fixpoints:> Select the method for measuring the control/target points. Select Meas All Now if a "Standard" setup is required. Select Add Points Later if an "On-the-Fly" setup is required.
6.	Press CONT (F1) to access SETUP Measure Target 1 .
7.	SETUP Measure Target
8.	ALL (F1) or REC (F3) or GPS (F4) (to measure a point with GPS).
9.	Refer to "11.8 Setup Method - Orientation & Height Transfer" for details on all fields and keys.

SETUP Measure Target XX

This screen is similar to **SETUP Measure Target XX** for the setup method **<Method: Ori & Ht Transfr>**. Refer to "11.8 Setup Method - Orientation & Height Transfer" for screen information and a description of fields.

11.10 Setup Method - Local Resection

Description

- This setup method is only applicable to TPS1200+/TS30/TM30 and not to SmartStation.
- This method can be used to calculate the two or three-dimensional local coordinates for the instrument station and the orientation of the horizontal circle from distance and angular measurements to two target points.
- The first target point always defines the origin of the local coordinate system. The second target point, in conjunction with the first target point, always defines the local direction of North or East (depending on the configuration settings).

Requirements

Important features:

- all coordinates calculated are local coordinates.
- the first target point always defines the origin of the local coordinate system (North=0, East=0, Height=0 (optional))
- The second target point, in conjunction with the first target point, always defines the local direction of North or East.

Access step-by-step

Step	Description
1.	Press PROG to access the TPS1200+/TS30/TM30 Programs menu.
2.	Select and activate Setup to move to the first screen.
3.	Press CONT (F1) to access SETUP Station Setup .
4.	<p><Method:> Ensure that Local Resection is selected.</p> <p><Station ID:> Enter the instrument station.</p> <p><Instrument Ht:> Enter the height of the instrument station.</p> <p><Stn Ht From:> Select the source for the instrument station height.</p> <p><Station Ht:> Enter the elevation of the instrument station.</p>
5.	Press CONT (F1) to access SETUP Measure Target 1 .

SETUP Measure Target XX

This screen is similar to **SETUP Measure Target XX** for the setup method **<Method: Ori & Ht Transfr>**. Refer to "11.8 Setup Method - Orientation & Height Transfer" for screen information and a description of fields.


11.11 Setup Results - Least Square and Robust Calculation

Access

Press **CALC (F5)** in the **SETUP Measure Target XX** screen.

SETUP Results XX, Stn Coords page

The explanations for the softkeys given below are valid for the **Stn Coord** and **Sigma** page.



Refer to the description of softkeys for details on softkeys and their functionality.

Description of screen softkeys

Key	Description
SET (F1)	To set data selected in <Set:> .
COORD (F2)	To view other coordinate types.
ROBST (F3) or LSQRS (F3)	To display the results for the robust or the least squares calculation method.
INFO (F4)	To display additional information.
DONE (F5)	Available when Fixpoints=Add Points Later. To temporarily exit the Setup program. The station setup will be incomplete but can be continued and completed at a later time.
SURVY (F5)	Available when Fixpoints=Meas All Now. To measure more target points.
SHIFT ELL H (F2) or SHIFT ORTH (F2)	To change between the ellipsoidal and the orthometric height.
SHIFT 3 PAR (F2) or SHIFT 4 PAR (F2)	Switches between a 3 parameter and 4 parameter helmert calculation. The results are immediately updated.
SHIFT OTHER (F5)	Available if two solutions were calculated. Changes between these solutions.

Description of fields

Field	Option	Description
<Station ID:>	User input	Station ID of the current station set up.
<No. of Points:>	Output	Number of points used in calculation.

Field	Option	Description
<Set:>	E, N, Ht, Ori, E, N, Ht E, N, Ori, Ht, Ori, Ht or Ori	The selected options are set and stored in the system. All other values are taken from the current system setup.
<Instrument Ht:>	Output	The current instrument height.
<Stn Easting:> and <Stn Northing:>	Output	Easting/Northing is displayed either from fixpoint job, system or calculated.
<Stn Height:>	Output	The calculated Height is displayed.
<New Azimuth>	Output	New oriented azimuth with running angle as telescope moves.

Next step

PAGE (F6) changes to the **Sigma** page.

**SETUP
Results XX,
Sigma page**

Description of fields

Field	Option	Description
< σ Easting:>, < σ Northing:>, < σ Height:> and < σ Hz Orient.:>	Output	Standard deviation of the calculated station Easting/Northing, Height and orientation.
< Δ Height:>	Output	Delta height, the difference between original and calculated height.
<Calc Scale:> and <Calc ppm:>	Output	Calculated scale factor/ppm from resection or orientation and height transfer.
<Current Scale:>	Output	The current scale calculated from the geometric ppm.

Next step

PAGE (F6) changes to the **Stn Code** page.

**SETUP
Results XX,
Stn Code page**

The functionality of the **Stn Code** page is similar to **MANAGE New Point, Code** page. Refer to "TPS1200+/TS30/TM30 System Field Manual" for information on coding.

Next step

INFO (F4) changes to **SETUP Additional Information, Status** page.

SETUP
Additional Information, Status page

Point ID	Use	ΔHz [g]
0002	3D	0.0000
0003	3D	0.0000
0004	3D	-0.0000
0005	3D	-0.0000

Refer to the description of softkeys for details on softkeys and their functionality.

Description of screen softkeys

Key	Description
RECLC (F1)	To recalculate the station data and update all values.
USE (F3)	To decide whether a target point is to be used in the calculation as 3D point, 2D point or not used. Changes the value in the Use column.
REMOV (F4)	To delete a point from the list of measured target points and exclude it from the Setup calculation.
MORE (F5)	To view more information.
SHIFT SURVY (F5)	To measure more target points.

Description of columns

Column	Description
!	The ! indicates that the delta value of either measured horizontal angle, distance or height exceeds the calculation limit.
Point ID	The point ID of the measured target points.
Use	Indicates if and how a target point is used in the station calculation. Choices are 3D , 2D , 1D and NO .
ΔHz, ΔDist, ΔHeight, ΔEast, ΔNorth	Can be displayed by pressing MORE (F5) . Difference between calculated and measured horizontal angle, distance from station to target points and height for the target points. If a target point does not have coordinates, ---- are displayed. Differences exceeding the defined limit are indicated by a *.

Next steps

RECLC (F1) recalculates the station data.

11.12 Setup Results - Local Resection

Access

Press **ALL (F1)** in the **SETUP Measure Target 2** screen.

SETUP Results, Stn Coords page

17:20
 SETUP
 Results
 Stn Coords | Stn Code | PInt
 Station ID : 0001
 No. of Points : 2
 Set : E, N, Ht, Ori
 Instrument Ht : 1.255 m
 Stn Easting : 53.044 m
 Stn Northing : 53.044 m
 Stn Height : 455.220 m
 New Azimuth : 350.0000 g
 Q2 a ↑
 SET PAGE

SET (F1)

To set data selected in **<Set:>** and to store all setup data and exit the application program.

Description of fields

Field	Option	Description
<Station ID:>	User input	Station ID of the current station set up.
<No. of Points:>	Output	Number of points used in calculation.
<Set:>	Output	The displayed options are set and stored in the system. All other values are taken from the current system setup.
<Instrument Ht:>	Output	The current instrument height.
<Stn Easting:>	Output	The calculated Easting.
<Stn Northing:>	Output	The calculated Northing.
<Stn Height:>	Output	The calculated Height.
<New Azimuth>	Output	New oriented azimuth with running angle as telescope moves.

Next step

PAGE (F6) changes to the **Stn Code** page.

SETUP Results, Stn Code page

The functionality of the **Stn Code** page is similar to **MANAGE New Point, Code** page. Refer to "TPS1200+/TS30/TM30 System Field Manual" for information on coding.

Description of fields

Field	Option	Description
<Point Code:>		The thematical code for the offset point.


Field	Option	Description
	Choicelist	Available for <Themac Codes: With Codelist> . All point codes from the job codelist can be selected. The attributes are shown as output, input or choicelist fields depending on their definition.
	User input	Available for <Themac Codes: Without Codelist> . Codes can be typed in but not selected from a codelist. A check is performed to see if a point code of this name already exists in the job. If so, the according attributes are shown.
<Code Desc:>	Output	Available for <Themac Codes: With Codelist> . The description of the code.
<Attribute n:>	User input	Available for <Themac Codes: Without Codelist> . Up to eight attribute values are available.

Next step

PAGE (F6) changes to the **Stn Plot** page.

12 Stakeout

12.1 Overview

Description	<p>The Stakeout application program is used to place marks in the field at predetermined points. These predetermined points are the points to be staked. The points to be staked may</p> <ul style="list-style-type: none">• have been uploaded to a job on the instrument using LGO.• already exist in a job on the instrument.• have been uploaded from an ASCII file to a job on the instrument using Main Menu: Convert...\Import Data to Job\Import ASCII/GSI.• be typed in.
Stakeout modes	<p>Points can be staked using different modes:</p> <ul style="list-style-type: none">• Polar mode.• Orthogonal to station mode.• Orthogonal from station mode.
	<p>The points to be staked must exist in a job on the active memory device or can be typed in.</p>
Coordinate system	<p>Points cannot be staked if the active coordinate system is different to that in which the points to be staked are stored. For example, the points to be staked are stored in WGS 1984 and the active coordinate system is <None>.</p>
Height source	<p>Heights can be taken into account from:</p> <ul style="list-style-type: none">• the vertical component of a coordinate triplet• a Digital Terrain Model.


12.2 Configuring Stakeout

Access step-by-step

Step	Description
1.	PROG. The PROG key opens the TPS1200+/TS30/TM30 Programs menu.
2.	Select Stakeout and press CONT (F1) .
3.	Press CONF (F2) to access STAKEOUT Configuration .

STAKEOUT Configuration, General page

The explanations for the softkeys given below are valid for all pages, unless otherwise stated.



CONT (F1)

To accept changes and return to the screen from where this screen was accessed.

DMASK (F3)

Available for <Display Mask:> being highlighted on **General** page. To edit the display mask currently being displayed in this field.

Description of fields

Field	Option	Description
<Orientate:>		The reference direction to be used to stakeout points. The stakeout elements and the graphical display shown in the Stakeout application program are based on this selection.
	From Station	The direction of the orientation is from the instrument to the point to be staked.
	To Station	The direction of the orientation is from the point to be staked to the instrument.
	From North	The direction of the orientation is from the North direction to the point to be staked.
	To North	The direction of the orientation is from the point to be staked to the North direction.
	To Arrow	The direction of the orientation is from the current position to the point to be staked. The graphical display shows an arrow pointing in the direction of the point to be staked.

Field	Option	Description
	To Last Point To Point (Stake) To Point (Store) To Line (Stake) To Line (Store)	<p>Timewise the last recorded point. If no points are yet staked, <Orientate: To North> is used for the first point to be staked.</p> <p>A point from <Stakeout Job:> selected in STAKEOUT Stakeout Begin.</p> <p>A point from <Job:> selected in STAKEOUT Stakeout Begin.</p> <p>The direction of the orientation is parallel to a reference line from <Stakeout Job:> selected in STAKEOUT Stakeout Begin. Open the listbox to create, edit or delete a reference line.</p> <p>The direction of the orientation is parallel to a reference line from <Job:> selected in STAKEOUT Stakeout Begin. Open the listbox to create, edit or delete a reference line.</p>
<To:>	Choicelist	<p>Available when</p> <ul style="list-style-type: none"> • <Orientate: To Point(Stake)>, • <Orientate: To Point(Store)>, • <Orientate: To Line(Stake)> and • <Orientate: To Line(Store)>. <p>To select the point or line to be used for orientation.</p>
<Stake Mode:>	Polar Orthogonal	<p>The method of staking out.</p> <p>The direction from the orientation reference, the horizontal distance and the cut/fill is displayed.</p> <p>The distance forwards to/backwards from the point, the distance right/left to the point and the cut/fill is displayed.</p>
<Visual Guides:>	Off Arrows Graphics Arrows & Graphics	<p>Arrows and/or a graphical display in STAKEOUT XX Stakeout. help finding the point to be staked.</p> <p>Neither arrows nor a graphical display are shown.</p> <p>Upon pressing DIST (F2) arrows are shown.</p> <p>A graphical display is shown.</p> <p>Upon pressing DIST (F2) arrows are shown. A graphical display is always shown.</p>

Field	Option	Description
<Message Line:>	Off	For each point which is selected for staking, angle and distance information is momentarily displayed in the message line. No information is displayed in the message line.
	Dist From Stn	The delta Hz angle that the instrument should turn to the point and the distance from the instrument to the point is momentarily displayed in the message line.
	Dist Frm Last Pt	The delta Hz angle that the instrument should turn to the point and the distance from the last staked point is momentarily displayed in the message line.
<Display Mask:>	Choicelist	The user defined display mask to be shown in STAKEOUT XX Stakeout .
<Closest Point:>	Yes	The order of the points suggested for staking out. After staking and storing a point, the next point suggested for staking out is the point closest to the point which was staked.
	No	After staking and storing one point, the next point suggested for staking out is the subsequent one in <Stakeout Job:> .
<Auto Position:>	2D	Instrument positions horizontally to the point to be staked.
	3D	Instrument positions horizontally and vertically to the point to be staked.
	Off	Instrument does not position to the point to be staked.
<Update Angle:>	Yes	Angles are updated with telescope movement after a distance was measured.
	No	Angles and stakeout values are updated after a distance measurement.
<Store Pt ID:>	Same as Stake Pt	The manually occupied staked points are stored with the same point ID's as the points to be staked.
	Prefix	Adds the setting for <Prefix/Suffix:> in front of the original point ID's.
	Suffix	Adds the setting for <Prefix/Suffix:> at the end of the original point ID's.

Field	Option	Description
<Prefix/Suffix:>	User input	Available for <Store Pt ID: Prefix> and <Store Pt ID: Suffix>. The identifier with up to four characters is added in front of or at the end of the ID of the manually occupied staked point.

Next step

PAGE (F6) changes to the **Checks** page.

**STAKEOUT
Configuration,
Checks page**

Description of fields

Field	Option	Description
<Pos Check:>	Yes or No	Allows a check to be made on the horizontal coordinate difference between the staked point and the point to be staked.
<Pos Limit:>	User input	Available for <Pos Check: Yes>. Sets the maximum horizontal coordinate difference accepted in the position check.
<Height Check:>	Yes or No	Allows a check to be made on the vertical difference between the staked point and the point to be staked.
<Height Limit:>	User input	Available for <Height Check: Yes>. Sets the maximum vertical difference accepted in the height check.
<Beep near Pt:>	Yes or No	The instrument beeps when the horizontal radial distance from the current position to the point to be staked is equal to or less than defined in <Dist from Pt:>.
<Dist from Pt:>	User input	Available for <Beep near Pt: Yes>. The horizontal radial distance from the current position to the point to be staked when a beep should be heard.

Next step

PAGE (F6) changes to the **Heights** page.

**STAKEOUT
Configuration,
Heights page**

Description of fields

Field	Option	Description
<Height Offset:>	User input	Allows a constant height offset to be applied to the height of the points or DTM being staked.
<Edit Height:>	Yes	The design height, the height of the point to be staked, is displayed. The value can be changed.

Field	Option	Description
	No	The height of the current position is displayed while staking out. The value cannot be changed.
<Use DTM:>	No	Available if DTM Stakeout has been activated via a licence key. No DTM file is used. The positions and heights of points in the selected <Stakeout Job:> are staked out.
	DTM only	Activates the stakeout of heights without positions. Heights relative to the selected <DTM Job:> are staked out.
	DTM & Stake Job	The positions of points in the selected <Stakeout Job:> are staked out. Heights to be staked out are taken from <DTM Job:> .

Next step


PAGE (F6) changes to the **Logfile** page. Refer to "1.2 Configuration of a Logfile".

12.3 Staking Out

Diagrams


The diagrams show examples for staking out.

Orthogonal mode




- P0 Station
- P1 Current position
- P2 Point to be staked
- d1 <Go FORWARD:> ↓ ↑ or <Go BACK:> ↑ ↓
- d2 <Go RIGHT:> → or <Go LEFT:> ←
- d3 <CUT:> or <FILL:>

Polar mode



- P0 Station
- P1 Current position
- P2 Point to be staked
- a <Δ DISTANCE:>
- b <Δ HZ:>
- c <CUT:> or <FILL:>

DTM Stakeout




- P1 Point to be staked
- d1 <CUT:> or <FILL:>
- d2 Reflector height

Access

Refer to "1.1 Starting an Application Program" to access **STAKEOUT XX Stakeout**.

**STAKEOUT
XX Stakeout,
Stake page**

The pages shown are those from a typical configuration set. An additional page is available when a user defined display mask is used.



ALL (F1)

To measure a distance and store distance and angles.

DIST (F2)

To measure a distance.

REC (F3)

To store angles and distance.

Distance must be measured before.

2FACE (F4)

To take a measurement in Face I and Face II. The point stored is an average of the two measurements. When using instruments fitted with ATR, the point is automatically measured in both faces, the resulting point is stored and the instrument is returned to the first face.

This hotkey is only available for **<EDM Mode: Standard>** and **<EDM Mode: Fast>** and in the Survey, Reference Line and Stakeout programs.

SURVY (F5)

To access Survey application program to measure points independent from the Stakeout application program. To return to Stakeout application program, press **SHIFT QUIT (F6)** or **ESC**.

SHIFT CONF (F2)

To configure stakeout.

SHIFT POS2D (F3)

To position the telescope (X,Y) onto the point to be staked.

SHIFT POS3D (F4)


To position the telescope (X,Y,Z) onto the point to be staked.

SHIFT MSTAK (F5)

To enter angle and distance values to stake out a point.

Description of fields

Field	Option	Description
<Point ID:>	Chocelist	The point ID of the point to be staked.

Field	Option	Description
<Reflector Ht:> or <hr:>	User input	The default reflector height as defined in the active configuration set is suggested.
< Δ Hz:>	Output	<p>The difference of the horizontal angle from the point to be staked to the current position.</p> <p> For <Orientate: From Station> and <Orientate: To Station> the value is calculated and displayed permanently. For other orientation methods, the distance must be measured before the value can be displayed.</p>
<Height:> or <Ht:>	Output	<p>Available for <Edit Height: No> in STAKEOUT Configuration, Heights page.</p> <p>The height of the current position is displayed as orthometric height. If the orthometric height cannot be displayed, the local ellipsoidal height is displayed. If it is not possible to display the local ellipsoidal height, the WGS 1984 height is displayed.</p>
<Design Ht:> or <D Ht:>	User input	<p>Available for <Edit Height: Yes> in STAKEOUT Configuration, Heights page.</p> <p>The design height, which is the height of the point to be staked, is displayed as orthometric height. If the orthometric height cannot be displayed, the local ellipsoidal height is displayed. If it is not possible to display the local ellipsoidal height, the WGS 1984 height is displayed. The value for <Height Offset:> configured in STAKEOUT Configuration, Heights page is not taken into account.</p>

Next step

PAGE (F6) changes to the **Map** page.

12.4 Stakeout Difference Limit Exceeded

Description

If configured a check is made on the horizontal and/or vertical coordinate distance from the staked point to the point to be staked when storing a staked point.

Access

The screen shown below is accessed automatically when the staked point is stored if either of the configured difference limits are exceeded.

STAKEOUT Difference Limit Exceeded

The availability of the fields depends on the configured **<Stake Mode:>** and **<Use DTM:>**. For example for **<Use DTM: DTM only>**, position relevant fields are unavailable.

The limits that have been exceeded are shown in bold and indicated by a ?.

Difference	Limit	Exceeded
Point ID	:	0001
Store ID	:	0001
BACK	:	? 0.868 m
LEFT	:	? 5.211 m
FILL	:	? 0.534 m
2D-Diff	:	? 5.282 m
3D-Diff	:	? 5.309 m

Q2 a ↑

BACK STORE SKIP

BACK (F1)

To return to **STAKEOUT XX Stakeout** without storing the point. Staking out of the same point continues.

STORE (F3)

To accept the coordinate differences, store the point information and return to **STAKEOUT XX Stakeout**.

SKIP (F4)

To return to **STAKEOUT XX Stakeout** without storing the point. According to filter and sort settings the subsequent point in **<Stakeout Job:>** is suggested for staking out.

Description of fields

Field	Option	Description
<Point ID:>	Output	The point ID of the point to be staked.
<Store ID:>	User input	The unique number which is used to store the staked point. Allows a different point ID to be typed in if needed.
<Δ DISTANCE:>	Output	The difference of the horizontal distance to the point to be staked and the current position.
<2D-Diff:>	Output	Displays the horizontal difference from the staked point to the point to be staked.
<3D-Diff:>	Output	Displays the spatial difference from the staked point to the point to be staked.

13 Survey - General


Access step-by-step

Step	Description
1.	PROG. The PROG key opens the TPS1200+/TS30/TM30 Programs menu.
2.	Select Survey and press CONT (F1) .
3.	Press CONT (F1) to access SURVEY Survey .

SURVEY

Survey: Job Name, Survey page

The fields shown are those from a typical configuration set. The screen described consists of the **Survey** page and the **Map** page. The explanations for the softkeys given below are valid for the **Survey** page.



ALL (F1)

To measure and store distances and angles.

STOP (F1)

Stops the distance measurements. (F1) changes back to **ALL**.

DIST (F2)

To measure and display distances.

REC (F3)

To record data.

REMOT (F4)

To measure a remote point.

SETAZ (F5)

To set the horizontal angle.

SETUP (F5) (For Add Points Later)

Available when the setup is incomplete.

TEST (F5)

To access the **SURVEY EDM Test Signal/Frequency** screen. Available for **<EDM Mode: Tracking>** and/or **<Log Auto Pts: Yes>**, after the tracking or logging is started.

SHIFT CONF (F2)

To configure SmartCodes, auto points and remote point measurements.

SHIFT AVGE (F2)

To check the residuals for the averaged point. Available for **<Averaging Mode: Average>** and for more than one measured coordinate triplet recorded for the same point.

SHIFT ABS (F2)

To check the absolute difference between the measurements. Available for **<Averaging Mode: Absolute Diffs>** and for more than one measured coordinate triplet recorded for the same point.

SHIFT 2FACE (F4)

To take a measurement in Face I and Face II. The point stored is an average of the two measurements. When using instruments fitted with ATR, the point is automatically measured in both faces, the resulting point is stored and the instrument is returned to the first face.

This hotkey is only available for **<EDM Mode: Standard>** and **<EDM Mode: Fast>** and in the Survey, Reference Line and Stakeout programs.

SHIFT INDIV (F5) and SHIFT RUN (F5)

To change between entering an individual point ID different to the defined ID template and the running point ID according to the ID template.

Description of fields

Field	Option	Description
<Point ID:>	User input	The identifier for measured points. The configured point ID template is used. The ID can be changed: <ul style="list-style-type: none">To start a new sequence of point ID's overwrite the point ID.For an individual number independent of the ID template SHIFT INDIV (F5). SHIFT RUN (F5) changes back to the next ID from the configured ID template.
<Reflector Ht:>	User input	The last used reflector height is suggested when accessing the Survey application program. An individual reflector height can be typed in.
<Hz:>	Output	The current horizontal angle.
<V:>	Output	The current vertical angle.

Field	Option	Description
<Horiz Dist:>	Output	The horizontal distance after DIST (F2) was pressed. No distance is displayed when accessing the screen and after REC (F3) or ALL (F1) .
<Ht Diff:>	Output	The height difference between station and measured point after DIST (F2) . Displays ----- when accessing the screen and after REC (F3) or ALL (F1) .
<Easting:>	Output	Easting coordinate of the measured point.
<Northing:>	Output	Northing coordinate of the measured point.
<Height:>	Output	Elevation of the measured point.

Next step

PAGE (F6) changes to another page on this screen.

14 Survey - Auto Points

14.1 Overview

Description


- Auto points is used to automatically measure and store points at a specific rate. Additionally, individual auto points can be stored outside the defined rate. Auto points logged between starting and stopping logging of auto points form one chain. A new chain is formed each time logging of auto points is started.
 - Auto points can be collected in the Survey application program. An **Auto** page is visible when logging of auto points is active.
 - Up to two offset points related to one auto point can be logged. The offset points can be both to the left or right and they can be coded independently of each other and of the auto points. Refer to "14.4 Offset Points of Auto Points".
-

14.2 Configuring Auto Points

Access step-by-step

Step	Description
1.	PROG. The PROG key opens the TPS1200+/TS30/TM30 Programs menu.
2.	Select Survey and press CONT (F1) .
3.	Press CONF (F2) to access SURVEY Configuration .

SURVEY Configuration, Auto Points page



CONT (F1)

To accept changes and return to the screen from where this screen was accessed.

DMASK (F3)

Available for **<Log Auto Pts: Yes>**. To configure what is viewed in the **Auto** page in the Survey application program.

Description of fields

Field	Option	Description
<Log Auto Pts:>	Yes or No	Activates or deactivates logging of auto points and all fields on this screen.
<Log By:>	Time	Auto points are stored according to a time interval.
	Distance	The difference in distance from the last stored auto point, which must be reached before the next auto point is measured. The auto point is stored with the next available measured position.
	Height Diff	The height difference from the last stored auto point, which must be reached before the next auto point is measured. The auto point is stored with the next available measured position.
	Dist or Ht	Before the next auto point is measured, either the difference in distance or the difference in height must be reached. The auto point is stored with the next available measured position.
	Stop & Go	An auto point is stored when the position of the reflector does not move more than the distance configured in <Stop Position:> within the <Stop Time:> .

Field	Option	Description
	User Decides	An auto point is stored upon pressing REC (F3) in SURVEY Survey: Job Name, Auto page. In the beginning, the chain to which the auto points should be assigned must be started with START (F1) . In the end, the chain must be closed with STOP (F1) .
<Log Every:>	User input For <Log By: Time> from 0.1s to 60.0s	Available unless <Log By: Dist or Ht> . For <Log By: Distance> and <Log By: Height Diff> . The difference in distance or height before the next auto point is logged. For <Log By: Time> . The time interval before the next auto point is logged.
<Min Distance:>	User input	Available for <Log By: Dist or Ht> . The value for the difference in distance before the next auto point is logged.
<Min Height:>	User input	Available for <Log By: Dist or Ht> . The value for the height difference before the next auto point is logged.
<Stop Position:>	User input	Available for <Log By: Stop & Go> . The maximum distance within which the position is considered stationary.
<Stop Time:>	User input	Available for <Log By: Stop & Go> . The time while the position must be stationary until an auto point is stored.
<EDM Mode:>	Tracking SynchroTrack	Continuous distance measurement with 0.3 s measuring time and 5 mm + 2 ppm accuracy. When the logging of auto points has started, TRK is displayed as an icon. Available only for <EDM Type: Reflector (IR)> . This is the measurement mode for the interpolation of angle measurements in IR LOCK Tracking mode. In difference to normal IR LOCK Tracking mode, where angle measurements are only assigned to certain distance measurements, SynchroTrack will perform a linear interpolation between the previous and following angle measurement, based upon the timestamp of the EDM measurement. When the logging of auto points has started, SYNC is displayed as an icon.

Next step

DMASK (F3) to configure a display mask.

SURVEY Configure Auto Pts Display Mask

Line	Option
Fixed Lines :	1
1st Line :	Point ID (auto)
2nd Line :	Reflector Height
3rd Line :	Line Space Half
4th Line :	Msd Auto Points
5th Line :	Code (auto)
6th Line :	Code Desc
7th Line :	Line Space Half

CONT CLEAR DEFLT

CONT (F1)

To accept changes and return to the screen from where this screen was accessed.

CLEAR (F4)

To set all fields to **<XX. Line: Line Space Full>**.

DEFLT (F5)

Available if the active configuration set is a default configuration set. To recall the default settings.

Description of fields

Field	Option	Description
<Fixed Lines:>	From 0 to 5	Defines how many lines do not scroll in SURVEY Survey: Job Name, Auto page when that display mask is used.
<1st Line:>	Output	Fixed to <1st Line: Point ID (auto)> .
<2nd Line:> to <16th Line:>	Add. Constant	Output field for the additive constant of the currently selected reflector.
	Angle Right	Output field for the angle right.
	Annotation 1-4	Input field for comments to be stored with the point.
	Attrib (free) 01-20	Output field for attributes for free codes.
	Attrib (pt) 01-03	Input field for attributes for point codes.
	Azimuth	Output field for the azimuth.
	Code (auto)	Choicelist or input field for auto point codes.
	Code (free)	Output field for free codes.
	Code Desc	Output field for the description of codes.
	Code Desc (free)	Output field for the description of free codes.
	Code Type	Output field for the description of point codes.
	EDM Mode	Output field displaying the current EDM mode.
	EDM Type	Output field displaying the current EDM type.
	Easting	Output field for the Easting coordinate of the measured point.

Field	Option	Description
	Height	Output field for the height coordinate of the measured point
	Height Diff	Output field for the height difference between station and reflector.
	Horiz Dist	Output field for the horizontal distance calculated from the measured slope distance and the vertical angle.
	Hz-Angle	Output field for the horizontal angle.
	Line Space Full	Insert full line space.
	Line Space Half	Insert half line space.
	Linework	Choicelist with instructions how the software should flag a line/area.
	Msd Auto Points	Output field for the number of auto points logged after pressing START (F1) in SURVEY Survey: Job Name, Auto page. Counting starts from 0 every time START (F1) is pressed.
	Northing	Output field for the North coordinate of the measured point.
	Offset Cross	Input field for the horizontal distance offset for the measured point, perpendicular to the line of sight.
	Offset Height	Input field for the height offset of the measured point.
	Offset Length	Input field for the horizontal distance offset, in the direction of line of sight.
	Reflector	Output field for the chosen reflector.
	Reflector Height	Input field for the reflector height.
	SD-Last Rec	Output field for the last recorded distance.
	Slope Dist	Output field for the measured slope distance.
	Time at Point	Output field for the time from when the point is occupied until point occupation is stopped. Appears in the display mask during the point occupation.
	V-Angle	Output field for the vertical angle.

Next steps

CONT (F1) closes the screen and returns to **SURVEY Configuration, Auto Points** page.

14.3 Auto Points

Requirements

<Log Auto Pts: Yes> in SURVEY Configuration, Auto Points page.

Access step-by-step

Step	Description
1.	PROG. The PROG key opens the TPS1200+/TS30/TM30 Programs menu.
2.	Select Survey and press CONT (F1) .
3.	Press CONT (F1) to access SURVEY Survey .
4.	Press PAGE (F6) until the Auto page is visible.

SURVEY

Survey: Job Name, Auto page

The softkeys and the field <Auto Pt ID:> are always displayed. Other fields may be displayed depending on the display mask configured.

START (F1)

To start logging of auto points and offset points if configured or, for <Log By: User Decides>, to start the chain to which the auto points should be assigned. The first auto point is stored.

STOP (F1)

To end recording of auto points and offset points if configured or, for <Log By: User Decides>, to end the chain to which the auto points are assigned.

REC (F3)

Available for **STOP (F1)**. To store an auto point at any time.

OFST1 (F4)

To configure recording of the first type of offset points.

OFST2 (F5)

To configure recording of a second type of offset points.

SHIFT CONF (F2)

To configure auto points.

SHIFT QUIT (F6)

To exit the Survey application program. Point information logged until pressing **SHIFT QUIT (F6)** is saved in the database.

Description of fields

Field	Option	Description
<Auto Pt ID:>	User input	Available unless <Auto Pts: Time & Date> in CONFIGURE ID Templates . The identifier for auto points. The configured ID template for auto points is used. The ID can be changed. To start a new sequence of point ID's overtype the point ID.
	Time and Date	Available for <Auto Pts: Time & Date> in CONFIGURE ID Templates . The current local time and date is used as identifier for auto points.
<Reflector Ht:>	User input	The default reflector height as defined in the active configuration set is suggested.
<Msd Auto Pts:>	Output	Available after pressing START (F1) and before pressing STOP (F1) . The number of auto points measured since START (F1) has been pressed.
<Auto Pt Code:>	Choicelist	The thematical code for the auto point. Available for <Themadc Codes: With Codelist >. All point codes from the job codelist can be selected. The attributes are shown as output, input or choicelist fields depending on their definition.
	User input	Available for <Themadc Codes: Without Codelist >. Codes can be typed in but not selected from a codelist. A check is performed to see if a point code of this name already exists in the job. If so, the according attributes are shown.
<Code Desc:>	Output	The description of the code.
<Slope Dist:>	Output	The measured slope distance. When START (F1) is pressed, <EDM Mode: Tracking > is set and the slope distance is constantly updated.
<Hz:>	Output	The current horizontal angle.
<V:>	Output	The current vertical angle.

Next step

IF	THEN
auto points are to be logged	START (F1) to start logging of auto points. Then, for <Log By: User Decides >, REC (F3) whenever an auto point is to be logged.

IF	THEN
offset points are to be configured	OFST1 (F4) or OFST2 (F5) . Refer to "14.4 Offset Points of Auto Points".

14.4 Offset Points of Auto Points

14.4.1 Overview

Description

- Offset points
 - can be created with auto points when auto points are stored to the DB-X.
 - can be to the left or to the right of auto points.
 - are automatically computed with the logging of auto points, if configured.
 - form a chain relative to the chain of auto points to which they are related. Subsequently computed chains are independent from each other.
 - can be coded independently of auto points.
 - have the same time of when they were stored as the auto points to which they are related.
- Up to two offset points can be related to one auto point. The screens for the configuration of offset points are identical except for the title **Auto Points - Offset 1** and **Auto Points - Offset 2**. For simplicity, the title **Auto Points - Offset** is used in the following description.

Computation of offset points

The computation of offset points depends on the number of auto points in one chain.

One auto point

No offset points are computed or stored.

Two auto points


The configured offsets are applied perpendicular to the line between two auto points.

Three or more auto points

The first offset points are computed perpendicular to the line between the first and the second auto point.

The last offset point is computed perpendicular to the line between the last auto point and the one before.

All other offset points are computed on a bearing. The bearing is half of the angle between the last and the next measured auto point.



14.4.2 Configuring Offset Points

Access
step-by-step

Step	Description
1.	PROG. The PROG key opens the TPS1200+/TS30/TM30 Programs menu.
2.	Select Survey and press CONT (F1) .
3.	Press CONT (F1) to access SURVEY Survey .
4.	Press PAGE (F6) until the Auto page is visible.
5.	Press OFST1 (F4)/OFST2 (F5) to access SURVEY Auto Points - Offset .

SURVEY
Auto Points -
Offset,
General page

10:09
SURVEY
Auto Points - Offset 1
General Code
Store Offset1: Yes
Horiz Offset: 1.000 m
Height Offset: 0.000 m
Identifier: 0S1
Prefix/Suffix: Suffix
CONT OFST2 PAGE Q2 a ↑

CONT (F1)

To accept changes and return to the screen from where this screen was accessed.

OFST2 (F2) and OFST1 (F2)

To switch between configuring offset point type one and two.

Description of fields

Field	Option	Description
<Store Offset1:> and <Store Offset2:>	Yes or No	Activates or deactivates the logging of offset points and all fields on this screen.
<Horiz Offset:>	User input	The horizontal offset between -1000 m and 1000 m at which the offset point is collected.
<Height Offset:>	User input	The height offset between -100 m and 100 m from the related auto point.
<Identifier:>	User input	The identifier with up to four characters is added in front of or at the end of the ID of the auto point. This ID is then used as the point ID for the related offset point.
<Prefix/Suffix:>	Prefix or Suffix	Adds the setting for <Identifier:> in front of or at the end of the auto point ID.

Next step

PAGE (F6) changes to the **Code** page. The setting for **<Thematic Codes:>** in **CONFIGURE Coding & Linework** determines the availability of the fields and softkeys. They are identical to those of thematic coding with/without codelist. Up to

three attribute values can be stored. Refer to the TPS1200+/TS30/TM30 System Field Manual for information on coding.


15 Survey - Remote Point

15.1 Overview

Description

Remote point is used to determine the 3D coordinates of inaccessible points, for example on bridges. The horizontal distance to a base point directly underneath or above the remote point is measured. Then the instrument is aimed at the remote point. The coordinates of the remote point are calculated with the distance measured to the base point and the angles measured to the remote point.

Diagram



- P0 Instrument station
- P1 Base point
- P2 Remote point
- d1 horizontal distance to the base point
- α vertical angle between base point and remote point
- a Vertical axis from P1 to P2

TPS12_112



To ensure correct results, the remote point and the reflector must be lined up vertically. If it is not possible to maintain an exactly vertical line, the acceptable **<Hz Dist Tol:>** must be chosen. The horizontal distance to the remote point and to the base point should coincide.

15.2 Configuring Remote Point

Access step-by-step

Step	Description
1.	PROG. The PROG key opens the TPS1200+/TS30/TM30 Programs menu.
2.	Select Survey and press CONT (F1) .
3.	Press CONF (F2) to access SURVEY Configuration .

SURVEY Configuration, Remote Pt page

Description of fields

Field	Option	Description
<Use Remote Pt:>	Yes or No	Activates or deactivates the remote point function.
<Hz Dist Tol:>	User input	The horizontal distance to the remote point is equal to the horizontal distance of the base point. The value for <Hz Dist Tol:> is the maximum tolerated length of the chord between the base point and the remote point.
<Display Mask:>	Choicelist	Displays <None> until a display mask is chosen.

Next step

CONT (F1) exits the screen **SURVEY Configuration**.

15.3 Remote Point

Description

Remote point measurements are possible from the Survey application program when **<Use Remote Pt: Yes>** is set in the **SURVEY Configuration, Remote Pt** page and a valid distance measurement is available. Refer to "15.2 Configuring Remote Point".



Unless **<Display Mask: None>** in **SURVEY Configuration, Remote Pt** page, this screen contains an additional, user defined display mask.

Access

REMOT (F4) in **SURVEY Survey: Job Name** after one point is measured.

SURVEY Survey Remote Point, Remote Pt page

10:19
SURVEY
Survey Remote Point
Remote Pt
Point ID : 0001
ΔHt BaseRem : 1.248 m
Hz : 55.0000 g
V : 37.0002 g
Slope Dist : 118.998 m
Horiz Dist : 65.333 m
Easting : 49.680 m
STORE BASE

STORE (F1)

Stores the remote point. Stays in the **SURVEY Survey Remote Point** screen.

BASE (F4)

Returns to **SURVEY Survey: Job Name**. The distance measurement is cleared. **BASE (F4)** has the same behaviour as **L.GO (F5)** when **<Automation: LOCK>** was set before pressing **REMOT (F4)**.

Description of fields

Field	Option	Description
<Point ID:>	User input	Displays the point ID for the remote point. The point ID in SURVEY Survey Remote Point is always identical to the point ID in SURVEY Survey: Job Name .
<ΔHt BasRem:>	Output	The elevation difference between the base point and the remote point.
<Hz:> or <V:>	Output	The current horizontal or vertical angle.
<Slope Dist:>	Output	The current slope distance to the remote point calculated from the horizontal distance to the base point and the current vertical angle.
<Horiz Dist:>	Output	The horizontal distance measured to the base point.
<Easting:> , <Northing:> and <Height:>	Output	Calculated Easting, Northing coordinate or height for the remote point.

Next step

STORE (F1) stores the remote point.

16 Survey Cross Section

16.1 Overview

Description

- The Survey Cross Section application program allows for the automatic changing of codes during a survey.
- The codes for the elements in the cross section to be surveyed are all stored and pre-defined in a template. The codes are then automatically changed after each point observation.


Template

- Templates are used to pre-define the order of the codes for the survey.
- A template pre-defines:
 - the coding sequence of a cross section.
 - the type of coding.


Cross section methods and directions

- Templates can be applied
 - to the ZigZag method or the Same Direction method.
 - in either a forward direction or in a backward direction.

ZigZag



Same Direction



16.2 Configuring Survey Cross Section

Access

Step	Description
1.	PROG. The PROG key opens the TPS1200+/TS30/TM30 Programs menu.
2.	Select Survey Cross Section and press CONT (F1) .
3.	Press CONF (F2) to access X-SECTION Configuration .

X-SECTION Configuration, General page

12:24 X-SECTION Configuration

General

Method : ZigZag

Direction : Forward

Show Attrib : 1

Show Dist : Yes

Display Mask : <None>

CONT Q2 a ↑

CONT (F1)

To accept changes and return to the screen from where this screen was accessed.

DMASK (F3)

Available for **<Display Mask:>** being highlighted on **General** page. To edit the display mask currently being displayed in this field.

SHIFT ABOUT (F5)

To display information about the program name, the version number, the date of the version, the copyright and the article number.

Description of fields

Field	Option	Description
<Method:>	ZigZag or Same Direction	Method by which subsequent cross sections will be surveyed. Refer to "16.1 Overview" for a diagram.
<Direction:>	Forward Backward	The cross sections will be surveyed in the same way as the elements are defined in the selected <Template:> in X-SECTION Survey: Job Name . The cross sections will be surveyed in the reverse way as the elements are defined in the selected <Template:> in X-SECTION Survey: Job Name .
<Show Attrib:>	Choicelist	Defines which attribute field is displayed in X-SECTION Survey: Job Name . Useful if the surveyor is stringing - can then see that the correct string attribute value is being used.
<Show Dist:>	Yes or No	Activates an output field in X-SECTION Survey: Job Name . The horizontal grid distance from the current position to the point last surveyed for the same cross section will be displayed.

Field	Option	Description
<Display Mask:>	Choicelist	The user defined display mask is shown in X-SECTION Survey: Job Name .

Next step

CONT (F1) to return to **X-SECTION Begin** followed by **CONT (F1)** to access **X-SECTION Survey: Job Name**.

16.3 Surveying Cross Sections

Access

Refer to "16.2 Configuring Survey Cross Section" to access **X-SECTION Survey: Job Name**.

X-SECTION

Survey: Job Name,
General page

The pages shown are those from a typical configuration set. An additional page is available when a user defined display mask is used.

12:31	IR STD I
X-SECTION	
Survey: construction	
General	Map
Point ID :	0001
Reflector Ht :	1.250 m
Template :	template
Element :	1/3
Code :	kerb 1
-----	-----
Dist to Last :	----- m

ALL	DIST	REC	END	SURVY	PAGE
-----	------	-----	-----	-------	------

ALL (F1)

To measure and store distances and angles. Available if a template has been opened with **START (F4)**.

DIST (F2)

To measure and display distances.

REC (F3)

To record data.

START (F4) and END (F4)

To open and close the selected cross section template. While the template is open, the elements of the cross section can be surveyed.

SURVY (F5)

To manually occupy a point that is not part of the cross section. The point is not treated as an element of the cross section. The open template remains open. Available if a template has been opened with **START (F4)**.

SHIFT CONF (F2)

To configure the Cross Section Survey application program.

SHIFT PREV (F3)

To select the previous element of the cross section template. The currently measured element will not be stored. Available for **STOP (F4)** being displayed.

SHIFT NEXT (F4)

To select the next element of the cross section template. The currently measured element will not be stored. Available for **STOP (F4)** being displayed.

SHIFT INDIV (F5) and SHIFT RUN (F5)

To change between entering an individual point ID different to the defined ID template and the running point ID according to the ID template.

Description of fields

Field	Option	Description
<Point ID:>	User input	The identifier for manually occupied points. The configured point ID template is used. The ID can be changed in the following ways: <ul style="list-style-type: none"> To start a new sequence of point ID's type over the point ID. For an individual point ID independent of the ID template SHIFT INDIV (F5). SHIFT RUN (F5) changes back to the next ID from the configured ID template.
<Reflector Ht:>	User input	The reflector height.
<Template:>	Choicelist	The cross section template is closed. ---- is displayed if no template is defined.
	Output	The cross section template is open.
<Element:>	Output	x Number of next element on active template. y Total number of elements on active template.
<Code:>	Output	The name of the code.
<Stringline ID:>	Output	Available for <String Attrib:> being activated in CONFIGURE Coding & Linework, Coding page. Points that have the same code attached and belong to different cross sections are strung to one line.
<Dist to Last:>	Output	The horizontal grid distance from the current position to the last surveyed point. ---- is displayed for unavailable information.

Next step

IF	THEN
a cross section template is to be opened	select the desired <Template:>. START (F4) .
an element of a cross section is to be surveyed	ALL (F1) .
a cross section template is to be closed	select the desired <Template:>. END (F4) .
data is to be viewed graphically	PAGE (F6) . An element of a cross section template can also be surveyed from the Map page.

16.4 Cross Section Templates


16.4.1 Accessing Cross Section Template Management

Access
step-by-step

Step	Description
1.	PROG. The PROG key opens the TPS1200+/TS30/TM30 Programs menu.
2.	Select Survey Cross Section and press CONT (F1) .
3.	Press CONT (F1) in X-SECTION Begin to access X-SECTION Survey: Job Name .
4.	X-SECTION Survey: Job Name, General page Open the choicelist for <Template:> .

**X-SECTION
Templates**

All cross section templates stored in the active job are listed in alphabetical order, including the number of elements in each cross section template.



CONT (F1)

To select the highlighted cross section template and to return to the screen from where this screen was accessed.

NEW (F2)

To create a cross section template. Refer to "16.4.2 Creating/Editing a Cross Section Template".

EDIT (F3)

To edit the highlighted cross section template. Refer to "16.4.2 Creating/Editing a Cross Section Template".

DEL (F4)

To delete the highlighted cross section template.

COPY (F5)

To create a cross section template based on the one currently highlighted.

Next step

Step	Description
1.	highlight the desired cross section template.
2.	CONT (F1) closes the screen and returns to the screen from where X-SECTION Templates was accessed.

16.4.2 Creating/Editing a Cross Section Template

Access

Step	Description
1.	Open the choicelist for <Template:> in X-SECTION Survey: Job Name, General page.
2.	<p>X-SECTION Templates</p> <ul style="list-style-type: none"> Is a cross section template to be created from scratch? NEW (F2) to access X-SECTION New Template. Is a cross section template to be created based on the one currently highlighted? COPY (F5) to access X-SECTION New Template. Is a cross section template to be edited? EDIT (F3) to access X-SECTION Edit Template.



Copying and editing cross section templates is similar to creating a new cross section template. For simplicity, the screens are called **MANAGE XX Template**.

X-SECTION New Template, General page

Type in a name for the new cross section template.

Next step
PAGE (F6) changes to the **Elements** page.

X-SECTION New Template, Elements page

The elements existing in the template are listed.

Description of columns


Field	Description
No.	The number of the element.
Code	The code assigned to the element. ---- is displayed if no code is assigned to the element.
Code Type	The type of the code assigned to the element.

Next step

IF	THEN
the creation of a template is finished	STORE (F1) .
an element is to be added	ADD (F2) or ->ADD (F5) . Refer to paragraph "X-SECTION Add Element".
an element is to be edited	EDIT (F3) . Refer to paragraph "X-SECTION Add Element".

X-SECTION Add Element

The functionality of the screens **X-SECTION Insert Element** and **X-SECTION Edit Element in Template** is very similar.



CONT (F1)

To add the element at the end of the cross section template or to store the changes. To return to the screen from where this screen was accessed.

NEXT (F5)

Available in **X-SECTION Add Element**. To add the element at the end of the cross section template. To stay in this screen and create the next element.

PREV (F5)

Available in **X-SECTION Edit Element in Template**. To store the changes. To stay in this screen and edit the previous element.

NEXT (F6)

Available in **X-SECTION Edit Element in Template**. To store the changes. To stay in this screen and add the next element.

Description of columns

Field	Option	Description
<Element No.:>	Output	For X-SECTION Add Element and X-SECTION Insert Element : The number of the element to be added. For X-SECTION Edit Element in Template : x Number of the element to be edited. y Total number of elements on the active template.
<Code Type:>	Free Code Thematic Codes	To store a code independent of the element as time related information. To store a code together with the element.
<Rec Free Code:>	After Point or Before Point	Available for <Code Type: Free Code>. Determines if a free code is stored before or after the point.
<Code (free):>	Choicelist	The code which will be stored before or after the point/line. Available for <Code Type: Free Code>.
<Code:>	Choicelist	The code which will be stored with the next point/line. Available for <Code Type: Thematic Codes>.

Field	Option	Description
Attribute name	Output	The attribute and the attribute value which will be stored with the point/line. Available unless <Show Attrib: Do Not Show> in X-SECTION Configuration .

Next step

CONT (F1) adds the element or stores the changes and returns to **X-SECTION New Template, Elements** page.


17 Traverse

17.1 Overview

Description

The Traverse application is to fulfil one of the most common operations done by surveyors to establish a control point base system to be used as a skeleton for other survey operations for example topographic survey, point stakeout, line stakeout or road stake.

Diagram




- P1 Traverse point
- P2 Backsight point
- P3 Traverse point
- P4 Sideshot point
- P5 Traverse point
- P6 Sideshot point
- P7 Sideshot point
- P8 Closing point
- P9 Sideshot point
- P10 Closing angle point

17.2 Configuring Traverse

Access step-by-step

Step	Description
1.	PROG. The PROG key opens the TPS1200+/TS30/TM30 Programs menu.
2.	Select Traverse and press CONT (F1) .
3.	Press CONF (F2) to access TRAVERSE Configuration .

TRAVERSE Configuration, Parameters page



CONT (F1)

To accept changes and to access the subsequent screen.

F JOB (F3)

To update the **<Fixpoint Job:>** previously selected in **TRAVERSE Traverse Begin** during runtime. To access a separate set of points to check or close on. Available on the **Parameters** page.

DMASK (F3)

To edit the display mask currently being displayed in this field. Available for **<Display Mask:>** being highlighted on **Parameters** page.

Description of fields

Field	Option	Description
<MeasMethod:>	B'F'...F'B''	All points are measured in face I, then measured in face II in reverse sequential order.
	B'F'...B''F''	All points are measured in face I, then measured in face II.
	B'B''F'F''	Backsight point is measured in face I immediately followed by the face II. Other points are measured in face I, face II order.
	B'B''F''F'	Backsight point is measured in face I immediately followed by the face II. Other points are measured in alternating face order.
	B'F'...	All points are measured in face I only.
<Foresight:>	Single or Multiple	Option to define if only one foresight point or multiple points are used during the sets.

Field	Option	Description
<Auto Survey:>	On or Off	For instruments with ATR and <Auto Survey: On> ATR search and ATR measurements are done to specified targets and subsequent sets.
<Display Mask:>	Choicelist	The user defined display mask to be shown in TRAVERSE XX, Set:X/X .
<User Guidance:>	Yes or No	To activate/deactivate helpful message dialogs to assist in using the Traverse program.

Next step

PAGE (F6) changes to **Tolerances** page.

**TRAVERSE
Configuration,
Tolerances page**

Description of fields

Field	Option	Description
<Use Tolerance:>	Yes or No	The entered horizontal, vertical and distance tolerances are checked during the measurements to verify accurate pointing and measurements.
<Hz Tolerance:>, <V Tolerance:> or <Dist Tol:>	User input	Tolerance for horizontal, vertical directions and distances.
<BS Ht Tol:>	User input	Tolerance for the backsight height.

Next step

PAGE (F6) changes to **Logfile** page. Refer to "1.2 Configuration of a Logfile".

17.3 Traverse Information and Traverse Management

Access

In **TRAVERSE Traverse Begin** press **CONT (F1)**.

TRAVERSE Traverse Information

17:21
TRAVERSE
Traverse Information
Traverse ID : 001
Description : new traverse
Operator : Abc
Date : 06.03.06
Time : 17:17:53
Status : Open

CONT (F1)

To begin traverse measurement.

DATA (F5)

To display traverse data. Accesses **TRAVERSE Traverse Data**. Refer to "17.4 Traverse Data". Not available for adjusted traverses.

RESLT (F6)

To view results of the traverse. Accesses **TRAVERSE Traverse Results**. Not available for open traverses.

CONT DATA RESLT

Description of fields


Field	Option	Description
<Traverse ID:>	Choicelist	The ID of the traverse. ENTER to access TRAVERSE Traverse Management .
<Status:>	Open Position Closed Pos & Ang Closed Adjusted	The traverse is not closed in position. The traverse has been closed in position on a control point. The traverse has been closed both in position and angularly. The traverse data is the result from an adjustment.

Next step

ENTER when the **Traverse ID** is highlighted. Accesses **TRAVERSE Traverse Management**.

TRAVERSE
Traverse Manage-
ment

All traverses of the active job are displayed.



CONT (F1)

To confirm selection of highlighted traverse and return to **TRAVERSE Traverse Information**.

NEW (F2)

To create a new traverse.

EDIT (F3)

To edit the traverse ID and description of the highlighted traverse.

DATA (F5)

To display traverse data.

Next step

CONT (F1) to return to **TRAVERSE Traverse Information**.

17.4 Traverse Data

Access

DATA (F5) in **TRAVERSE Traverse Information**.

OR

DATA (F5) in **TRAVERSE Traverse Management**.

TRAVERSE
Traverse Data

Station ID	Backsight ID	No. Sets	No.	FS
setup2	chair	1	1	1
tps15	setup2	1	1	1
tps19	tps15	1	1	1
tps020	tps19	1	1	1

CONT EDIT DEL PAGE

CONT (F1)

To return to where this screen was accessed from.

EDIT (F3)

To access the **TRAVERSE Traverse Point Results** screen.

DEL (F4)

To permanently delete the LAST traverse station.

Description of columns

Column	Description
Station ID	Point ID of the station ID.
Backsight ID	The backsight point measured from the current station ID.
No Sets	Number of measured sets.
No FS	Number of measured foresight points.

Next step


CONT (F1) returns to the previous screen.

17.5 Traverse Point Results

Access

Is displayed automatically after measuring all sets from the current station.
OR
DATA (F5) in **TRAVERSE Traverse Information. EDIT (F3).**

TRAVERSE Point Results, Foresight page and Backsight page



CONT (F1)

While measuring a traverse:
Displays a confirmation window with traverse measurement options.
Otherwise: To return to **TRAVERSE Traverse Data.**

+SETS (F2)

To add more sets while still at the setup.

SETS (F3)

To include or exclude measured sets in the calculation of a foresight point. In the **TRAVERSE Sets, Point** screen **USE (F3)** to include or exclude a set and **SPRD (F4)/RESID (F4)** to review the affect of using the set.

CLOSE (F4)

To set a point as a closing point if not selected before measurement. Or to revert a closing point to a normal foresight.

MORE (F5)

To display additional information.

SHIFT CONF (F2)

To configure the Traverse application program.

SHIFT EDIT (F3)

To edit point code and annotations.

SHIFT CHECK (F4)

To check inverse distances and closure between the selected foresight point and a point from the fixpoint job. Available on the **Foresight** page.

SHIFT CTRL (F5)

Available on the **Backsight** page of the initial station. To turn the point into a control point.

SHIFT QUIT (F6)

To return to **TPS1200+ Main Menu.**

Description of fields

Field	Option	Description
<Point ID:>	Chocelist	Selected point ID.
<Reflector Height:>	User input	The reflector height of the target point. Editable.
<Point Type:>	Foresight, Close or Close Angle	The current point type.
<Used Sets:>	Output	The number of sets out of all measured sets used for the calculation. Available for the Foresight page.
<No. of Sets:>	Output	The number of sets the point was measured in. Available for the Backsight page.
<Hz Arc Avg:>	Output	Average horizontal angle.
<V Avg:>	Output	Average vertical angle.
<Dist Avg:>	Output	Average distance.
<Hz Arc StdDev:>	Output	Standard deviation of horizontal angle.
<V StdDev:>	Output	Standard deviation of vertical angle
<Dist StdDev:>	Output	Standard deviation of distance.
<Hz Spread:>	Output	Spread of horizontal angle.
<V Spread:>	Output	Spread of vertical angle.
<Dist Spread:>	Output	Spread of distance.

Next step

PAGE (F6) changes to the **Stat Info** page where information about the current station is displayed.

IF accessed	THEN
after sets measurement	<p>CONT (F1) opens a confirmation window with options that dependant on traverse status are:</p> <ul style="list-style-type: none"> For an open traverse: Move to next station, return to TRAVERSE Point Results, to survey a sideshot, to view traverse data or to quit the traverse application. For a closed traverse: Move to close angle, return to TRAVERSE Point Results, to survey a sideshot or to quit the traverse application.
from TRAVERSE Traverse Data	CONT (F1) returns to TRAVERSE Traverse Data .

17.6 Traverse Results

Access

Is displayed automatically after the traverse closing point is measured or selected.

OR

RESLT (F6) in **TRAVERSE Traverse Information** when a traverse is closed.

TRAVERSE

Traverse Results, Position page

Traverse Results		
Position	Angle	Map
Start Stn :	setup2	
Close Point :	setup3	
Length of Err :	0.0124 m	
Dir of Err :	98.3659 g	
Δ Height :	-0.0023 m	
Total Dist :	170.7280 m	
2D Accuracy :	1/13782	
1D Accuracy :	1/74695	
Q2 a 0		
CONT	N & E	ADJST
		PAGE

CONT (F1)

To move to close angle, to return to **TRAVERSE Traverse Results**, to survey a sideshot, to adjust the traverse or to quit the Traverse application.

N & E (F3) or L & D (F3)

To view the misclosure error in north/east or length/direction.

ADJST (F4)

To adjust the traverse.

DATA (F5)

To display traverse data.

Description of fields

Field	Option	Description
<Start Stn:>	Output	The point ID of the traverse start point.
<Close Point:>	Output	The point ID of the traverse closing point.
<Length of Err:> or <Dir. of Err:>	Output	The length or direction of the misclosure error.
<Δ North>, <Δ East> or <Δ Height:>	Output	Error in north, east or height.
<Total Dist:>	Output	Total length of the traverse.
<2D Accuracy:> or <1D Accuracy:>	Output	Position or height ratio of misclosure.

Next step

PAGE (F6) changes to the **Angle** page.

TRAVERSE

Traverse Results, Angle page

Description of fields

Field	Option	Description
<Foresight ID:>	Output	Point ID of the closing angle point. Displays ----- if no values are available.
<Known Azimuth:>	Output	Defined azimuth of closing line. Displays ----- if no values are available.

Field	Option	Description
<Azimuth Avg:>	Output	Mean value of the measured azimuth closing line. Displays ----- if no values are available.
<Angular Misc:>	Output	Angular misclosure of traverse. Displays ----- if no values are available.



Next step

IF the traverse	THEN
is to be closed	<p>CONT (F1) allows to:</p> <ul style="list-style-type: none"> • C ANG (F1) closes the traverse with angular closure. Available unless closing angle is already measured. • BACK (F2) returns to TRAVERSE Traverse Results. • SURVY (F3) measures a sideshot point. • ADJST (F4) adjusts the traverse. • QUIT (F6) ends Traverse application program.

17.7 Traverse Methods





17.7.1 Starting Traverse


Step-by-step

Step	Description
1.	PROG. The PROG key opens the TPS1200+/TS30/TM30 Programs menu.
2.	Select Traverse and press CONT (F1) .
3.	Press CONT (F1) to access TRAVERSE Traverse Information .
	ENTER to select an existing traverse or to create a new one.
4.	CONT (F1) to access TRAVERSE Traverse Configuration . Check the settings.
5.	CONT (F1) to access SETUP Station Setup . Any standard setup method can be used.
6.	SET (F1) to set the station and orientation.
7.	If User Guidance is active, a confirmation window is displayed. 
8.	TRAVERSE Foresight, Set:X/X <Foresight ID:> The name of the foresight point. <Reflector Ht:> The reflector height of the foresight point. <No. of Sets:> The number of sets to be measured.
9.	ALL (F1) to measure and record. The measurement settings for the first measurement to each point are used for all further sets.
10.	TRAVERSE Point Results CONT (F1) to move to the next station, to return to the TRAVERSE Point Results screen (and set a point as a closing point), to survey a sideshot, to view traverse data or to end the traverse.
11.	MOVE (F1) to move to the next station. Continue with the next chapter.

17.7.2 Continuing an Existing Traverse



Measure traverse step-by-step


Step	Description
1.	Start the Traverse application program.
2.	TRAVERSE Traverse Begin Check the settings.
3.	CONT (F1) to access TRAVERSE Traverse Information .
4.	TRAVERSE Traverse Information <Traverse ID:> The name of the traverse. ENTER to select a different existing traverse.
	DATA (F5) to view data of the active traverse.
	SHIFT CONF (F2) to change the configuration settings.
5.	CONT (F1) to access TRAVERSE Backsight, Set:X/X . Enter <Instrument Ht:>. <Hz:>, <V:> and <Horiz Dist:> The measured values are displayed. <Calc Azimuth:> The calculated azimuth from the current station point to the backsight point. < Δ Horiz Dist:> and < Δ Height:> The difference between the computed and measured values.
	MORE (F5) to change between the displayed values.
6.	ALL (F1) to measure and record the backsight point.
7.	FS (F1) to measure a foresight point.
8.	TRAVERSE Foresight, Set:X/X <Foresight ID:> The name of the foresight point. <Reflector Ht:> The reflector height of the foresight point. <No. of Sets:> The number of sets to be measured.
	SURVY (F5) to measure sideshot points.
9.	ALL (F1) to measure and record the foresight points. The measurement settings for the first measurement to each point are used for all further sets.
10.	TRAVERSE Point Results CONT (F1)

Step	Description
11.	<p>A Confirmation window is displayed.</p>  <p>MOVE (F1) to move to the next station.</p>
12.	Repeat steps 1. to 11. until traverse is ready to be closed.

17.7.3 Closing Traverse


Step-by-step

Step	Description
1.	Measure a backsight on a new station.
2.	<p>The Confirmation window in TRAVERSE Foresight, Set:X/X is displayed.</p>  <p>CLOSE (F2)</p>
3.	OK (F4)
4.	<p>TRAVERSE Data</p> <p>Highlight the closing point.</p>
5.	CONT (F1)
6.	<p>TRAVERSE Foresight, Set:X/X</p> <p>ALL (F1) to measure and record the closing point.</p>
7.	<p>TRAVERSE Point Results</p> <p>CONT (F1) to view traverse results.</p>
8.	<p>TRAVERSE Traverse Results</p> <p>CONT (F1)</p>
9.	C ANG (F1) to close the traverse with angular closure.
	Optionally the traverse can be adjusted.
10.	Move to the closure point and start Traverse application program.
11.	<p>TRAVERSE Traverse Begin</p> <p>Check the settings.</p>
12.	CONT (F1) to access TRAVERSE Traverse Information .
13.	<p>TRAVERSE Traverse Information</p> <p>The existing traverse is shown</p>
14.	CONT (F1) to access TRAVERSE Close Angle .
15.	<p>TRAVERSE Close Angle</p> <p><FS Type:> To measure onto a known point or a known azimuth.</p> <p><Foresight ID:> The point ID of the foresight point.</p> <p><Known Azimuth:> Available for <FS Type: Known Azimuth>. Known azimuth for foresight point.</p>

Step	Description
16.	CONT (F1) to access TRAVERSE Backsight, Set:X/X .
17.	ALL (F1) to measure all sets.
18.	TRAVERSE Point Results CONT (F1) to view traverse results.
19.	TRAVERSE Traverse Results CONT (F1) to exit viewing traverse results.
20.	QUIT (F6) to quit the Traverse application.
	Optionally the traverse can be adjusted.

Close traverse on internal reference

This option is used for determining the closure of a closed loop traverse, consisting of a single control point with an arbitrary backsight azimuth. This allows completion of a traverse without having to reoccupy the initial station setup to measure a closing angle. The positional closure is calculated by comparing the control position of the initial station setup to the measured position of the final foresight. The angular closure is calculated by comparing the set azimuth of the initial backsight to the azimuth of the final measured leg.



The first station setup is on P1, and an assumed direction to backsight P6. Upon closing this traverse, with the last setup over P6, the closing point is P1. In this case the only point that is considered as a control is P1.

17.8 Traverse Adjustment

17.8.1 Accessing Traverse Adjustment



Survey points have to be measured while Traverse is running to be part of the adjustment calculations.

TRAVERSE Adjustment Method

17:14	+	IR	I	Bluetooth	GPS	Printer
TRAVERSE		STD				
Adjustment Method						
Method Map						
Traverse ID :		001				
Horz. Adjust.:		Compass				
Angle Balance:		No Distribution				
Vert. Adjust.:		Equally				
Progress :		<input type="text"/>				

CALC					Q2 a ↑
					PAGE

CONT (F1)

To calculate the result.

Description of fields

Field	Option	Description
<Traverse ID:>	Output	The point ID of the traverse start point.
<Horz. Adjust:>	Compass	Suitable for surveys, where angles and distances were measured with equal precision.
	Transit	Suitable for surveys, where angles were measured with a higher precision than the distances.
	No Distribution	No distribution is made.
<Angle Balance:>	Equally	The angle misclosure is distributed equally.
	No Distribution	No distribution is made.
<Vert. Adjust:>	Equally	The height error is distributed equally.
	By distance	The height error is distributed by distance.
	No Distribution	No distribution is made.

Next step

CALC (F1) starts the adjustment calculation.

17.8.2 Adjustment Results

**TRAVERSE
Adj. Results,
Position page and
Angles page**

Position	Angle	Points	Method	Map
Closure		Adjusted		
Start Stn		setup2		
Close Point		setup3		
Length of Err		0.000	m	
Dirac of Err		0°00'00"		
Δ Height		-0.000	m	
Total Dist		35.817	m	
2D Accuracy		----		

Navigation buttons: CONT, N & E, MORE, PAGE

CONT (F1)

To access the next screen.

N & E (F3) or L & D (F3)

To view the misclosure error in north/east or length/direction.

MORE (F5)

To display the values for the unadjusted, the balanced and the adjusted solution.

Description of fields

The fields are the same as in **TRAVERSE Traverse Results**. Refer to "17.6 Traverse Results".

Next step

PAGE (F6) changes to the **Points** page.

**TRAVERSE
Adj. Results,
Points page**

The adjusted points are listed. The **Point Type** column shows the purpose for each point.

VIEW (F3) shows the coordinate values of the highlighted point.

Next step

PAGE (F6) changes to the **Method** page.

**TRAVERSE
Adj. Results,
Method page**

The adjustment methods previously selected in **TRAVERSE Traverse Method** and used for the adjustment are displayed.

Next step

PAGE (F6) changes to the **Map** page. The **Map** page provides an interactive display of the data.

CONT (F1) accesses **TRAVERSE Adjustment Store**.

**TRAVERSE
Adjustment Store**

Description of fields

Field	Option	Description
<Traverse ID:>	Choicelist	The point ID of the traverse start point.
<Store to Job:>	User input	Once adjustment results have been reviewed and accepted, the adjusted position of the points can be stored in a separate job.
<Incl. Srvy Pt:>	Yes or No	Survey points can be included or not.
<Add Identifier:>	Yes or No	Activates the use of additional identifiers for the point ID's of the adjusted points.

Field	Option	Description
<Identifier:>	User input	The identifier with up to four characters is added in front of or at the end of the ID of the adjusted points.
<Prefix/Suffix:>	Prefix	Adds the setting for <Identifier:> in front of the original point ID's.
	Suffix	Adds the setting for <Identifier:> at the end of the original point ID's.

Next step

STORE (F1) stores the results.


REPR (F4) to generate an adjustment report. The adjustment report is stored into an XML file. For the XML file to be viewable as HTML a XSL file named adjust_report.xsl has to be placed in a directory named SRC in the folder containing the XML file.

18 Volume Calculations

18.1 The Volume Calculations Menu

The menu

- This menu lists all of the necessary steps and the option to close the program.



CONT (F1)

To select the highlighted option and to continue with the subsequent screen.



SHIFT CONF (F2)

To configure the program.

Menu Option	Description
Step 1) Survey Points	To measure points defining a new surface or extending existing surfaces currently stored in the active job.
Step 2) Triangulate Surface	To triangulate (delauny triangulation) the measured surface points to establish the surface.
Step 3) Compute Volume	To compute the volume of a surface by a reference (3D point, entered elevation) or by the stockpile method.
Step 4) End Volume Calculations	To end Volume Calculations and return to the screen from where Volume Calculations was accessed.

Next step

IF	THEN
to start the program	highlight the relevant option and press CONT (F1) .
to configure the program	press SHIFT CONF (F2) .
to close the program	highlight End Volume Calculations , press CONT (F1) .

18.2 Step 1) Surveying the Points

Description

- To measure points to a new surface or to an existing surface in the active job. If no surfaces currently exist in the active job, the user has to enter a **New Surface** first in **VOLUMES Choose Task & Surface**. The menu items **Triangulate Surface** and **Compute Volume** within the **VOLUMES Volumes & Surfaces Menu** are marked grey if no surface exists in the active job.

Surveying points

- This menu lists all of the necessary steps and the option to close the program.

17:24
VOLUMES

IR STD I

Surface Points

Survey Offset Code Map

Point ID : 100

Reflector Ht : 1.567 m

Hz : 200.0009 g

V : 100.0029 g

Horiz Dist : 50.010 m

Ht Diff : -0.014 m

Q2 a ↑

ALL | DIST | REC | >BNDY | DONE | PAGE

ALL (F1)

To measure and store distances and angles.

STOP (F1)

Available if **<EDM Mode: Tracking>** and **DIST (F2)** was pressed. Stops the distance measurements. **(F1)** changes back to **ALL**.

DIST (F2)

To measure and display distances. Available unless **<EDM Mode: Tracking>** and/or **<Log Auto Pts: Yes>**, after the tracking or logging is started.

REC (F3)

To record data. If **<EDM Mode: Tracking>** and/or **<Log Auto Pts: Yes>**, records measured point and continues tracking.

>BNDY (F3) / >SURF (F3)

To change the class of the point to be measured between surface point and boundary point.

DONE (F5)

To finish measuring and to return to the **Volumes Calculations Menu**.

PAGE (F6)

To change to another page on this screen.

SHIFT INDIV (F5) and SHIFT RUN (F5)

To change between entering an individual point ID different to the defined ID template and the running point ID according to the ID template.

Description of fields

Field	Option	Description
<Point ID:>	User input	The identifier for manually occupied points. The configured point ID template is used. The ID can be changed in the following ways: To start a new sequence of point ID's type over the point ID. For an individual point ID independent of the ID template SHIFT INDIV (F5) . SHIFT RUN (F5) changes back to the next ID from the configured ID template.
<Reflector Ht:>	User input	The last used reflector height is suggested when accessing the Survey application program. An individual reflector height can be typed in.
<Hz:>	Output	The current horizontal angle.
<V:>	Output	The current vertical angle.
<Horiz Dist:>	Output	The horizontal distance after DIST (F2) was pressed. No distance is displayed when accessing the screen and after REC (F3) or ALL (F1) .
<Ht Diff:>	Output	The height difference between station and measured point after DIST (F2) . Displays ----- when accessing the screen and after REC (F3) or ALL (F1) .

Next step

Press **ESC** returns to the **VOLUMES Choose Task & Surface** screen.

Press **ESC** again to return to the **VOLUMES Volume Calculations Menu** screen.

18.3 Step 2) Triangulating the Surface

Triangulating the surface

- To calculate a surface by establishing a triangulation (triangulation method: delauny) of the measured surface points.

17:23
VOLUMES

IR STD

Triangulate Surface

General | Points | Map

Surface Name : S1

No. Surf Pts : 93
No. Bndy Pts : 33

Last Pt ID : 1000
Last Pt Date : 29.03.06
Last Pt Time : 12:24:29

Q2 a ↑

CONT PAGE

CONT (F1)

To access **VOLUMES Boundary Definition**. (F1) changes to **CALC**.

PAGE (F6)

To change to another page on this screen.

SHIFT CONF (F2)

To configure the program.

SHIFT DEL S (F4)

To delete the surface.

Description of fields

Field	Option	Description
<Surface Name:>	Choicelist	Name of the surface to be triangulated.
<No. Surf Pts:>	Output	Number of the measured surface points.
<No. Bndy Pts:>	Output	Number of the measured boundary points.
<Last Pt ID:>	Output	ID of the last measured point of the chosen surface.
<Last Pt Date:>	Output	Date of the last measured point of the chosen surface.
<Last Pt Time:>	Output	Time of the last measured point of the chosen surface.

Next step

CONT (F1) continues to the **VOLUMES Boundary Definition** screen.

Defining the boundary

17:22
VOLUMES

IR STD

Boundary Definition

Points | Map

Point ID	Height
1044	1641.070
1000	1641.550
1001	1641.060
1007	1640.610
1008	1640.260
1009	1640.870
1010	1641.310

Q2 a ↑

CALC ADD 1 UP DOWN MORE PAGE

CALC (F1)

To start calculating the triangulation and to access to the **VOLUMES Triangulation Results**.

ADD 1 (F2)

To add points from the active job to the surface.

UP (F3)

To move the focused point one step up within the boundary definition.

DOWN (F4)

To move the focused point one step down within the boundary definition.

MORE (F5)

To display information about the code group, the code type, the code description and the quick codes if available.

PAGE (F6)

To change to another page on this screen.

SHIFT HOME (F2)

To move the focus to the top of the points list.

SHIFT END (F3)

To move the focus to the bottom of the points list.

SHIFT REM 1 (F4)


To remove the marked point from the surface.

SHIFT EXTRA (F5)

To access to the **VOLUMES Extra Menu**.

Next step

SHIFT EXTRA (F5) continues to the **VOLUMES Extra Menu** screen.

The Extra menu**CONT (F1)**

To select the highlighted option and to continue with the subsequent screen.



Menu Option	Description
Add Many Points	Access Data Manage and all points that are in the list.
Remove All Points	Method to remove all points that are indicated in the Boundary Definition points page.
Sort Points by Time	Method to sort all points in the Boundary Definition points page by the time they were stored.
Sort Points by Proximity	Method to sort all points in the Boundary Definition points page by the closest proximity.
Compute Rubber Band Boundary	Method to define a new boundary as if a rubber band was placed around the points. The current list of boundary points will be ignored.

Next step

CONT (F1) returns to the previous screen.

CALC (F1) calculates the triangulation and continues to the **VOLUMES Triangulation Results** screen.

Triangulation results

17:23
VOLUMES

Triangulation Results

Summary | Details | Map

Surface Name : S1

Area : 24727.08 m²

No. Triangles: 217

No. Surf Pts : 93

No. Bndy Pts : 33

Q2 a ↑

DONE | DXF | PAGE

DONE (F1)

To close the triangulation of the surface and return to **Volumes Calculations Menu**.

DXF (F4)

To export the triangulation results to a DXF file on the data or root directory of the CF Card.

PAGE (F6)

To change to another page on this screen.

SHIFT CONF (F2)

To configure the program.

Description of fields

Field	Option	Description
<Surface Name:>	Output	Name of the surface.
<Area:>	Output	Area of the base plane.
<No. Triangles:>	Output	Number of triangles used within the triangulation.
<No. Surf Pts:>	Output	Number of points inside the surface.
<No. Bndy Pts:>	Output	Number of boundary points of the surface.

Next step


DONE (F1) returns to the **Volume Calculation Menu** screen.

18.4 Step 3) Computing the Volume

Description

- To calculate a surface by establishing a triangulation (triangulation method: delauny) of the measured surface points.
- To compute the volume of the triangulated surface by using either:
 - the stockpile method,
 - an elevation plane as a reference,
 - a single point as a reference.

Computing the volume



CALC (F1)

Computing the volume and access to the **VOLUMES Volume Calculation Results page. (F1)** changes to **CONT.**

SHIFT CONF (F2)

To configure the program.

Description of fields


Field	Option	Description
<Method:>	Choicelist	To calculate the volume of the triangulated surface.
	Stockpile	To calculate a volume between the triangulated surface and the surface defined by the boundary points of the surface.
	Surface to Elev	To calculate a volume between the triangulated surface and the height entered by the user.
	Surface to Point	To calculate a volume between the triangulated surface and the height of a selected point.
<Surface Name:>	Choicelist	The surface chosen from the triangulated surfaces currently stored to the active job.
<No. Triangles:>	Output	The number of triangles from the triangulated surface
<To Elevation:>	User Input	To enter a height for the elevation plane. This height will be used as the reference when <Method: Surface To Elev> is selected.
<To Point:>	Choicelist	To select a point from the active job. This point height will be used as the reference when <Method: Surface To Point> is selected.

Field	Option	Description
<Elevation:>	Output	The elevation of the selected point.

Next step

CALC (F1) calculates the volume and continues to the **VOLUMES Volume Calculation Results** screen.

Volume calculation results



Area : 24727.08 m²
 Net Volume : 228439.47 m³



CONT (F1)

Computing the volume and access to the **VOLUMES Volume Calculation Results page. (F1)** changes to **CONT**.

PAGE (F6)

To change to another page on this screen.

SHIFT CONF (F2)

To configure the program.

Description of fields

Field	Option	Description
<Surface Name:>	Output	Surface.
<Area:>	Output	Area of the base plane.
<Net Volume:>	Output	Volume of the surface.

Next step

CONT (F1) returns to the **Volume Calculation Menu** screen.

Index

A	
Access	
Auto point	206
Determine coordinate system	
One point localisation method	63
Gridstake to reference line/arc	117
Local Resection	181
Resection / Resection Helmert	180
Select reference line from job	100
Set station and azimuth	172
Set station and backsight	175
Sets of angles	144
Stakeout points, reference line	113
ADD	37
ADD1	37
ADJUST	51
Adjustment report	
Traverse	244
Adjustment Results	243
Angle right	162
Antenna	
Create	80
Edit	80
Antennas	
Default	79
Application program	
COGO	11
Determine coordinate system	
General	49
Normal	55
One point localisation	63
Reference line	91
Sets of angles	143
Setup	159
Stakeout	187
Survey	
Auto points	201
General	197
Remote point	213
Traverse	227
Application programs	
Open, maximum number	7
Arc, reference	91
Area calculations	
COGO calculation method	30
Arrow, orientate to	93
Arrow, orientate to, Stakeout	188
Auto points	201, 206
Configuration	202
Logging	202
Offset points	209
Auto Points, access	206
Azimuth, compute	
Determine coordinate system	73
B	
Backsight, traverse	238
Backward in Survey Cross Section	218
BASE	215
Bearing-Bearing, intersection method	26
Bearing-Distance, intersection method	26
C	
Calculate sets of angles	152
Chainage	
Format	94
Reference Line	91
Classic 3D transformation	
One point localisation	72
Close traverse	233
On internal reference	241
COGO	11
Distance input/output	13
Modify values	23
Combined Scale Factor	68
Computing	
Grid scale factor	70
Height scale factor	71
Offset points	209
Required azimuth	73
Configuration	
Auto points	202
Offset auto points	210
Remote point	214
Sets of angles	145
Setup	162
Stakeout	188
Traverse	228
Control point, create in Traverse	233
Control points	49

Coordinate		E	
Geometry calculations	11	Edit	
Coordinate system		Antenna	80
Determine	49, 55	Matching points	60
Normal method	55	Ellipsoid	
One point localisation	63	Distance in COGO	13
Update	55	Exceeded limit	
Create		Height	
Antenna	80	Reference line	94
Cross Section Survey, configure	218	Position	
Cross Section Template		Reference line	94
Create	223	Stakeout difference	196
Edit	223	F	
D		FIX	51
Data		Forward in Survey Cross Section	218
Preparing for staking polylines	119	G	
Default, recall		GETPT	150
Auto points	204	Grid distance in COGO	13
Sets of angles	145	Grid scale factor, compute	70
Define reference arc	91	Gridstake	
Define reference line	91	Line	97
Delete		Reference arc	117
Cross section template	222	Reference line	117
Matched points	41, 56	To arc	97
Determine coordinate system		Ground distance in COGO	13
Access one point localisation	63	H	
Configure	51	Height offset, stakeout	191
Normal	51	Height scale factor, compute	71
One point localisation	53	I	
One point localisation		INDIV	139, 198
Classic 3D transformation	72	Information	
Onestep transformation	64	Traverse	230
Twostep transformation	64	Intersection	
Transform results	61	COGO calculation method	26
Difference limit exceeded, stakeout	196	INV	22
Display mask		Inverse	
Auto points	204	COGO calculation method	16
Distance		K	
Input/output in COGO	13	Known backsight point	175
Distribution			
Residuals COGO Shift, Rotate & Scale	14		
Residuals throughout transformation area	52		
DMASK			
Auto points	202		
DTM layer, select	8		

L		
Layer, DTM, select	8	Offset auto points
Licence key	7	Computing
LINE	113	Configuration
Line		Offset, plane
Orientate to	92	Offsets, antenna, input
Stakeout	189	OFST1
Reference	91	OFST2
Line calculations		One point localisation
COGO calculation method	30	Classic 3D transformation
LINE+	118	Onestep transformation
Logfile	10	Orientate
Logging auto points	202	From station
		Stakeout
		To arrow
		To line/arc
		To station
M		Orientation and height transfer
Management		Origin, plane
Reference line	97	ORIGN
Traverse	230	
MATCH	41, 56	P
Match		PLANE
Point parameters	51	Point
Points	41, 56	Auto
Maximum number		Orientate to
Open application programs	7	Stakeout
Measure		Point ID
Sets, sets of angles	151	Next available
Setup points	177	Real-time rover operations
To arc	97	Static operations
To line	97	Polyline
Measured point	91	Selection
Modify values in COGO	23	polyline
		preparing data
N		Positive offset, COGO
Negative offset, COGO	22	ppm, transformation results
Next available point ID		PROG
Real-time rover operations	77	7, 10, 12, 13
Static operations	247	Properties
North, orientate to		points in GPS mode
Stakeout	188	Setup points
O		
Offset		
Reference line	104	
Reference Plane	134	
Stakeout, height	191	
Type in		
COGO intersection	28	

R	
RANGE	37
Recall	
Default	
Auto points	204
Sets of angles	145
RECLC	184
Reference arc	
Define	91, 97
Define offsets	104
Delete	101
Enter manually	97
Gridstake	117
Manage	97
Measure to	110
Select from job	100
Stake to	113
Reference line	
Application program	91
Configuration	92
Define	91, 97
Define offsets	104
Delete	101
Enter manually	97
Gridstake	117
Manage	97
Measure to	110
Methods	98
Select from job	100
Stake to	113
Reference plane	
defining	129
Tilted	130
Vertical	129
Reference point	91
REM A	37
REMOT	215
Remote point	213, 215
Access	215
Configuration	214
Use	214
Report	
Traverse adjustment	244
Resection / Resection Helmert	180
Residual	
Distribution COGO Shift, Rotate & Scale	14
Distribution throughout transformation area	52

Results	
Sets of angles	
One face	155
Two faces	153
Traverse	233, 235
Traverse Adjustment	243
Root mean square	61
RSLT1	28
RSLT2	28
RUN	139, 198
S	
Same Direction, Survey Cross Section	217
Scale	
Transformation results	61
Scale factor, combined	68
Select matching points	60
Select points, sets of angles	150
Select, DTM layer	8
Set station and azimuth	172
Set station and backsight	175
Sets of angles	
Access	144
Calculation	152
Configuration	145
Measure sets	151
Measurement methods	145
Results	
One face	155
Two faces	153
Select points	150
Sets of angles application program	143
Setup	
Application program	159
Configuration	162
Measure target points	177
Methods	172
Properties of points	161
Set station and azimuth	172
Set station and backsight	175
Shift, Rotate & Scale	
COGO, match points	41
Sideshot, traverse COGO calculation	22
SKIP	151, 196
Skip point in Stakeout	196
SSHOT	22

Stake		Traverse	
To arc	97	Adjustment report	244
To arc, grid	97	Application program	227
To line	97	Backsight screen	238
To line, grid	97	Close	233
To polyline	120	Close angle	240
To reference arc	113	Close on internal reference	241
To reference line	113	COGO calculation method	22
Stakeout		Configuration	228
Application program	187	Continuing an Existing Traverse	238
Configuration	188	Create control point	233
Difference limit exceeded	196	Delete station setup	232
Restake point	196	Point results	233
Skip point	196	Start traverse	237
Station setup, delete in Traverse	232	Traverse Information	230
Station, orientate to		Traverse Management	230
Stakeout	188	Traverse Results	235
Survey		Twostep transformation	
Application program		One point localisation	64
Auto points	201	U	
General	197	Update, coordinate system	8
Remote point	213	V	
Default screen	197	Volume Calculations	
Survey Cross Section		End	245
Direction	218	Z	
Methods	217	ZigZag, Survey Cross Section	217
Survey remote point	215		
T			
Target point	91		
Template, Survey Cross Section	217, 222		
Tolerances			
Traverse	229		
Transformation			
Requirements	49		
Set parameters	52		

Total Quality Management: Our commitment to total customer satisfaction.



Leica Geosystems AG, Heerbrugg, Switzerland, has been certified as being equipped with a quality system which meets the International Standards of Quality Management and Quality Systems (ISO standard 9001) and Environmental Management Systems (ISO standard 14001).

Ask your local Leica Geosystems dealer for more information about our TQM program.

761406-7.1.0en
Original text
Printed in Switzerland © 2009 Leica Geosystems AG, Heerbrugg, Switzerland

Leica Geosystems AG
Heinrich-Wild-Strasse
CH-9435 Heerbrugg
Switzerland
Phone +41 71 727 31 31
www.leica-geosystems.com

- when it has to be **right**

Leica
Geosystems